

The image shows the front cover of a user manual for 'The Boombox Speaker'. The cover has a solid dark blue background. At the top center is a white circular logo containing a stylized 'R'. Below the logo, the text 'THE' is in a small, white, sans-serif font. Underneath 'THE' is the word 'BOOMBOX' in a large, bold, white, sans-serif font. Below 'BOOMBOX' is the word 'SPEAKER' in a medium-sized, white, sans-serif font. At the bottom center, the words 'USER MANUAL' are written in a small, white, sans-serif font.

TABLE OF CONTENTS	
INTRODUCTION	1
UNIT 1: A GLOSSARY	2
CHAPTER 1: A GLOSSARY	2
QUICK START GUIDE	4
CHAPTERS 2-10: A GLOSSARY	4
FUNCTIONS	5
HELP-UP GUIDE	6
CHAPTER 11: A GLOSSARY	7
POWER BANK FOR YOUR PHONE	7
PLACING A PHONE IN THE POWER BANK	7
AUX IN/VIDEO	8
POWER MODES	9
RESET FUNCTION	10
SAFETY GUIDELINES	11
FAQS/ADDITIONAL RESOURCES	12
SUPPORT	12
LIMITED WARRANTY	13
SPECIFICATIONS	13

INTRODUCTION

Welcome to your new Raycon Bluetooth Speaker!

We are Raycon. We create carefully crafted wireless audio products for go-getters who want that tech that keeps up with them. We teamed up with design engineers, leading tech makers, and platinum artists to design your product just how you like it.

We believe in the early days and the one-memo-miles of the world. We're sure you inspired by you.

Before using your speaker, we strongly encourage you to fully read through this user guide. You can also visit our support center at www.rayconbluetooth.com. The web page has more specific details and answers to common questions you may have. Your product's performance, charge fully before first use.

Poling ID: **The Bluetooth Speaker**

INTERNATIONAL WARRANTY

For international versions of the manual, please visit www.rayconbluetooth.com.

UNIT AT A GLANCE

- 1. Power On/Off
- 2. Walk-Ink
- 3. SD
- 4. Play/Replay
- 5. Battery Indicator
- 6. Light/Screen
- 7. Noise/Volume Up
- 8. Previous/Volume Down
- 9. Start/Power Output
- 10. Charging Port
- 11. AUX & IR Port
- 12. Noise SD Slot
- 13. Reset Slot



The diagram shows the top of the Walk-Ink device. Callout 1 points to the power button. Callout 2 points to the 'Walk-Ink' text. Callout 3 points to the SD card slot. Callout 4 points to the play/replay button. Callout 5 points to the battery level indicator. Callout 6 points to the light/screen area. Callout 7 points to the volume up button. Callout 8 points to the previous/volume down button. Callout 9 points to the start/power output button. Callout 10 points to the charging port. Callout 11 points to the AUX & IR port. Callout 12 points to the noise SD slot. Callout 13 points to the reset slot.

FEATURE AT A GLANCE

- THREE SOUND PROFILES**
Being the noise you wish with three distinct sound profiles.
- MULTI LINK MODE**
Use a multi-speaker or multi-room speakers via Bluetooth to link up to two speakers or multi-room setup of sound.
- WAX INFUSED RESISTANCE**
Holds or builds your party is protected from whatever nature throws at it. Because the Boombox is designed in 100% water resistant.
- THREE OF WIRELESS PLAY TIME**
A long play battery means you the Boombox brings it until closing time.
- ON THE GO SHARP**
Take your party on the road with the added portability of an on the go trip.
- PARTY LAD LIGHTS**
When you're at the Boombox is the club. Bring a light show wherever you go.

QUICK START GUIDE

1. Hold "Q" for about 3 seconds to power speaker on. The speaker will start pairing mode automatically.

2. Press the touchpad device, go to Bluetooth settings and enable Bluetooth on. Search for "The Sboombox Speaker" and select it to pair.

3. Enjoy your Sboombox Speaker!

CHARGING YOUR DEVICE

1. Use a standard **5V/2A charger** or a **PC** to charge this device.

2. While charging, the LEDs will stay on after fully charging, at 4 LED lights will turn off. Charge time should be 4-6 hours.

Charging **Fully Charged**

FUNCTIONS

CONTROL PANEL TOP VIEW

POWER PLAY/PAUSE STOP SKIP REWIND F.W.

FUNCTIONS	
PHONE CALL CONTROL	
	Answer/Redial Call Phone Reject Call Hold (H) 1/2 Answer Call (redial) Answer/Phone and Redial (Speaker) (Shouting in call) Hold (H) 1/2
VOICE MESSAGE LISTENING	
	Activate Message Assistant Hold (H) 1/2

MULTI-LINK MODE

Put two Baseboard Speakers together with an iPod/iPhone/iPad.

1. Make sure both speakers are connected to any iPod/iPhone/iPad device.
2. On one speaker, press "OFF" to change position, a voice prompt "The audio link speakers are successful" is issued.
3. From the second device, search for "The Baseboard Speaker" and select it to pair.

POWER BANK FOR YOUR PHONE

Using a charging cable that is compatible with your phone (not supplied), connect to the Power Output Port on the boombox to begin charging.

PLAYING MUSIC FROM MICRO SD CARD

You can also play music using a Micro SD card. Note that if you use Bluetooth Power Speaker in Bluetooth Mode, inserting a Micro SD card will automatically switch the speaker to Micro SD mode. To return to Bluetooth Mode, remove the Micro SD card.

1. Hold "A" for about 3 seconds to turn speaker on.
2. Insert a Micro SD card into Micro SD port. The speaker will play the stored music automatically.

The diagram shows the side of the speaker with a slot labeled "MICRO SD". An inset shows a close-up of a Micro SD card being inserted into the slot. The card is labeled "Micro SD" and "8GB".

AUX-IN MODE

To enjoy music from your MP3/MP4 player on either compatible device, use the supplied aux-in cable to connect from Line Out port on the device to the Aux-In port on your Region 800000 speaker.

The speaker will automatically switch to AUX Mode when a compatible device is connected using the aux-in cable. To return to Bluetooth mode, disconnect AUX cable from speaker.

SOUND PROFILES

Your sound, your way. Our sound profiles are designed by artists and producers at the top of the industry. Press  to toggle between sound profiles.

BALANCED SOUND	BASS SOUND	PURE SOUND
A limited sound that is great for all-around performance and clarity.	A limited sound that is great for songs with strong bass and with lots of bass lines.	A limited sound that is great for songs with strong vocals to hear every single note.

FAQ & ADDITIONAL RESOURCES

Visit www.kynix.com/global/customer-support

SUPPORT

If your device is not functioning correctly, please visit www.kynix.com/global/customer-support for customer support, and we will be more than happy to help you.

LIMITED WARRANTY

Visit www.kynix.com/global/customer-support/warranty

SPECIFICATIONS

Parting Name: The Bluetooth Speaker
 Part Number: KSD-1000
 Battery Capacity: 7400mAh
 Play Time: up to 10 hours
 Support Profile: A2DP/AVRCP/SDP
 Frequency Response: 80Hz-20KHz
 Bluetooth Range: up to 10 Meter

RFCA WARNING:

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTICE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause interference to radio communications. It has been found that this equipment may cause interference when used in close proximity to a television or other radio receiving equipment. It is guaranteed that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, the user is advised to take the following steps to correct the interference by one or more of the following measures:

- Accient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Refer to the instructions for the equipment for additional instructions for help. The device has been evaluated to meet general EMC requirements.
- The device can be used in portable equipment condition without restriction.

Et Conformité

- English:
- This device complies with Industry Canada license exempt RSS (radio) requirements.
- Operation is subject to the following two conditions:
- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause unintended operation of the device.
- French:
- Le présent appareil est conforme aux CNR d'Industry Canada applicables aux appareils radio exempts de licence.
- L'exploitation est soumise aux deux conditions suivantes :
- (1) L'appareil ne doit pas produire d'interférence, et
- (2) L'appareil doit accepter toute interférence, y compris toute interférence pouvant causer un fonctionnement non désiré de l'appareil.

Les appareils radio exempts de licence, exploités en continu ou à des intervalles courts.

(1) L'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

RSS-40: 3420V-1466952
 IC: 2785-895653

 @mycorgished