



RAYCON PORTABLE BOOMBOX SPEAKER

QUICK START GUIDE



CONNECT



STEP 1

Press and hold the power button for 1-3 seconds to turn on the speaker. The speaker will enter pairing mode.

STEP 2

Select "Raycon Portable Boombox" from the list of available devices in your Bluetooth settings.

FUNCTIONS



1



Volume Down

Tap x1



Previous Track

Hold 3 sec

4



Exit Auracast

Tap x1

Pair/Reconnect

Hold 3 sec



Pair speakers (TWS)

Tap x2

2



Volume Up

Tap x1



Next Track

Hold 3 sec

5



Play/Pause

Tap x1

6



Change Light Mode

Tap x1



Turn Off Light

Hold 3 sec

3



Power

Hold 3 sec

7



Auracast On/Off

Tap x1

8



Extra Bass On/Off

Tap x1

Combo: Hold + and — for 5 sec → Reset speaker

ADVANCED FEATURE - MULTI-SPEAKER MODES

Your speaker supports two ways to play audio across multiple speakers

TWS (STEREO PAIRING)

Pair 2 speakers for left + right stereo sound.

- Double-tap the Bluetooth button on both speaker

Perfect for more immersive, directional audio.

AURACAST (MULTI-SPEAKER)

Play audio on multiple speakers at once.

- Tap the Auracast button to start or join
- Tap again to leave

One speaker connects to your device, and others can join and play in sync.

TIP

Turning on Auracast enables broadcast mode.

Connecting speakers is a separate step.

	TWS	AURACAST
Speakers	2 only	Unlimited
Audio	Split L/R stereo	Same audio,all in sync
Activate	Double-click	Short-press
Use case	Stereo Listening	Party/Broadcast

TROUBLESHOOTING/FAQ

BLUETOOTH CONNECTION/SOUND INTERFERENCE?

- Ensure speaker is within 10 meters (33 feet) of connected Bluetooth device
- Check the battery level: If the battery level of either the speaker or your connected device is low, it can cause the connection to be weak or to drop.

SPEAKER WILL NOT TURN ON?

- Charge the speaker: Make sure the speaker is fully charged by plugging it into a power source using the provided charger cable.
- Check the Power Button: Make sure the Power Button on the speaker is not stuck or broken. Press the Power Button firmly to ensure it is engaging.
- Reset the speaker: Follow the Reset Instructions in this user manual to reset the speaker.

MULTI-LINK IS NOT WORKING?

- Confirm both speakers are charged, powered on, and they are both disconnected from any Bluetooth device and in Pairing Mode.
- Be sure to use only one speaker as the parent device by holding the Play Button on just one speaker.
- Ensure both speakers are in close proximity of each other.

SAFETY GUIDELINES

- Be wary of any edges, uneven surfaces, and metal parts, including on accessories and product packaging, to prevent any possible injury or damage.
- Listen to music at a proper volume to avoid damaging your hearing and speaker.
- Do not store in high temperatures, such as in a hot vehicle or in direct sunlight.
- Store in cool and dry area.
- Do not drop or cause undue impact to the speaker.
- Do not modify, repair, or dismantle the product on your own.
- Ensure all port covers are securely closed if exposing speaker to liquid, and do not expose speaker and any of its supplied parts to liquid such as rain for prolonged periods of time.
- Please see IPX6-Rating for more guidelines.
- Do not expose the speaker to water while charging, as doing so may result in damage to the speaker or the power source.
- When cleaning this speaker, use a soft dry cloth. For more severe stains, dampen the cloth with water only. Anything else increases the chance of dissolving the paint or damaging the plastic.

FAQ & SUPPORT

If your device is not functioning correctly, please email support@rayconglobal.com for customer support, and we will be more than happy to help you.

LIMITED WARRANTY

Visit: www.rayconglobal.com/warranty.

SPECIFICATIONS

Model Number: RBS955
Bluetooth Pairing Name: Raycon Portable Boombox
RDID: D955-26E-0526
Bluetooth Version: BT6.0
Battery Capacity: 7.2V/4000 mAh
Input: 5V/3A
IP Rating: IPX6
Charging Time: 2.5 to 3 hours
Play Time: About 8 hours, bass on, 50% volume
Bass Speaker Size: 3" / 4", 20W x 2
Treble Speaker Size: 4", 10W x 1
Speaker Power: 50W
Weight: 4.2 lbs
Product Size: 264.4 x 120.4 x 130mm
Bluetooth Operating Range: 25m to 30m
FCC ID: 2AZOV-RBS955

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction



FCC ID: 2AZOV-RBS955