





SK114

4MP WiFi Mini Ball Camera
Operation Instruction

Important Information



for Using Your Security Camera

Before using your security camera, please read the user manual thoroughly. If you encounter any issues during setup or operation, please contact us with your order number and problem description. We are committed to providing a fast solution within 24 hours.

Common setup issues such as networking connection, motion detection, false alarms, and battery management can be easily solved through proper settings. To ensure optimal performance and minimize false alarms, please follow the setup instructions carefully and adjust the camera settings as needed.

Thank you for choosing our security cameras. We're here to help you with any questions or concerns you may have.



360days limited
warranty



tech@camoon.net




www.camoon.net


Camera Guide




Packing List




PTZ Camera



Screw Pack



Camera Wall Bracket



power adapter



Quick Start Guide

Product Specification

Model	SK114
Lens Field of View	92°
Audio	Full Duplex 2 way Audio
Pan tilt rotation angle	Horizontal: 360° Vertical: 90°
Microphone	Microphone with noise and echo cancellation
Night Vision	Infrared & White Light
Motion Detection	PIR, adjustable sensitivity, detects up to 26 feet (8m)
Networking	2.4GHz & 5GHz WiFi
Operating Temperature	14°F to 140°F (-10°C to 60°C)

FAQ

Q: How to turn on the camera?

A: Plug the camera into the power source. After 3 seconds, the camera will start to flash a white light..

Q: How to turn off the camera?


A: Unplug the power supply of the camera.

Q: How to reset the camera?

A: Open the silicone cover at the bottom of the camera sphere, press the reset button for about 3 seconds until you hear a voice prompt, Then the white light began to flicker.

Step 1: Charge your camera battery

Fully charge your camera battery. Plug into a USB power source (5V) using the provided cable.



Step 2: Download the APP

Please scan the QR code or search “HG Cam” in Google Play Store or APP Store to download the APP.



Vistaflow

IOS APP




Vistaflow

Android APP



Step 3: Add your camera into APP

1. Turn on the camera.
2. Open the App, sign up for a free account, and log in.
3. On the home page, tap the “+” icon in the top right corner.
4. Connect the camera via Bluetooth or follow the on-screen instructions to add the camera.




Mounting the Camera



Check the Wi-Fi signal at the installation spot with your phone before setting up the camera to ensure the router provides a strong connection.



Mount the camera 2-3 meters high and angle it downward about 15°.



The camera may not detect objects moving straight toward its center. Adjust the angle so moving objects pass across the camera's view, making it easier for the PIR sensor to detect them.




Installation Tips

Please avoid installing the camera in the following locations:

1. Directly facing moving trees.
2. Directly facing roads with heavy traffic or many pedestrians.

** These conditions may cause the PIR sensor to trigger frequent false alarms, resulting in unnecessary power consumption and affecting normal use.*



FCC Warning Statement

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Important: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Email: tech@camoon.net
website: www.camoon.net