

OREIN智能球泡说明书

640mm*120mm

8折页

裁剪线

折线

OREIN

illuminate for a better life

WiFi RGBW LED Bulb Quick User Guide

WiFi RGBW LED-Lampe Kurzanleitung

Ampoule LED RGBW WiFi Guide de l'utilisateur rapide

Bombilla LED WiFi RGBW Guía rápida del usuario

WiFi RGBW LED電球 クイックユーザーガイド

We appreciate the trust and confidence you have placed in OREIN through the purchase of smart bulbs. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs.

Thank you for
choosing OREIN

■Basic Information

★Suitable for damp locations.

★For lamps with a weight significantly higher than that of the lamps for which they are a replacement, attention should be drawn to the fact that the increased weight may reduce the mechanical stability of certain luminaires and lamp holders and may impair contact making and lamp retention.

★The bulb is based on protocol WiFi, realizing the function of on/off, brightness dimming, tunable white and RGB color changing.

CONTROL YOUR LIGHTS FROM ANYWHERE In the world from the palm of your hand. The Orein produces beautiful high quality light that you can dim, or tune the light's color temperature from 1800 to 6500K as well as RGBW color changing with 16million colors and control from your smartphone or tablet. Easy to setup, bulbs fit into your standard household sockets - no need for installation by an electrician. A wireless network is required to operate bulbs.

SET LIGHT SCENES: Create rich indirect light scenes in your home by dim. Schedule to turn on the lights so you don't come home to a dark house. Set automated timers, or program the bulb to gradually increase brightness in the morning like the sunrise for a more pleasant, natural alarm.

SAVE ENERGY: OREIN bulbs use up to 84% less energy than traditional incandescent bulbs and last up to 25,000 hours making them a smart choice for energy conscious homes.

■Quick Start Guide

The following are the general user guide

① Screw the bulb into a standard socket.

② Turn on the bulb with your wall switch to apply power to the bulb. If you're not using a wall switch, then use your alternate method to apply power to the bulb.

③ Get the AiDot App for Android or iOS.



④ Create an account and sign in, enable your location and open your Bluetooth.

① Press "+" button to add the light bulb.



② Automatic discovery devices which to be added(through BLE protocol), then follow the instructions on App.

■Resetting Bulb
Restore the bulb(s) to factory default by switching 6 times.

① Starting from wall switch OFF



② User flips the bulb switch off and on 5x over between 1-2 seconds



③ Light(s) finishes on



④ Light blinks twice



⑤ User connects light(s) to new network(remote)



⑥ Light(s) added to device list as new.



Or ① after 5 min network close, restarted by wall switch. Then light(s) finishes on(step ①).



■Safety Instructions

Restore the bulb(s) to factory default by switching 6 times.

① Switch off the power supply to the socket and allow sufficient time for the bulb to cool before removing the bulb from the fitting

② Warning: Risk of Electric Shock. Do not attempt to disassemble bulb

③ Not suitable for use with standard wall dimmers

④ Suitable for use in operation environment between -4°F and 104°F (-20°C and 40°C)

⑤ Not for use in emergency lighting.

⑥ The bulb is not suitable for totally enclosed fixtures.

⑦ Do not clean the bulb when it is on and connected to the power supply

⑧ Do not place the bulb on hot surfaces

⑨ Dispose of this device in accordance with disposal laws in your area.

⑩ For additional help, regulatory and safety information, please go to: www.orein.com

■Grundinformation

■Für Feuchträume geeignet.

■Bei Lampen mit einem Gewicht, das erheblich höher ist als das der Lampen, für die sie ein Ersatz sind, sollte darauf hingewiesen werden, dass das erhöhte Gewicht die mechanische Stabilität bestimmter Leuchten und Lampenfassungen verringern und die Kontaktherstellung und die Lampenretention beeinträchtigen kann.

■Die Glühlampe basiert auf Protocol-WiLAN und erkennt die Funktion Ein / Aus, Helligkeitsdimmung, abstimmbares Weiß und RGB-Farbwechsel.

STEUERN SIE IHRE LICHTER VON ÜBERALL auf der Welt aus Ihrer Handfläche. Das Retrofit erzeugt wunderschönes, hochwertiges Licht, das Sie dimmen oder die Farbtemperatur des Lichts von 1800 bis 6500 K einstellen können, sowie RGBW-Farbwechsel mit 16 Millionen Farben und Steuerung über Ihr Smartphone oder Tablet. Die Lampen sind einfach einzurichten und passen in Ihre Standard-Haushaltssteckdosen - die Installation durch einen Elektriker ist nicht erforderlich. Für den Betrieb von Glühlampen ist ein drahtloses Netzwerk erforderlich.

LICHTSZENEN EINSTELLEN: Erstellen Sie durch Dimmen reichhaltige indirekte Lichtszenen in Ihrem Zuhause. Planen Sie, das Licht einzuschalten, damit Sie nicht in ein dunkles Haus zurückkehren. Stellen Sie automatische Timer ein oder programmieren Sie die Glühlampe so, dass die Helligkeit am Morgen wie beim Sonnenaufgang allmählich erhöht wird, um einen angenehmen, natürlichen Alarm zu erzielen.

ENERGIE SPAREN: OREIN-Lampen verbrauchen bis zu 84% weniger Energie als herkömmliche Glühlampen und halten bis zu 25.000 Stunden, was sie zu einer intelligenten Wahl für energiebewusste Haushalte macht.

■Schnelstartanleitung

Im Folgenden finden Sie die allgemeine Bedienungsanleitung:

① Schrauben Sie die Glühlampe in eine Standardfassung.


② Schalten Sie die Glühlampe mit Ihrem Wandschalter ein, um die Glühlampe mit Strom zu versorgen. Wenn Sie keinen Wandschalter verwenden, verwenden Sie Ihre alternative Methode, um die Glühlampe mit Strom zu versorgen.

③ Holen Sie sich die AiDot App für Android oder iOS.



④ Erstellen Sie ein Konto und melden Sie sich an, aktivieren Sie Ihren Standort und öffnen Sie Ihr Bluetooth.

⑤ Drücken Sie die Taste "+", um die Glühlampe hinzuzufügen.



⑥ Automatische Erkennungsgeräte, die über das BLE-Protokoll hinzugefügt werden sollen, folgen dann den Anweisungen in der App.

■Glühlampe zurücksetzen

Stellen Sie die Werkseinstellung (n) durch 6-maliges Umschalten auf die Werkseinstellungen zurück.

① Ausgehend von der Wandschalter AUS

② Der Benutzer schaltet den Wandschalter zwischen 1-2 Sekunden 5x aus und wieder ein

③ Licht (a) erlischt




④ Das Licht blinkt zweimal




⑤ Der Benutzer verbindet die Leuchte (n) mit dem neuen Netzwerk (Remote).

⑥ Die Leuchte (n) wurde als Neuheit zur Geräteliste hinzugefügt.



⑦ Oder ① nach 5 Minuten Netzwerkschluss, Neustart durch Wandschalter. Dann gehen die Lichter an(Schritt ①).



⑧



⑨



⑩




⑪



⑫



⑬



⑭




⑮




⑯



⑰



⑱



⑲




⑳




㉑




㉒



㉓



㉔



㉕




㉖



㉗



㉘



㉙



㉚



㉛



㉜



㉝



㉞



㉟



㊱



㊲



① Nicht zur Verwendung in der Notbeleuchtung.

② Die Glühlampe ist nicht für vollständig geschlossene Leuchten geeignet.

③ Reinigen Sie die Glühlampe nicht, wenn sie eingeschaltet und an die Stromversorgung angeschlossen ist

④ Stellen Sie die Glühlampe nicht auf heiße Oberflächen

⑤ Entsorgen Sie dieses Gerät gemäß den Entsorgungsgesetzen in Ihrer Nähe.

⑥ Weitere Informationen zu Hilfe, Vorschriften und Sicherheit finden Sie

⑦

⑧

⑨

⑩

⑪

⑫

⑬

⑭

⑮

⑯

⑰

⑱

⑲

⑳

㉑

㉒

㉓

㉔

㉕

㉖

㉗

㉘

㉙

㉚

㉛

㉜

㉝

㉞

㉟

㊱

㊲

㊳

㊴

㊵

㊶

㊷

㊸

㊹

㊺

㊻

㊼

㊽

㊾

㊿

0

1

2

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97