

SHRP-TWS10 - Open Air Clip True Wireless Earbuds

User Manual - Black and White Printing

5 in

5 in

6.5 in

⚠ WARNING

Please disconnect the charger and turn your product off before cleaning. Warranty will be voided if you attempt to disassemble the product yourself. Placing the product in direct sunlight can cause premature aging. Avoid operating in dusty places or dirty environments. Avoid extreme heat or cold when using product (-10°C to 40°C). Avoid spilling liquid or inserting foreign objects into the device. The product must not be dropped or subjected to intentional impact. Disassembly, impact, sun exposure, fire, and compression can cause battery failure. If the battery is compromised please do not continue to use.

☰ WARRANTY

This product has a 1 year warranty against defects in manufacturing under regular consumer use. For instructions about how to obtain warranty service for your product, please contact Customer Service: info@primebrandsgroup.com.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. This product is compatible with all wireless audio devices, Bluetooth® and non-Bluetooth®.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

⚠ WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov

PE
GR

©2026 Prime Brands Group. All rights reserved. All trade names are registered trademarks of the respective manufactures listed. Made in China.
Prime Brands Group • Brooklyn, NY 11232 • SHOPSOAR.COM

Sharper Image® name and logo (including the 77 logo) are trademarks or registered trademarks. Distributed by ©2026 Prime Brands Group, INC. Brooklyn, NY 11232. All rights reserved. For Technical Support, Please visit www.shopsoar.com. Colors and styles may vary. Before use, read all warnings found in the included instruction manual or refer to our website www.primebrandsgroup.com for more information.

SHARPER IMAGE®

OPEN AIR CLIP



USER MANUAL


6.5 in

SHARPER IMAGE®

Thank you for choosing the Open Air Clip True Wireless Earbuds by Sharper Image. Designed for comfort and everyday use, these open-ear, wraparound earbuds deliver clear sound while keeping you connected to your surroundings. With voice assistant support, multifunction touch controls, and a sleek LED display charging case, these earbuds are built for all-day wear and effortless control.

Includes: Open Air Clip True Wireless Earbuds, Digital Display Charging Case, USB-C Charging Cable, & User Manual

🔑 PRODUCT KEY



- Multi-Function Button
- Open-Air Speaker
- Clip-on Silicone Earbuds
- Earbud Charging Connectors
- Earbud LED Indicator Light
- Digital Display Charging Case
- Case Charging Connectors
- LED Power Display
- USB-C Power Input (Back)

📶 SPECS

Bluetooth Version: 5.3
Range: Up to 30 ft
Battery Capacity: 200 mAh
Music Playtime: Up to 3 hours
Charging Time: 1-1.5 hours



▶/|| MULTI-FUNCTION KEY CONTROLS

ANSWER A CALL: Tap left or right earbud once
HANG UP: Tap left or right earbud once
REJECT A CALL: Tap left or right earbud for 2 seconds
ACTIVATE VOICE ASSISTANT: Tap either earbud for 2 seconds
PLAY/PAUSE MUSIC: Tap left or right earbud once
VOLUME UP: Tap left earbud 3 times
VOLUME DOWN: Tap right earbud 3 times
NEXT TRACK: Tap right earbud 2 times
PREVIOUS TRACK: Tap left earbud 2 times

📶 PAIRING

Make sure Bluetooth is enabled on your device.

Open the charging case and remove the earbuds. They will automatically power on and enter pairing mode.

On your device's Bluetooth settings, select "SHRP-TWS10". When paired successfully, you'll hear a voice prompt.

Note: Your earbuds must be within 30 feet (10 meters) of your device to pair. Once paired, they'll automatically reconnect the next time they're powered on.

🔋 BATTERY & CHARGING

LOW BATTERY ALERT
When the battery is low, a warning sound will play before shutdown.

CHARGING THE CASE
Use the included USB-C cable to charge the case via wall adapter.

CHARGING THE EARBUDS
Place the earbuds inside the charging case. The red LED will turn on while charging and switch off once fully charged.

POWERING ON & OFF

- Earbuds power on automatically when removed from the case.
- Earbuds power off automatically when placed back in the case.

FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.