


I. 配件清单:

- 1* 蓝牙音箱
1*Type C 充电线
1* 用户手册

2. 参数:

蓝牙版本: 5.3
材料: ABS+铁网
电池: 1200mAh
扬声器: 5W
功能: BT/FM/TF/AUX/USB/LED
尺寸:170x77x107mm

3. 功能及按键



- ① 暂停/播放按键
② 上一曲/减小音量按键
③ 下一曲/增加音量按键
④ M 按键
⑤ TF 卡槽
⑥ AUX 孔
⑦ USB 卡槽
⑧ 充电指示灯
⑨ 充电孔

配对

打开设备时, 会有声音提示音箱已打开。
激活手机上的蓝牙功能, 搜索并连接蓝牙设备“M10”。

开机/关机/功能按键

长按开机/关机
短按切换 BT/FM/TF Card/AUX/USB, 功能。

切换到 FM 模式时, 短按 ④ 按钮会自动搜索 FM 频道。短按音量按钮可选择下一个或上一个预设电台, 长按音量按钮可调节音量以获得所需的音量。

播放/暂停按钮

短按可播放或暂停音乐。

M键按钮

长按可切换到不同的灯光模式。

下一曲/增大音量

短按切换到下一首音乐

长按增加音量

上一曲/减小音量

短按切换到上一首音乐

长按减小音量

USB/TF 卡读取

将 USB 驱动器/TF 卡插入扬声器可自动播放 MP3 文件。

短按 ①/ ③ 按钮切换到下一首/上一首音乐。

长按①/③按钮可调节音量。

充电端口

将 Type-C 充电线（附带）的小端与音箱的 Type-C 端口连接。

将充电线的大端连接到电脑的或者墙充（没包含）。充电时, LED

指示灯将变为红色。充满时, LED指示灯将熄灭。

Q1:如何后台语音唤醒手机助手？

手动点击主界面麦克风。
可以直接说:“你好小云”即可唤醒。

Q2:拨打电话操作指南？

目前软件支持号码拨打和通讯录人名拨打功能, 例如:

可以直接说:“你好小云, 拨打张三电话”。

唤醒状态下, 说“打张三电话”或打电话给张三。

唤醒状态下, 说“张三电话”。

唤醒状态下, 说“拨打1000000000”(支持号码拨打)。

Q3: 软件支持来电语音接听、挂断电话吗？

不支持该功能。

Q4:导航功能操作指南？

可以直接说:“你好小云, 导航到xxx酒店/大厦/广场/地铁”。

温馨提醒:导航功能需要开启系统设置中GPS定位功能。

由于多个城市存在相同地名的可能性, 地名前加上具体省份、

城市或街道等详细信息, 识别更精准。

如:导航到深圳市世界之窗。

Q5: 控制音量小大指南？

可以直接说:“你好小云, 调大音量/调小音量”。

也可以直接说:“你好小云, 音量调到20%/音量调到100%”。

Q6:打开手机APP指南？

例如您可以直接说:“你好小云, 打开微信”。

例如您可以直接说:“你好小云, 打开京东”。

Q7:音乐播放操作指南？

可以直接说:“你好小云, 播放音乐”(随机播放)。

可以直接说:“你好小云, 播放xxx的歌曲”(指定歌手名)。

可以直接说:“你好小云, 播放歌曲xxx”(指定歌曲名)。

可以直接说:“你好小云, 讲个笑话”。

可以直接说:“你好小云, 播放郭德纲相声”。

播放状态下, 可以说:“你好小云, 上一曲”、“下一曲”、

“暂停播放”、“继续播放”、“退出播放”等指令。

Q8:查询天气指南？

可以直接说:“你好小云, 今天的天气”(默认当前城市)。

可以直接说:“你好小云, 后天的天气”(默认当前城市)。

可以直接说:“你好小云, 北京明天的天气”(指定城市)。

可以直接说:“你好小云, 现在几点”(当前时间)。

注意:天气查询范围限定于后7天内

Q9: 手机刚更新了联系人, 打电话时软件未能识别？

如更新了联系人号码,需退出软件重新开启, 系统会自

动刷新联系人号码。

AI智能蓝牙使用说明（仅AI版使用）

1.首先打开手机“应用商店”，下载并安装“小云助手”APP和“QQ音乐”APP

2.打开已安装的QQ音乐，进行注册、登陆并授权

3.进入QQ音乐---打开“我的”---“设置”---将“流量提醒”关闭

4.进入QQ音乐---打开“我的”---“设置”---将“允许其它应用同时播放”打开，否则有其它应用时可能会关闭QQ音乐而引起无法打开

5.打开已安装的小云助手，进行注册并登陆，同时所有弹出提醒框全部同意并进行使用授权

6.打开您所购买的智能AI产品，并与手机进行蓝牙连接

7.连接成功以后，进入到“小云助手”APP页面，提示“认证成功”说明已可以正常使用

8.连接成功以后，对着手机说“你好，小云”可以唤醒

9.唤醒APP以后可以说出您的需求，例如：“你好，小云，我要听歌”如果没有明确要求，APP随机进行播放

10.APP支持

序号	服务	支持平台	备注	序号	服务	支持平台	备注
1	地图	高德	内置	1	百科知识	百度	内置
2	在线音乐	QQ音乐	安装APP	2	翻译	云动	内置
		喜马拉雅	内置	3	单位换算	云动	内置
3	网络电台	考拉	内置	4	闲聊	云动	内置
		乐听	内置	5	有声读物	喜马拉雅	内置
4	新闻	中国人民大学	内置			酷我畅听	内置
5	天气	墨迹	内置			听伴	内置
		云动	内置	6	股票	懒人听书	内置
6	股票	云动	内置			云动	内置



扫描关注及下载


1. Included:

- 1*Bluetooth Speaker
1*Type C Charging Cable
1*User Manual

2. Specifications:

- Bluetooth version: 5.3
- Material: ABS+Iron mesh
- Battery: 1200mAh
- Speaker: 5W
- Function: BT/FM/TF/AUX/USB/LED
- Dimension: 170x77x107mm

3. Functional buttons



- ① Play/Pause button
② Previous music/Decrease volume
③ Next music/Increase volume
④ M key button
⑤ TF card port
⑥ AUX port
⑦ USB port
⑧ LED indicator
⑨ Charging port

Pairing

When you turn on the device, a sound will indicated the speaker is on.
Activate the bluetooth feature on your phone, and set the phone to search for bluetooth device "M10".

ON/OFF/Mode button

Long press to turn on/off the speaker.
Short press to switch among BT,FM,TF Card,AUX,USB drive.

When switch to FM mode,short press the ④ button to search the FM channels automatically. If you need to stop searching, just short press again.The searched FM channels will be saved automatically.Short press the volume button to select next or previous preset station.Long press volume button to adjust the volume to obtain the desired volume level.

Play/Pause button

Short press to play or pause music.

M key button

Long press to change to different light mode.

Next music/Increase volume

Short press to change to next music
Long press to increase the volume

Previous music/Decrease volume

Short press to change to previous music
Long press to decrease the volume

USB/TF card reading

Insert the USB drive/TF card into the speaker to play MP3 file automatically.
Short press the ①/ ③ button to change to next/previous music.Long press the ①/ ③ button to adjust the volume.

Charging port

Connect the small end of the type-C charging cable (included) to the type-C port of the speaker. Connect the larger end of the cable to your computer's USB port or an AC adaptor(not included).The LED indicator will turn red while charging.Once fully charged, the red LED will turn off.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.