

Care and Usage Instructions

To Turn on vibrating Functions:

1,hold the  3 seconds until the button LED display turns on.

2,Press  to cycle through 10 vibrating functions.

Using the Wireless Remote:

1,Once the toy is powered on,press the  to cycle through 10 vibrating functions.

2,press ▲ to cycle throgh 10 higher-intensity vibrating functions.

3,Press ▼ to cycle through 10 lower-intensity vibrating functions.

On the Wireless Remote: Hold down  to turn off vibrations temporarily.LED Display on the VIBE will remain on.

On the Vibrating Toy: Hold down  on the toy until the LED disply turns off.

To Charge:

Charge completely before first use.Plug the included cable into a USB power source ,then locate charging port on the vibe and plug in.The LED display will blink while charging .Once the LED stay lit,you Vibrator is fully charged.

Charge Time:90 minutes.Usage Time:45 minutes.

Wireless Remote Uses AAA Battery(not included)

specifications:

emote Battery: 1AAA Batteries

Model:I-MX-1472-09

Sample Description:MOOD VIBRATING EGG WITH REMOTE - ORANG

WARNING FOR VIBRATING PRODUCTS:To avoid injury or aggravation of pre-existing conditions,this product not be used on swollen or inflamed areas or skin laceataions. No meducal claims are warranted or implied by the use of this product.

EU Authorised Representative(for authorities only)ProductIPAR Services Galvanistraat 1,6716 AE

Ede The Netherlands·EUAR@productip.com

UK Authorised Representative(for authorities only)ProductIP(UK)Ltd.

8,Northumberland Av.London WC2N 5BY·UKAR@productip.com




FCC ID: 0000000-000000



PRODUCT USES AND WARNINGS:

To ensure the safe use of our products and to extend product life, before using our products please scan the QR code and review our Product Use Guidelines. Although all Doc Johnson products are designed and manufactured with great care, we urge our customers to practice sex toy safety. These Guidelines are also available on our website at <https://www.docjohnson.com/safety-practice>.



This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

RF warning for portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.