



User Manual


Tablet Wireless Keyboard, Portable Compatible w/ PC, MacOS, Laptop, Smartphone, Tablet

Manuel de l'utilisateur

FR Tablet Wireless Keyboard, Portable Compatible w/ PC, MacOS, Laptop, Smartphone, Tablet

Manual del usuario

ES Tablet Wireless Keyboard, Portable Compatible w/ PC, MacOS, Laptop, Smartphone, Tablet



Note: The keyboard layout varies depending on your model.
To see the MX layout, see the ES section.

Note: The keyboard layout varies depending on your model.
To see the MX layout, see the ES section.

Note: The keyboard layout varies depending on your model.
To see the MX layout, see the ES section.

EN	 Page	3
FR	 Page	XX
ES	 Página	XX

Contents

Safety Instructions	4
Package Contents.....	5
Compatibility	5
Parts Overview.....	5
Setting Up the Keyboard.....	7
Using the Keyboard.....	9
Cleaning and Maintenance	11
Troubleshooting.....	11
Specifications	13
Legal Notices	13
Feedback and Help.....	15

Safety Instructions

Precautions: See instructions before use. Use with caution. This product must be handled by an adult.



Read these instructions carefully and retain them for future use. If this product is passed to a third party, then these instructions must be included.

When using the product, basic safety precautions should always be followed to reduce the risk of injury, including the following:

⚠ DANGER Risk of suffocation! Keep packaging materials away from children and pets. These materials are a potential source of danger, such as suffocation.

- ▶ Never use this product if it is damaged.
- ▶ Do not insert any foreign objects inside the casing.
- ▶ Protect this product from extreme temperatures, hot surfaces, open flames, direct sunlight, water, high humidity, moisture, strong jolts, flammable gases, vapors, and solvents.
- ▶ Keep this product out of the reach of children and pets.

Battery Warnings

- ▶ Keep away from children. Seek immediate help if swallowed.
- ▶ Do not dispose of batteries in fire.
- ▶ Store unused batteries in their original packaging away from metal objects. If already unpacked, do not mix or jumble batteries.
- ▶ If the battery leaks, avoid contact with skin and eyes. Rinse affected areas immediately with plenty of clean water, then consult a doctor.

Package Contents


- ▶ Keyboard
- ▶ USB-C data/charging cable
- ▶ Nano receiver
- ▶ *User Manual*

Compatibility

- ▶ Windows, iOS, or Android
- ▶ An available USB-C port


Parts Overview

Keyboard Front



No.	Icon	Description
1		Open media player
2		Decrease volume
3		Increase volume
4		Mute
5		Previous track
6		Next track
7		Play/Pause track
8		Stop track
9		Open browser home page
10		Open email client
11		Open "This PC" folder
12		Open favorite webpage
13		Function lock
14		Battery/Function lock indicator
15	2.4G/ 	2.4G/wired connection indicator
16		Bluetooth indicator
17		Caps lock/operating system indicator
18	2.4G	2.4G wireless connection
19		Bluetooth connection (device 1/2)
20	Windows Android IOS	Select operating system
21	Fn	Function

Keyboard Side and Back




Setting Up the Keyboard

1. Make sure that your keyboard has enough power. See "Charging the Keyboard" on page 7.
2. Connect your keyboard to your device using a wired or wireless connection. See "Connecting the Keyboard" on page 8.

Charging the Keyboard

NOTICE: The battery indicator blinks red when the keyboard's battery is low.

Connect the provided USB-C cable from the keyboard's USB-C port to your device or wall charger. The battery indicator lights solid red while charging, then turns off when the battery is fully charged.



Connecting the Keyboard

You can connect your keyboard with the 2.4G nano receiver, Bluetooth, or a USB-C cable. Switch between devices by pressing **Fn + 2.4G**, **Fn + 1** (Bluetooth device 1) or **Fn + 2** (Bluetooth device 2).


2.4G Nano Receiver

1. Gently remove the nano receiver from the back of your keyboard's nano receiver storage slot.
2. Connect the receiver to your device, and turn on the keyboard.
3. Press **Fn + 2.4G** to switch to the 2.4G channel. The 2.4G indicator lights solid white during use.

Bluetooth

1. Turn on your Bluetooth device, then make sure that Bluetooth is turned on.
2. Slide your keyboard's power switch **ON**.
3. Press **Fn + 1** (Bluetooth device 1) or **Fn + 2** (Bluetooth device 2). The Bluetooth indicator blinks quickly to show it is in pairing mode.

NOTICE: If the Bluetooth indicator blinks slowly, it is not in pairing mode. Press and hold **Fn + 1** or **Fn + 2** for three seconds. The Bluetooth indicator blinks quickly to show it is in pairing mode.



4. Tap **Tab KB BT1** or **Tab KB BT2** on your device's screen, then tap **Add Device**. The Bluetooth indicator is green when connected to BT1 (Bluetooth device 1) and blue when connected to BT2 (Bluetooth device 2). Your keyboard is now connected to your device.

USB-C Cable (Wired Mode)

1. Slide your keyboard's power switch **OFF**.

NOTICE: The wired connection only works when the keyboard is powered off.

2. Connect the provided USB-C cable from the keyboard's USB-C port to your device. The 2.4G/wired connection indicator lights red to show your keyboard is connected.

NOTICE: If you use a third-party USB-C cable, it must be rated to carry data.

Using the Keyboard

After connecting your device, select your operating system and learn to use your keyboard functions.

Selecting the Operating System

Press **Fn + Windows/Android/iOS** to select your device's operating system. The operating system indicator blinks white three times when the operating system is switched.

Because iOS, Windows, and Android are different operating systems, the definitions given by various brands of tablets and mobile phones may vary. Some functions may be unavailable. See "Identifying Supported Multimedia Keys" on page 10 to determine which functions are available for your operating system.



Using the Multimedia Controls

- Press **Fn** + any function key (F1 through F12). See "Parts Overview" on page 5 for key descriptions.
- When the  function lock is turned on, you can use multimedia controls without pressing the Fn key. Press the  function lock key to turn the function lock on/off. The function lock indicator blinks red three times when the function lock is turned on or off.

Identifying Supported Multimedia Keys

The table below shows which functions are supported by each operating system. An "X" means the function is supported, and an empty cell means it is not supported.

Icon	Windows	Android	iOS	macOS
	X			
	X	X	X	X
	X	X	X	X
	X	X	X	X
	X	X	X	X
	X	X	X	X
	X	X	X	X
	X			
	X	X	X	
	X			
	X			
	X			

Waking the Keyboard

Your keyboard automatically goes to sleep if it is inactive for 30 minutes. Press any key to wake your keyboard.

Cleaning and Maintenance

- ▶ Clean your keyboard with a dry, lint-free cloth.
- ▶ Do not allow any water or other liquids to enter the interior of your keyboard.
- ▶ Never use corrosive detergents, wire brushes, abrasive scourers, metal, or sharp utensils to clean your keyboard.
- ▶ Store in a cool, dry area away from children and pets.

Troubleshooting

Problem

My keyboard does not pair with my device (nano receiver or Bluetooth).

Solutions

- ▶ Make sure that your keyboard has enough battery life. The battery indicator light blinks red when the battery is low. See "Charging the Keyboard" on page 7.
- ▶ Make sure that the power on/off switch is **ON**.
- ▶ Move your keyboard closer to your device.
- ▶ If connecting with the nano receiver, remove and reinsert the nano receiver.
- ▶ Press and hold **Fn** + **⌘**₁ (Bluetooth device 1)/**⌘**₂ (Bluetooth device 2) to reinitiate pairing mode.
- ▶ Make sure that your keyboard is compatible with your device. See "Compatibility" on page 5.

Problem

My keyboard does not work with a wired USB-C connection.

Solutions

- ▶ Connect your keyboard using the included USB-C cable. If you use a third-party cable, make sure that it supports data transfer.
- ▶ Make sure that your keyboard's power switch is turned **OFF**. The keyboard will not work in wired mode while turned on.
- ▶ Try connecting to a different USB-C port on your device.

Problem

My keyboard stops working.

Solutions

- ▶ Make sure that your keyboard has enough battery life. The battery indicator light blinks red when the battery is low. See "Charging the Keyboard" on page 7.
- ▶ Move your keyboard closer to your device.
- ▶ Your keyboard automatically goes to sleep after some time of inactivity. Press any key to wake your keyboard.
- ▶ Press **Fn + Windows/Android/iOS** to select your operating system.
- ▶ If connecting with the nano receiver, remove and reinsert the nano receiver.
- ▶ Press and hold **Fn +**  ₁ (Bluetooth device 1)/ ₂ (Bluetooth device 2) to reinitiate pairing mode.
- ▶ If the media or function keys stop working, press **Fn +**  (function lock) to turn the function lock on/off.

Specifications

[Reviewers please confirm all specs. Is anything else needed?]

Number of Keys	BOF6TMJW16: 78 keys BOF6T9JS58: 79 keys
Battery Life	At least three months (two hours per day)
Charge Time	Less than three hours
Connection	2.4GHz, Bluetooth, USB-C
Operating Range	Less than 33ft (10m)
Cable Length	5.9ft (1.8m)

Legal Notices

FCC – Supplier's Declaration of Conformity

Unique Identifier	Amazon Basics Tablet Wireless Keyboard, Portable Compatible w/ PC, MacOS, Laptop, Smartphone, Tablet BOF6TMJW16/BOF6T9JS58
Responsible Party	Amazon.com Services LLC.
U.S. Contact Information	410 Terry Ave N. Seattle, WA 98109, United States
Telephone Number	(206) 266-1000

FCC Compliance Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the two following conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more, of the following measures:

- ▶ Reorient or relocate the receiving antenna.
- ▶ Increase the separation between the equipment and the receiver.
- ▶ Connect the equipment into an outlet on a circuit different to which the receiver is connected.
- ▶ Consult the dealer or an experienced radio/TV technician for help.

Canada IC Notice

This Class B digital apparatus complies with Canadian CAN ICES (B)/NMB (B) standard.

RF Warning Statement

- ▶ Do not place the product near any heat sources such as radiators, heat registers, stoves, or other equipment (including amplifiers) that produce heat.
- ▶ Do not use the product outdoors during a thunderstorm. Doing so may result in electric shock or device malfunction.

ISED Statement

English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian CAN ICES - 3 (B)/NMB - 3(B).

French: Cet appareil contient des émetteurs/récepteurs exempts de licence qui sont conformes aux RSS exemptés de licence d'Innovation, Sciences et Développement économique Canada.

L'exploitation est soumise aux deux conditions suivantes :

(1) Cet appareil ne doit pas provoquer d'interférences.

(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

L'appareil numérique du ciem conforme canadien peut - 3 (b) / nmb - 3 (b).

This device meets the exemption from the routine evaluation limits in section 6.3 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

cet appareil est conforme à l'exemption des limites d'évaluation courante dans la section 6.3 du cnr - 102 et conformité avec rss 102 de l'exposition aux rf, les utilisateurs peuvent obtenir des données canadiennes sur l'exposition aux champs rf et la conformité.

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment.

Cet équipement est conforme aux limites d'exposition aux rayonnements du Canada établies pour un environnement non contrôlé.

RF Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences. L'appareil peut être utilisé en condition d'exposition portable sans restriction.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Feedback and Help

We would love to hear your feedback. Please consider leaving a rating and review through your purchase orders. If you need help with your product, log in to your account and navigate to the customer service / contact us page.

amazon basics

amazon.com/pbhelp

FCC ID: **2BA78HK8981US**

IC: **8340A-HK8981US**



Amazon.com Services LLC, 410 Terry Ave N. Seattle, WA 98109 USA • Amazon.com.ca ULC, 605 5th Avenue South Suite 100 Seattle Washington, United States 98104 • Amazon México, S. de R.L. de C.V., Boulevard Manuel Ávila Camacho, #261 Piso 5 Colonia Polanco I Sección, Miguel Hidalgo, Ciudad de México, C.P.11510 México RFC: ACA140623TXA (☎: 800-874-8725)

Amazon Commercial Services Pty Ltd, L 37 2-26 Park ST, Sydney NSW 2000 Australia • Amazon Commerical Services (South Africa), Wembley Square 2 - 134 Solan Street, Gardens, Cape Town, Western Cape, 8001