


SP-7275

尺寸：100*70mm，展开尺寸：70*200mm，

材质：封面/封底：128g双铜，4C+过哑胶，内页70g书纸4+4，成型方式：骑马钉

注：封面/封底：反面不印内页内容，为空白页。

封面




100mm

70mm

Quick Guide | Guia Rápida | Guida Rapida

Power	Used to power on/off the device and to lock the screen.
On / Off	• Long press the power button to power on. • Press the power to power on the phone and to access the power on/off to lock the screen.
Volume	Adjusts the ring volume, call volume, and multimedia volume.
Home	The home button passes any control action and returns to the home screen.
Recent Apps	Opens the list of recent applications. Press and hold the home button simultaneously. Press the home button to return to the home screen.
Back	Returns to the previous screen. Clicks the back button, any open program, or any menu option.
USB Port	Connects the device and transfers data with the computer, music, and other external devices.
Headset Jack	Plug headphones into the headset jack and press the headset button to use the headset.
Power Camera	A high-resolution rear camera with zoom, video, and other features.
Flash	Provides light for photos in low-light conditions. It also may be used as a flashlight.
Proximity Sensor	Prevents the screen from activating when the device is in your pocket.

INTRODUCTION
Installation of the SIM card
Warning: Please insert the SIM card into the notch of the SIM card. The SIM card and the contact pins must be inserted into the notch of the SIM card. Please insert the SIM card into the notch of the SIM card.
To insert SIM card
• Remove the SIM card tray (both lock). Insert the SIM card.
• Insert the SIM card (for additional storage capacity).



ATTENTION
• For instructions on any question pertaining to phone usage, please click on the Siragon page by clicking the Siragon website: www.siragon.com
• Please observe instructions or program instructions on use of the SIM card, for better usage of the Siragon website: www.siragon.com
• Please observe instructions or program instructions on use of the SIM card, for better usage of the Siragon website: www.siragon.com


ABOUT YOUR PHONE
Transportation Safety
Observe all transportation rules and regulations.
PLEASE DRIVE RESPONSIBLY. DO NOT TEXT & DRIVE
Required Safety
Follow transport rules and regulations and turn off your mobile phone when your medical instruments.
Required Safety
Remember to follow all airport and flight safety regulations.
Water Resistant
Your phone is not waterproof. Keep your phone away from water or liquid to avoid damage.
Emergency Calls
Makes sure your mobile phone is switched on and in a service area. On home screen, tap the phone key and dial the emergency number.
Battery Charge
For better performance and longer battery life, it is recommended that you charge the battery fully before using the mobile phone for the first time and that you totally complete two to three charge cycles.
REI Information
To check your REI, press *9068

KEY FUNCTIONS
Front Camera
Volume
Power On / Off
Proximity Sensor
Home
Recent Apps

Home
Volume
Power On / Off
Proximity Sensor
Home
Recent Apps

Power	Used to power on/off the device and to lock the screen.
On / Off	• Long press the power button to power on. • Press the power to power on the phone and to access the power on/off to lock the screen.
Volume	Adjusts the ring volume, call volume, and multimedia volume.
Home	The home button passes any control action and returns to the home screen.
Recent Apps	Opens the list of recent applications. Press and hold the home button simultaneously. Press the home button to return to the home screen.
Back	Returns to the previous screen. Clicks the back button, any open program, or any menu option.
USB Port	Connects the device and transfers data with the computer, music, and other external devices.
Headset Jack	Plug headphones into the headset jack and press the headset button to use the headset.
Power Camera	A high-resolution rear camera with zoom, video, and other features.
Flash	Provides light for photos in low-light conditions. It also may be used as a flashlight.
Proximity Sensor	Prevents the screen from activating when the device is in your pocket.

INTRODUCTION
Installation of the SIM card
Warning: Please insert the SIM card into the notch of the SIM card. The SIM card and the contact pins must be inserted into the notch of the SIM card. Please insert the SIM card into the notch of the SIM card.
To insert SIM card
• Remove the SIM card tray (both lock). Insert the SIM card.
• Insert the SIM card (for additional storage capacity).



DEVICE CONFIGURATION
When you initially power on your phone, there will be a series of steps to set up basic features.
INSERT SIM
Insert your SIM card into the phone and register to the network.
SELECT LANGUAGE
When you first power on your phone, you will be asked to select your language. In this step, you will have the option to select a language for the phone. You can select a language for the phone.
CONNECT TO WIFI
This step allows you to connect to the Internet. Wi-Fi is the fastest network that the phone can connect to. You can connect to the Internet by selecting Wi-Fi. You can connect to the Internet by selecting Wi-Fi.
CREATE A NEW ACCOUNT
This step allows you to create a new account. You can create a new account by selecting Google. You can create a new account by selecting Google.

GOOGLE SERVICES
Click to add Google services that include Backup and Restore, Location Services, Install Updates and more.
SET SECURITY
Enable your lock screen and fingerprint to unlock your phone and for authentication on certain apps.
CONNECT TO WIFI
This step allows you to connect to the Internet. Wi-Fi is the fastest network that the phone can connect to. You can connect to the Internet by selecting Wi-Fi. You can connect to the Internet by selecting Wi-Fi.
CREATE A NEW ACCOUNT
This step allows you to create a new account. You can create a new account by selecting Google. You can create a new account by selecting Google.

SOBRE SU TELÉFONO
Seguridad de Transporte
Observe todas las reglas y regulaciones de transporte.
MANEJE RESPONSABLEMENTE. NO USE MÓVILES CUANDO ESTE CONDUciendo
• No opere el teléfono mientras conduce. Manténgalo alejado de agua o líquidos para evitar daños.
Seguridad de Emergencia
Para hacer llamadas de emergencia, asegúrese de que su teléfono móvil esté encendido y en un área de servicio. En la pantalla de inicio, pulse la tecla del teléfono y marque el número de emergencia.
Seguridad de Batería
Para mejorar el rendimiento y la vida útil de la batería, se recomienda que cargue la batería completamente antes de usar el teléfono móvil por primera vez y que realice un ciclo completo de tres ciclos de carga completos.
Información de REI
Para conocer su REI, marque *9068.

FUNÇÕES
Câmera Frontal
Volume
Botão de Lig./Deslig.
Sensor de Proximidade
Home
Aplicações Recentes

SOBRE SU TELÉFONO
Seguridad de Transporte
Observe todas las reglas y regulaciones de transporte.
MANEJE RESPONSABLEMENTE. NO USE MÓVILES CUANDO ESTE CONDUciendo
• No opere el teléfono mientras conduce. Manténgalo alejado de agua o líquidos para evitar daños.
Seguridad de Emergencia
Para hacer llamadas de emergencia, asegúrese de que su teléfono móvil esté encendido y en un área de servicio. En la pantalla de inicio, pulse la tecla del teléfono y marque el número de emergencia.
Seguridad de Batería
Para mejorar el rendimiento y la vida útil de la batería, se recomienda que cargue la batería completamente antes de usar el teléfono móvil por primera vez y que realice un ciclo completo de tres ciclos de carga completos.
Información de REI
Para conocer su REI, marque *9068.

FUNÇÃO
Câmera Frontal
Volume
Botão de Lig./Deslig.
Sensor de Proximidade
Home
Aplicações Recentes

Home
Volume
Botão de Lig./Deslig.
Sensor de Proximidade
Home
Aplicações Recentes

CONFIGURACIÓN DEL DISPOSITIVO
Cuando inicialmente se enciende el teléfono, habrá una serie de pasos para configurar las funciones básicas.
INSERTAR SIM
Advertencia: Inserte la tarjeta SIM en la ranura de la tarjeta SIM. El contacto de la tarjeta SIM se debe insertar en la ranura de la tarjeta SIM. Inserte la tarjeta SIM en la ranura de la tarjeta SIM.
SELECCIONAR IDIOMA
Al encender el teléfono por primera vez, se le pedirá que seleccione un idioma. En este paso, tendrá la opción de seleccionar un idioma para el teléfono. Puede seleccionar un idioma para el teléfono.
CONECTARSE A WI-FI
Este paso permite que el dispositivo se conecte a la red de Wi-Fi. Wi-Fi es la red más rápida que puede utilizar para conectarse a Internet. Puede conectarse a Internet seleccionando Wi-Fi. Puede conectarse a Internet seleccionando Wi-Fi.
CREAR UNA CUENTA NUEVA
Este paso permite que cree una nueva cuenta. Puede crear una nueva cuenta seleccionando Google. Puede crear una nueva cuenta seleccionando Google.

PASOS PARA AUMENTAR RAM VIRTUAL
• A la Configuración de dispositivo
• A la Configuración de dispositivo
• A la Configuración de dispositivo
• A la Configuración de dispositivo

CONFIGURAÇÃO DO APARELHO
Cuando inicialmente se enciende el teléfono, habrá una serie de pasos para configurar las funciones básicas.
INSERTAR SIM
Advertencia: Inserte la tarjeta SIM en la ranura de la tarjeta SIM. El contacto de la tarjeta SIM se debe insertar en la ranura de la tarjeta SIM. Inserte la tarjeta SIM en la ranura de la tarjeta SIM.
SELECCIONAR IDIOMA
Al encender el teléfono por primera vez, se le pedirá que seleccione un idioma. En este paso, tendrá la opción de seleccionar un idioma para el teléfono. Puede seleccionar un idioma para el teléfono.
CONECTARSE A WI-FI
Este paso permite que el dispositivo se conecte a la red de Wi-Fi. Wi-Fi es la red más rápida que puede utilizar para conectarse a Internet. Puede conectarse a Internet seleccionando Wi-Fi. Puede conectarse a Internet seleccionando Wi-Fi.
CREAR UNA CUENTA NUEVA
Este paso permite que cree una nueva cuenta. Puede crear una nueva cuenta seleccionando Google. Puede crear una nueva cuenta seleccionando Google.

CONFIGURACIÓN DE SEGURIDAD
Configure la configuración de seguridad de su dispositivo para protegerlo de amenazas de seguridad.
Seguridad de Transporte
Observe todas las reglas y regulaciones de transporte.
MANEJE RESPONSABLEMENTE. NO USE MÓVILES CUANDO ESTE CONDUciendo
• No opere el teléfono mientras conduce. Manténgalo alejado de agua o líquidos para evitar daños.
Seguridad de Emergencia
Para hacer llamadas de emergencia, asegúrese de que su teléfono móvil esté encendido y en un área de servicio. En la pantalla de inicio, pulse la tecla del teléfono y marque el número de emergencia.
Seguridad de Batería
Para mejorar el rendimiento y la vida útil de la batería, se recomienda que cargue la batería completamente antes de usar el teléfono móvil por primera vez y que realice un ciclo completo de tres ciclos de carga completos.
Información de REI
Para conocer su REI, marque *9068.

À PROPOS DE VOTRE TÉLÉPHONE
Sécurité de Transport
Observe toutes les règles et réglementations de transport.
MANEJE RESPONSABLEMENT. NO USE MÓVILES CUANDO ESTE CONDUciendo
• No opere el teléfono mientras conduce. Manténgalo alejado de agua o líquidos para evitar daños.
Seguridad de Emergencia
Para hacer llamadas de emergencia, asegúrese de que su teléfono móvil esté encendido y en un área de servicio. En la pantalla de inicio, pulse la tecla del teléfono y marque el número de emergencia.
Seguridad de Batería
Para mejorar el rendimiento y la vida útil de la batería, se recomienda que cargue la batería completamente antes de usar el teléfono móvil por primera vez y que realice un ciclo completo de tres ciclos de carga completos.
Información de REI
Para conocer su REI, marque *9068.

FONCTION DES TOUCHES
Câmera Frontal
Volume
Botão de Lig./Deslig.
Sensor de Proximidade
Home
Aplicações Recentes

Apparel photo
Volume
Botão de Lig./Deslig.
Sensor de Proximidade
Home
Aplicações Recentes

INSTALLATION DE LA CARTE SIM
Attention: Veuillez insérer la carte SIM dans la fente de la carte SIM. Le contact de la carte SIM doit être inséré dans la fente de la carte SIM. Insérez la carte SIM dans la fente de la carte SIM.
Insérer la carte SIM
• Retirez la carte SIM de son emballage.
• Insérez la carte SIM dans la fente de la carte SIM.

INTRODUCTION
Insérer la carte SIM
Attention: Veuillez insérer la carte SIM dans la fente de la carte SIM. Le contact de la carte SIM doit être inséré dans la fente de la carte SIM. Insérez la carte SIM dans la fente de la carte SIM.
Insérer la carte SIM
• Retirez la carte SIM de son emballage.
• Insérez la carte SIM dans la fente de la carte SIM.

CONFIGURATION D'APPAREIL
Configure la configuration de sécurité de votre appareil pour le protéger des menaces de sécurité.
Seguridad de Transporte
Observe todas las reglas y regulaciones de transporte.
MANEJE RESPONSABLEMENTE. NO USE MÓVILES CUANDO ESTE CONDUciendo
• No opere el teléfono mientras conduce. Manténgalo alejado de agua o líquidos para evitar daños.
Seguridad de Emergencia
Para hacer llamadas de emergencia, asegúrese de que su teléfono móvil esté encendido y en un área de servicio. En la pantalla de inicio, pulse la tecla del teléfono y marque el número de emergencia.
Seguridad de Batería
Para mejorar el rendimiento y la vida útil de la batería, se recomienda que cargue la batería completamente antes de usar el teléfono móvil por primera vez y que realice un ciclo completo de tres ciclos de carga completos.
Información de REI
Para conocer su REI, marque *9068.

PROPOSITION 65 - STATE OF CALIFORNIA
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov
Federal Communication Commission Reference
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from authorized radio communication systems.
FAVORABLE LA CONFESSION
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from authorized radio communication systems.

PROPOSITION 65 - STATE OF CALIFORNIA
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov
Federal Communication Commission Reference
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from authorized radio communication systems.
FAVORABLE LA CONFESSION
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference from authorized radio communication systems.

FCC Caution
Any changes, modifications, or repairs not approved by the party responsible for compliance could void the user's authority to operate this device.
Relative Exposure Statement
This device meets the government's requirements for exposure to radio waves.
Relative Exposure Statement
This device meets the government's requirements for exposure to radio waves.

INSTALLATION DE LA CARTE SIM
Attention: Veuillez insérer la carte SIM dans la fente de la carte SIM. Le contact de la carte SIM doit être inséré dans la fente de la carte SIM. Insérez la carte SIM dans la fente de la carte SIM.
Insérer la carte SIM
• Retirez la carte SIM de son emballage.
• Insérez la carte SIM dans la fente de la carte SIM.

INSTALLATION DE LA CARTE SIM
Attention: Veuillez insérer la carte SIM dans la fente de la carte SIM. Le contact de la carte SIM doit être inséré dans la fente de la carte SIM. Insérez la carte SIM dans la fente de la carte SIM.
Insérer la carte SIM
• Retirez la carte SIM de son emballage.
• Insérez la carte SIM dans la fente de la carte SIM.

封底

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information

This device meets the government's requirements for FCC exposure limits set forth for an uncontrolled environment. This device was tested for typical bodyworn operations with the back of the Mobile phone kept 10 mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 10 mm separation distance between the user's body and the back of the Mobile phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.