



【Tips and Warnings】

In order to emphasize the important information of the user manual, special attention should be paid when seeing the label , which indicates some important warnings and reminders

【Safety Notice】

Read all instructions before installation. It is recommended that the machine be installed by a car audio professional

 This machine is suitable for the vehicle 12V power supply system (the ground wire must be grounded), please do not install the machine in the 24V vehicle, otherwise it will damage the machine.

 Do not repair the power fuse without professional guidance. Improper use of the fuse can cause damage to the machine and cause a fire.

 To avoid violating traffic rules, drivers cannot watch videos while driving and operating machines to avoid unnecessary accidents.

 For the sake of safety and to ensure the normal use of the product, Please invite professionals to install, disassemble or repair the machine to avoid machine damage and accidents.

 Please do not placing this product in a humid environment and water in case causing fire due to electric shock or other unnecessary damage.

Note: To Prevent Burning The Machine, Do Not Turn On The Power Until The Power Cord Is Properly Connected!

【Specification】

Power Voltage-----12~14.4V DC,Negative Ground

Current----- 15A


Output Power-----4X60W

【Test】

Before you install the radio into your car, please test the product as the method below first.




【Installation】




1. Separate the iron frame from the host
2. Insert the iron frame into the car radio installation window
3. Fix the iron frame to the car with a screwdriver.
4. Press the main unit into the iron frame and let the machine snap into the iron frame.

【Disassembly】



1. Insert the release keys deeply into the slots on both sides, then follow the arrows as shown on the illustration.
2. Pull the radio out.

【Power Harness Description】



– Recommend use the **connector in the package**.
If you use the connector of your original radio directly, make sure the function of **every wire** match the connector in the package, or it will cause malfunction.




– The unit will be turned on only if the **Yellow**, **Red** and **Black** wires are all connected correctly.




– Please connect the **Yellow** and Red wires opposite if the unit does not have memory function.

【Rear View Camera Wiring】

When using the rear view reversing function, the system will automatically disconnect the link with the mobile phone, such as calls and music in BT Mode, mobile phone mirroring links, etc., which are all normal




1. Monitor
2. Camera Power Source
3. Camera




【Interface Description】

(Note: The picture is for reference only, please refer to the actual product)



- | | |
|-------------------------|--------------------------|
| 1.SD card | 2.USB for charge |
| 3.IR remote receiver | 4.Home |
| 5.Mode | 6.Mic |
| 7.Power on/off/Mute/Vol | 8.Previous track |
| 9.Reset | 10.Next track |
| 11.USB | 12.Type-C USB for charge |



- | | |
|-----------------------|---------------------|
| 1.Power Cable set A/B | 2.Fuse |
| 3.External mic | 4.RCA Output-R |
| 5.RCA Output-L | 6.Video output 2 |
| 7.Video output 1 | 8.Camera Reverse in |
| 9.CVBS in | 10.Radio Antenna |
| 11.USB prot | |

TROUBLESHOOTING-1

Problem	Cause/Solution
No power	• Confirm the voltage is 12V; • Switch ignition key to "ACC" • Check the fuse • Confirm yellow, red & black wires have been connected correctly
No memory	• Reverse the yellow and red wires • The yellow and red wires are connected together
Automatic shut-down	• The blue cable is connected to the power cable of the unit. • The voltage is unstable.
USB/SD cannot be loaded	• Confirm the Disk is FAT32 format
There is noise	• The original speaker power is too small. • The speaker cable is grounded.
No sound	• Confirm the speaker cables connected correctly. • Confirm the unused speaker wires were sealed with insulating tape individually. • Only use speakers with 4 ohm impedance.

TROUBLESHOOTING-2

Problem	Cause/Solution
Radio signal is weak/ search the station automatically by itself	• Confirm the radio area is correct for your country(setting-Tuner region) • adujst the radio broadcast to "LOC" • Turn off AF/TA (RDS) function
Reversing camera does not display	• Pink color wire connect in wrong way.make sure you use the connector in package & connect the pink wire correctly.
screen move by itself/ cannot touch the screen	• Remove the screen protector • Calibration screen(Setup----Basic setup----Calibration screen)
cannot connected BT /disconnected randomly	• Restore Factory Mode & try to connect BT name "Carplay-BT" • Unplug and re-plug again.
show "invalid" when click the BT/mirror icon	• The radio is connectting carplay/ android auto by BT.Please disconnect the wifi to stop the carplay & click the BT icon again.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.