

**64mm**

**64mm**

**64mm**

**64mm**

**90mm**

# WIRELESS PET SPEAKER

**iHip® Bluetooth®**

**INSTRUCTION MANUAL**

PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE.

**FC BC**

## Getting Started

### Package Contents

- Wireless Pet Speaker
- USB Charging Cable
- Instruction Manual
- Black Lanyard

### Key Features

- Small size with rich, clear and quality sound
- Connect & stream wireless music anytime, anywhere
- Built-in mic for hands free calls
- Built-in rechargeable battery
- USB recharge cable included

### SAFETY INSTRUCTIONS

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

### Description of Parts

|   |                                           |
|---|-------------------------------------------|
| 1 | Speaker                                   |
| 2 | LED indicator                             |
| 3 | Built-in mic                              |
| 4 | MF (Power On/Off/Play/Pause/Phone) button |
| 5 | Charging port                             |

### Instructions for Use

#### Charging Instructions

- The Bluetooth Speaker comes with a built-in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied USB Cord to charge the Bluetooth Speaker. Please charge for 1-2 hours.

#### Turning on/off the device

Press and hold the MF button for 2-3 seconds to turn on/off the device

#### Pairing your device with the Speaker –

Your Bluetooth Speaker can stream wireless audio from any Bluetooth enabled device within the range of 27-33 Feet. Simply follow the below steps.

- Turn ON the speaker. You would hear an indication tone, and Blue LED light will flash rapidly, indicating that you are now in Bluetooth Pairing Mode.
- Activate the Bluetooth function on your source device (Mobile Phone or Tablet). Please refer to manufacturer's instructions for instructions on enabling Bluetooth on your device.
- Search for available Bluetooth devices and you would find "iHip - Pet Speaker" – Pair it with this device.
- If required, enter the password "0000" to pair with the device.
- Once paired successfully, you will hear another indication tone, and Blue LED will stay on.
- You can now stream wireless music on your speaker through your source device.

#### Listening to Music Wirelessly

Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker to stream music wirelessly. Once it is paired, play music from your device.

**Tip!**  
When the speaker is not in use, turn it OFF in order to save the battery power.

| Function | Operation     | Button                                               |
|----------|---------------|------------------------------------------------------|
| Pause    | Playing music | Short press the MF button once will pause the music  |
| Play     | Pausing       | Short press the MF button once will resume the music |

(Note: Besides play/pause, you will need to control through your source device for volume increase/decrease and next/previous track.)

Double press MF button to redial the last call in the phone record.

Basic operation

| Function      | Operation     | Button                                                    |
|---------------|---------------|-----------------------------------------------------------|
| Answer a call | Incoming Call | Short press the MF button once to answer an incoming call |
| End a call    | Incoming Call | After your phone conversation, short press the MF button. |

**Please Note**

- Not all mobile phones support all the functions listed above. Please refer to your cell phone's user's manual for further information.
- Certain functions and indication tone maybe vary depending on your mobile phone.

**Using the Wireless Shutter Remote**

- Please ensure that your device (iPhone, Tablet or Other Smart Phone) is paired with the Bluetooth Speaker.
- Adjust your device to camera mode and then press the MF button once each time to take photo.

**Specifications –**

Bluetooth® Version: 5.0  
 Wireless Streaming Range Distance: 27-33 Feet  
 Speaker output: 3W  
 Size: 1.8"L x 1.8"D x 2.03"H (Cat Shape)  
       1.8"L x 1.8"D x 2.03"H (Dog Shape)  
       1.8"L x 1.8"D x 2.03"H (Panda Shape)

Weight: 1.38 Oz approx.  
 Power Input: DC 5V  
 Charging Time: about 1-2 hours  
 Play time: 1-2 hours  
 Built-In Rechargeable Battery: 3.7V /350mAh  
 (Note: Battery life & charging time may vary based on usage, types of devices connected & wireless distance.)

**Troubleshooting**

| Problem                 | Possible Cause                                                                                                                     | Solution                                                                                            |
|-------------------------|------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------|
| <b>Low sound level</b>  | Source (Tablet, Mobile Phone, Laptop, etc.) volume too low.                                                                        | Adjust source volume.                                                                               |
| <b>No sound at all.</b> | Source (Tablet, Mobile Phone, Laptop.) turned off.<br>Speaker turned off.<br>Volume turned down source.<br>Media paused on source. | Turn the source on.<br><br>Turn the speaker on.<br>Adjust volume source.<br>Play media from source. |

**Care and maintenance**

Read the following recommendations before using the Bluetooth Speaker.

Following these you will be able to enjoy the product for many years.

- Do not expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Don't use abrasive cleaning solvents to clean the unit.
- Do not expose the unit to extremely high or low temperature as this will shorten the life of electronic devices, destroy the battery or distort certain plastic parts.
- Don't dispose of the unit in fire as it will result in an explosion.

- Don't expose the unit to contact with sharp objects as this will cause scratches and damage.
- Don't let the unit fall down onto the floor. The internal circuit might get damaged.
- Don't attempt to disassemble the unit as it may get damaged if you are not professional.

**FCC Instructions**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

© 2023 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.



Limited One Year Warranty.

**DON'T BE SHY**  
**FOLLOW & TAG US**  
**ON SOCIAL MEDIA :**

 iHIP: PORTABLE ENTERTAINMENT

 #ihip #ihipusa

 iHIP.COM

📍 525 7th Ave, New York, New York 10018

背面