










NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-50-H-DFT-QPSK-
Edge_1RB_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-O
uter_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-L-DFT-QPSK-E
dge_1RB_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-60-H-DFT-QPSK-
Edge_1RB_Right-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-70-L-DFT-QPSK-O
uter_Full-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-70-L-DFT-QPSK-E
dge_1RB_Left-Ant1-PASS




NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-O
Outer_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-70-H-DFT-QPSK-E
Edge_1RB_Right-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-O
uter_Full-Ant1-PASS



NTNV-N78-3450-3550-PC2-30-80-L-DFT-QPSK-E
dge_1RB_Left-Ant1-PASS