





Freq. Stability 40C 120V n20 5200MHz Ant1




Freq. Stability 50C 120V n20 5200MHz Ant1







Freq. Stability 20C 102V n20 5240MHz Ant1




Freq. Stability 20C 120V n20 5240MHz Ant1








Freq. Stability -10C 120V n20 5240MHz Ant1




Freq. Stability 0C 120V n20 5240MHz Ant1






Freq. Stability 10C 120V n20 5240MHz Ant1




Freq. Stability 30C 120V n20 5240MHz Ant1






Freq. Stability 40C 120V n20 5240MHz Ant1




Freq. Stability 50C 120V n20 5240MHz Ant1






Freq. Stability 20C 102V n40 5190MHz Ant1




Freq. Stability 20C 120V n40 5190MHz Ant1






Freq. Stability 20C 138V n40 5190MHz Ant1




Freq. Stability -20C 120V n40 5190MHz Ant1






Freq. Stability -10C 120V n40 5190MHz Ant1




Freq. Stability 0C 120V n40 5190MHz Ant1






Freq. Stability 10C 120V n40 5190MHz Ant1




Freq. Stability 30C 120V n40 5190MHz Ant1






Freq. Stability 40C 120V n40 5190MHz Ant1




Freq. Stability 50C 120V n40 5190MHz Ant1






Freq. Stability 20C 102V n40 5230MHz Ant1




Freq. Stability 20C 120V n40 5230MHz Ant1






Freq. Stability 20C 138V n40 5230MHz Ant1




Freq. Stability -20C 120V n40 5230MHz Ant1






Freq. Stability -10C 120V n40 5230MHz Ant1




Freq. Stability 0C 120V n40 5230MHz Ant1







Freq. Stability 10C 120V n40 5230MHz Ant1




Freq. Stability 30C 120V n40 5230MHz Ant1








Freq. Stability 20C 102V ac20 5180MHz Ant1




Freq. Stability 20C 120V ac20 5180MHz Ant1







Freq. Stability 20C 138V ac20 5180MHz Ant1




Freq. Stability -20C 120V ac20 5180MHz Ant1








Freq. Stability 10C 120V ac20 5180MHz Ant1




Freq. Stability 30C 120V ac20 5180MHz Ant1






Freq. Stability 40C 120V ac20 5180MHz Ant1




Freq. Stability 50C 120V ac20 5180MHz Ant1






Freq. Stability 20C 102V ac20 5200MHz Ant1




Freq. Stability 20C 120V ac20 5200MHz Ant1






Freq. Stability 20C 138V ac20 5200MHz Ant1




Freq. Stability -20C 120V ac20 5200MHz Ant1






Freq. Stability -10C 120V ac20 5200MHz Ant1




Freq. Stability 0C 120V ac20 5200MHz Ant1






Freq. Stability 10C 120V ac20 5200MHz Ant1




Freq. Stability 30C 120V ac20 5200MHz Ant1






Freq. Stability 40C 120V ac20 5200MHz Ant1




Freq. Stability 50C 120V ac20 5200MHz Ant1






Freq. Stability 20C 102V ac20 5240MHz Ant1




Freq. Stability 20C 120V ac20 5240MHz Ant1







Freq. Stability 20C 138V ac20 5240MHz Ant1




Freq. Stability -20C 120V ac20 5240MHz Ant1








Freq. Stability 10C 120V ac20 5240MHz Ant1




Freq. Stability 30C 120V ac20 5240MHz Ant1






Freq. Stability 40C 120V ac20 5240MHz Ant1




Freq. Stability 50C 120V ac20 5240MHz Ant1






Freq. Stability 20C 102V ac40 5190MHz Ant1




Freq. Stability 20C 120V ac40 5190MHz Ant1






Freq. Stability 20C 138V ac40 5190MHz Ant1




Freq. Stability -20C 120V ac40 5190MHz Ant1





Freq. Stability -10C 120V ac40 5190MHz Ant1



Freq. Stability 0C 120V ac40 5190MHz Ant1

