

[illegible]

QS-30 clip-on Bluetooth headset an instruction manual

Packing list

Product structure

Tips

- Except for the operation methods specifically marked in the manual, please do not try to disassemble or replace any parts in the earbuds.
- Don't put the earbuds in the water or any others liquid. The earbuds are not waterproof.
- If any liquid enters the product by accident, please disconnect and remove the connection immediately.
- Please make sure that there is no water on your hands when installing or uninstalling the product to avoid electroshock.
- Do not put the product near by the heat source or expose it to the fire source directly.
- Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product parameter

Headset parameters:
Bluetooth version: V5.3
Transmission distance: ≥10 M
Music time: About 4 hours
Standby time: About 40 hours
Charging time: About 1 hours
Battery capacity: 30mAh/3.7V
Horn size: 10mm
Rated input: 5V 30mA

Charging box parameters:
Battery capacity: 250mAh/3.7V
Charging time: About 1 hours
Rated input: 5V 250mA
(All technical information is subject to actual performance)

Product Operation Instructions

① Power on
Long press the function button for 3 seconds to power on (Voice prompt: "beep")

② Shutdown
Long press the function button for 6 seconds to power off (Voice prompt: "beep beep")

③ Bluetooth pairing
Step 1: After turning on and off, set to automatically enter the pairing state of left and right unilateral earphones, and the left and right ears will be automatically connected. After successful connection, the main ear will enter the pairing state, and the secondary ear will enter the online state. Device name: QS-30; (Voice prompt: "beep")

Step 2: Open the Bluetooth list of smart devices, search for "QS-30" and connect

Usage method

- Press one hand over your ear and clip it like an earring.
- First clip it above the ear and move it up and down to the best listening position.
- Pay attention to the small beads in the front, the big beads in the back, please do not mistake before and after.

Function key operation

■ General mode

- Play/Pause: Press any headset button
- Last song: Press the right ear button twice
- Next: Press the left ear button twice
- Volume plus: Long press the right ear button for 1 second
- Volume reduction: Long press the left ear button for 1 second

■ Call mode

- Answer an incoming call: Press any headset button
- To end a call: Press any headset button
- Reject calls: Long press any headset button for 2 seconds

■ Voice Assistant/Mode switch

- Mode switch: 3 Click the right ear button to switch the music/game mode (Prompt tone: "beep/beep")
- Voice assistant: Press the left ear button three times (Prompt tone: "beep")

Clear pairing

4 Press the headset button to clear the pairing. To clear pairing, you clear the pairing connection on the headset.

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances				
	Pb	Hg	Cd	Cr(VI)	PBB
Printed circuit assembly	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
① Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.
② Indicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.

The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components:
Including printed circuit boards and their parts, electronic components, etc. and depending on the product model, the earbuds you purchased may not contain all the above components.

Electronic and electrical products sold in the People's Republic of China must mark this LOGO, the number in the logo represents the product under normal use Environmental protection use period.

Warranty statement

Disclaimer
This user manual does not have any form of guarantee, position expression or other implication. The mentioned products, specifications and information are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged can be repaired. Free repair/free replacement if the manufacturer confirms that it cannot be repaired; repaired or replaced product. Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchased by sale the ticket date shall prevail if the purchase date cannot be determined, the warranty period shall be 15 (15) months.

If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of the three packs;
2. Altering the warranty card and product code does not match the product body;
3. Causes caused by misuse, abuse or improper transportation, use, maintenance or storage obstacles or damage;
4. Failure or damage caused by force majeure (such as earthquake, war, disaster, etc.) or accident back;
5. The zipper and tower buckle are damaged due to excessive force;
6. Disconnection or tearing caused by excessive load;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law.

Service supervision hotline: 400-885-8808

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

FCC ID: 2BAQF-QSD0001

QS-30 clip-on Bluetooth headset an instruction manual