

[illegible]

1  Charge L Left  Before use, please charge the headphones for 2 hours.	2  Bluetooth pairing L Left  1.  =  =  ...  ...  :02" For the first time use, after turning on the headphones, the headphones light flashes alternately in white and blue, entering Bluetooth pairing 2.   Bluetooth name "Philips TAH1020", click to connect	3  Incoming call L Left   =  x1 Click once to answer the call  =  x1 Long press for 1 second to hang up/reject the call	5  Music track switching/volume - L Left   =  x1 Long press for 1 second to switch to the previous track  =  x1 Click once to turn down the volume	6  Music track switching/volume + L Left   =  x1 Long press for 1 second to switch to the next track  =  x1 Click once to increase the volume	7  Voice assistant wake-up L Left   =  x2 Double click to wake up the voice assistant  =  x1 Click to close the voice assistant	9  Restore factory setting L Left   =  x2  :04" Long press for 4 seconds, the headphones will re-enter Bluetooth pairing mode
---	---	--	---	--	--	--