


TRANSFORMERS



TF-T23 Pro真无线蓝牙耳机 使用说明书

包装清单



产品示意图



温馨提示

1. 请仔细阅读有特殊标示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
2. 除将产品放入充电盒内进行充电外，请勿将产品放入水中。
3. 如果有任何液体不小心进入产品内部，请立即断开连接并移除产品。
4. 为避免触电，请在安装或拆卸产品时，确保手没有沾水。
5. 请勿将本产品放置于受潮或靠近热源在火源附近。
6. 请勿将本产品放置在有强大电力的环境中，否则会导致产品故障。

产品规格

蓝牙版本: V4.0
传输距离: ≈ 10 米
扬声器直径: $\Phi 13$ mm
扬声器阻抗: 16 Ω
充电满电时间: ≈ 5 小时
电池容量: 25mAh / 3.7V

充电仓规格

电池容量: 280mAh/3.7V
充电仓容量: 约1.54Ah
额定输入: 5V-280mA
(所有技术参数均以实际性能为准)

给充电仓充电用
Type-C充电线连接充电仓到5V电源适配器。

温馨提示: 耳机电池电量低于3.4V开始播报低电量提醒。
(声音提示: "battery low", 每1分钟播报一次, 请及时给耳机充电。)



LED指示灯状态

开机	红灯交替闪烁
关机	灯灭
插入设备配对状态	主耳红灯交替闪烁,副耳熄灭
连接失败	红灯长亮1秒熄灭
耳机充电	红灯长亮
耳机充满电	红灯熄灭

充电仓指示 (只供参考, 以实物为准)

充电仓主耳充电	充电仓灯指示耳灯亮
充电仓副耳充电	灯灭亮
充电仓充电中	充电仓灯指示耳灯亮
充电仓充满电	灯熄灭亮1秒(10秒后熄灭)
充电仓低电量	耳灯长亮1秒, 充电仓灯指示耳灯亮1秒熄灭
充电仓低电量	充电仓灯亮15%, 灯灭亮

产品操作说明

- ① 开机
方法一: 向上滑动充电仓打开, 耳机自动开机;
方法二: 长按左右耳机触摸区域3秒, 耳机开机(开机提示音: "power on")。
- ② 关机
方法一: 放回充电仓, 仓上盖合上, 耳机自动关机;
方法二: 长按左右耳机触摸区域3秒, 耳机关机(关机提示音: "power off")。
- ③ 配对
步骤一: 开机后, 左右耳机自动连接进入与手机配对状态(提示音: "配");
步骤二: 打开手机蓝牙搜索附近设备, 搜索"TF-T23 Pro"并连接。
温馨提示: 左右耳机连接不配对时, 请恢复出厂设置, 放回充电仓并打开自动配对。



触摸操作

- 音量控制
音量减: 单击左耳机触摸区(最小提示音"铃铃")
音量加: 单击右耳机触摸区(最大提示音"铃铃")
- 音乐控制
播放/暂停: 双击触摸键
上一曲: 三击左耳机触摸键
下一曲: 三击右耳机触摸键
- 通话模式
接听/结束来电: 双击左/右耳机触摸键
- 游戏/音乐模式
长按左耳机触摸键2秒释放, 启动"游戏/音乐模式"
长按右耳机触摸键2秒释放, 启动"游戏/音乐模式"
(提示音"game mode"/"music mode")

恢复出厂设置

开机未连接状态: 连续左/右耳机5次, 红灯长亮1秒熄灭, 清除配对信息左/右耳机。

产品中有毒物质的名称及含量

部件名称	铅 Pb	汞 Hg	镉 Cd	六价铬 Cr(VI)	多溴联苯 PBB	多溴二苯醚 PBDE
印刷电路板材料	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表依据SJ/T 11364的规定编制。
○ 表示有害物质在该材料所有含量均符合GB/T 26572规定的限量要求以下。
+ 表示有害物质至少在该部件的某一材料中的含量超出GB/T 26572规定的限量要求。
注:
1. 表中标识"○"的部件, 其制造技术或工艺水平限制无法实现有害物质替代。
2. 印刷电路板材料, 包括印刷电路板及其零件, 电子元器件等。
3. 根据产品型号不同, 您购买的产品可能不会含有以上所有材料。



保修声明

免责声明:
本使用手册没有以任何形式的担保, 立场表达或类似建议, 本使用手册所建的产品, 规格及信息仅供参考, 内容会随时更新于网页, 恕不另行通知。

保修声明:
基本文件附带的产品如下规定: 如产品在购买之日起十二(12)个月("保修期")内, 在正常使用情况下出现质量问题, 经修理、免费维修、经厂家确认无法修理、免费更换、修理或更换后的产品, 在保修期内(自购买之日起不少于30天)内维修享有保修, 购买日以销售发票日期为准, 如无法确定购买日, 则保修期自产品生产日期起按十二(12)个月计算。
如申请保修, 请致电电子产品服务热线, 并按我们指示的方式执行, 申请保修时, 您需提供准确、完整和清晰有效的有效信息。
以上保证不适用于下列情况:
1. 超过三包有效期限;
2. 非保修期内; 产品损坏与产品本身无关;
3. 因使用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
4. 因不可抗力(如地震、战争、火灾等)或意外事故导致的故障或损坏;
5. 因碰撞、震动或压力过大所致;
6. 因液体或液体造成的损坏或腐蚀;
7. 任何因不当使用造成的损坏;
8. 有损坏或液体迹象的产品;
9. 因擅自修改导致的损坏;
10. 产品正常使用过程中出现的老化、磨损、变形、破裂和其他故障;
11. 如产品有损坏或液体迹象或更改数据, 本保修将失效。
产品及随附材料的所有权和所有权不属于本保证范围, 您在接收产品时当场检验并不得以任何形式提出异议。

以上保证是我们产品提供的全部保证, 且仅在中国大陆地区内适用, 本文件的任何内容均不影响根据法律能提出排除或限制消费者权利。

服务热线: 400-885-8808

保修卡


尊敬的用户: 本保修卡是您将来申请保修的凭证, 请您配合销售商填写并妥善保管!

用户信息	
用户姓名	电子邮箱
联系电话	邮政编码
通讯地址	
产品型号	
产品型号/编号/批号	
销售商信息	
名称	名称
地址	地址
联系电话	邮政编码
销售日期	发票号码
备注	

合格证

产品编号:
生产日期:
检验员:

TRANSFORMERS



TF-T23 Pro True Wireless Bluetooth Headset User Manual

Packing list



Product Schematic



Tips

1. Except for the operation methods specifically marked in the manual, do not try to disassemble or replace any parts in the product.
2. Do not put the product in the water or any other liquid, the product is not waterproof.
3. If any liquid accidentally enters the product, please disconnect and remove the product immediately.
4. To avoid electric shock, please make sure there is no water on your hands when installing or uninstalling the product.
5. Do not put the product near a heat source or directly expose it to a fire source.
6. Do not put the product in an environment with strong electromagnetic force, otherwise it will cause product malfunction.

Product Specification


Bluetooth version: V4.0
Transmission distance: ≈ 10 metres
Speaker diameter: $\Phi 13$ mm
Speaker impedance: 16 Ω
Music playback time: ≈ 5 hours
Battery capacity: 25mAh / 3.7V

Charging compartment specifications

Battery capacity: 280mAh/3.7V
Charging time: about 1.5 hours
Rated input: 5V-280mA
(All technical information subject to actual performance)

For charging the charging compartment
Type-C charging cable connects the charging compartment to the 5V power adapter.

Warm reminder: headset battery power below 3.4V start broadcasting low battery reminder.
(Sound alert: "battery low", every 1 minute to remind, please charge the headset in time)



LED status indication

Switch on	Alternating red and blue light
Switch off	Light off
Paring Status	Primary ear: Alternating red and blue light Secondary ear: Off
Connection Lost	Red light steady for 1 second, then off
Headset charging	Red light steady
Headset fully charged	Red light off

Charging compartment indication (the reference only, subject to the real thing)

Charging case (charging) earbuds	Charging case multicoloured indicator illuminates
Charging case fully charged	Red light remains steady
Charging case fully charged	Multicoloured indicator extinguishes
Charging case low battery	Earbuds red light flashes, charging case multicoloured indicator flashes red, charging case battery $\approx 15\%$, while light flashes

Product Operating Instructions

- (1) Powering On
Method One: Slide the charging case upwards to open, earbuds power on automatically.
Method Two: Press and hold the touch area on either earbud for 3 seconds; earbuds power on (power-on prompt: "power on").
- (2) Powering Off
Method One: Return earbuds to the charging case and close the lid; earbuds power off automatically.
Method Two: Earbuds power off automatically if no device is connected within 3 minutes (power-off prompt: "power off").
- (3) Pairing
Step 1: After powering on, the left and right earbuds will automatically connect to each other and enter pairing mode with your mobile device.
Step 2: Open the Bluetooth settings on your smart device, search for "TF-T23 Pro" and connect.
Friendly reminder: Should the earbuds fail to pair, please restore factory settings, return them to the charging case, and open to initiate automatic pairing.



触摸操作

- Conventional mode
Volume down: click the left headset touch key (minimum "knock")
Volume Up: Click the right headset touch key (maximum beep "knock knock")
- Music control
Play/Pause: Double-click touch key
Previous track: Triple-click left headset touch key
Next Song: Triple-click right headset touch key
- Talk mode
Answer/hang up call: Double press the left/right headset touch key
Reject call: Long press the left/right headset touch key for 2 seconds
- Game/Music Mode
Press and hold the left headset touch key for 2 seconds to activate/deactivate the voice assistant.
Press and hold the right headset touch key for 2 seconds to switch between game/music mode.

Restore Factory Settings

Power on unconnected state after 5 times of continuous clicking on the left/right headset, the red light will be on for 1 second and off, clearing the pairing information and turning off the left/right headset.

The name and content of harmful substances in the product

Part name	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit components	○	○	○	○	○	○
Small structural parts (such as shell)	○	○	○	○	○	○

This form is compiled in accordance with the provisions of SJ/T 11364.
① Indicates that the content of the hazardous substances in all homogeneous materials of the part is below the limit requirements specified in GB/T 26572.
② Indicates that the content of the hazardous substances in at least one homogeneous material of the part exceeds the limit requirements specified in GB/T 26572.
Note: 1. The parts marked with "+" on the table are unable to achieve the requirement of harmful substances due to limitations in global technological development.
2. Printed circuit board components including printed circuit boards and their parts, electronic components, etc.
3. Depending on the product model, the product you purchased may not contain all of the above components.



Warranty statement

Disclaimer:
This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only, and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows: If the product is within (12) months from the date of purchase ("Warranty Period"), under normal conditions of use, if the product is found to be defective, we will provide free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shorter not less than 30 days). The date of purchase is subject to the date of the sales invoice. If the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out sales invoice.

The above guarantee does not apply to the following situations:
1. Exceeding the validity period of three months;
2. Altering the warranty card, the product code does not match the product body;
3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
5. Zipper and lower buckle are damaged due to excessive force;
6. Damage caused by burning, caused by excessive heat;
7. Any damage caused by sharp objects;
8. Products with signs of burning or flooding;
9. Damage caused by unauthorized disassembly;
10. If the original identification label of the product is changed or damaged, this guarantee will become invalid.
The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should inspect the product on the spot when you receive it and raise objections to any discrepancies.
The above guarantees are all guarantees we make regarding the products, and are only applicable in China Mainland. Nothing in this document affects the consumer rights that cannot be excluded or restricted by law.

Service supervision hotline: 400-885-8808

Warranty Service

Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!

User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sale date	Invoice number
Remark	

Certificate of conformity

Product No:
Production Time:
QC:

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.