


TF-T61 说明书 成品尺寸：73X93mm 60g书写纸 双面印刷 胶装

中文

TRANSFORMERS



TF-T61耳挂式蓝牙耳机
使用说明书

包装清单			
	充电仓X1		耳机X2
	说明书&保修卡 X1		Type-C充电线 X1



- 温馨提示**
- 除说明书有特殊提示的操作方式以外，请勿尝试拆卸或更换产品内的任何零件。
 - 请勿将产品放入水或其他液体中，此产品非防水设计。
 - 如果有任何液体不小心进入产品内时，请立即断开连接并移开此产品。
 - 为避免触电，请在安装或拆卸产品时，确保手上没有沾水。
 - 请勿将此产品放置于热源附近或直接暴露于火源附近。
 - 请勿将本产品放置在有强大电磁力的环境中，否则会导致产品故障。


产品规格	
蓝牙版本：V5.4	红蓝灯交替闪烁
传输距离：≥10米	红灯长亮1秒熄灭
音乐时间：约8小时	红蓝灯交替闪烁
喇叭尺寸：Φ14.2mm	主耳红灯灯交替闪烁，副耳熄灭
喇叭阻抗：32Ω	主耳红灯灯交替闪烁，副耳熄灭
充电时间：约1.5小时	耳机充电提醒
电池容量：90mAh/3.7V	耳机红灯长亮
额定输入：5V=300mA	耳机红灯熄灭
	耳机充满电
	耳机红灯熄灭
	清除配对
	红灯长亮1秒熄灭

充电仓规格	
电池容量：300mAh/3.7V	耳机充电提醒
充电时间：约1.5小时	耳机红灯长亮
额定输入：5V=300mA	耳机红灯熄灭
	耳机充满电
	耳机红灯熄灭
	清除配对
	红灯长亮1秒熄灭



LED指示状态	
开机	红蓝灯交替闪烁
关机	红灯长亮1秒熄灭
TWS配对状态	红蓝灯交替闪烁
进入设备配对状态	主耳红灯灯交替闪烁，副耳熄灭
断开连接	主耳红灯灯交替闪烁，副耳熄灭
耳机充电提醒	耳机红灯长亮
耳机充电	耳机红灯长亮
耳机充满电	耳机红灯熄灭
清除配对	红灯长亮1秒熄灭

充电仓指示说明(只做参考，以实物为准)	
充电仓充电状态	耳机充电提醒
充电仓充满电充电状态	耳机红灯长亮
充电仓充电耳机充满电状态	耳机红灯熄灭
给耳机充电，充电仓状态	耳机红灯长亮
耳机充满电充电仓状态	耳机红灯熄灭
充电仓低电状态	耳机红灯长亮




触摸操作	
■ 常规模式	音量减：单击左耳机触摸键(最小提示音“咚”)
■ 音乐播放模式	播放/暂停：双击触摸键
■ 通话模式	上一曲：三击左耳机触摸键
■ 游戏/音乐模式	下一曲：三击右耳机触摸键

恢复出厂设置	
方法①开机未连接状态，点击左/右耳机5次后左/右耳机关机(清除配对和连接的所有设备)；	长按左/右耳机触摸键2秒
方法②开机连接状态，左/右耳机长按5秒，3秒内长按10秒，清除耳机与蓝牙设备之间的配对信息后关机(提示音“power off”)；	长按左/右耳机触摸键2秒切换游戏/音乐模式(提示音“game mode”/“music mode”)


产品中有毒物质的名称及含量	
部件名称	有害物质
印刷电路板组件	Pb, Hg, Cd, Cr(VI), PBB, PBDE
外壳等小结构件	Pb, Hg, Cd, Cr(VI), PBB, PBDE

保修声明	
免责声明	本使用手册没有任何形式的担保、立场表达或其他提示。本使用手册所提到的产品、规格及信息仅供参考，内容亦会随时更新于网页，恕不另行通知。
保修声明	就本文件附带的产品做如下保证：如产品在您购买之日起十二(12)个月(“保修期”)内，在正常使用情况下因质量问题而发生损坏，能够修理、免费修理、经厂家确认无法修理的，免费更换、修理或更换后的产品，在剩余保修期(最短不少于30天)内继续享有保修。购买日以销售发票日期为准，如无销售发票日期，则以保修期自产品出厂日期起计算(13)个月计算。如申请保修，请先致电产品服务热线，并接我们指示的方式执行。申请保修时，您需要提供准确、完整和清晰填写的有效销售发票。
以上保证不适用于下列情况：	1. 超过三包有效期限的；
	2. 造成损坏、产品损坏与产品本身不符；
	3. 因使用、造成或不当使用、使用、维护或保管而导致的故障或损坏；
	4. 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏；
	5. 碰撞、挤压或受力过大而损坏；
	6. 因使用不当造成或导致的故障或损坏；
	7. 任何因尖锐物体造成的损坏；
	8. 有腐蚀性液体浸透的产品；
	9. 擅自篡改或修改的数据；
	10. 产品在正常使用过程中发生的老化、褪色、磨损、破裂和其他损坏；
	11. 如产品原有标识标签被更改或损毁，本保证将失效。



合格证	
产品名称：	TF-T61
生产日期：	2024
检验员：	QC

Warranty statement	
Disclaimer:	This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only and the content will also be updated on the web at any time without additional separate notice.
Warranty statement:	The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair, free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.
The above guarantee does not apply to the following situations:	1. Exceeding the validity period of three guarantees;
	2. Altering the warranty card, the product code does not match the product body;
	3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
	4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
	5. Damage caused by sharp objects;
	6. Disconnection or tearing caused by excessive load;
	7. Damage caused by unauthorized disassembly;
	8. Products with signs of burning or flooding;
	9. Damage caused by unauthorized disassembly;
	10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
	11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.




Warranty Service	
Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	
User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

Warranty Service	
Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	
User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	




英文

TRANSFORMERS



TF-T61 Ear mounted BT
headphones Instructions for use


Packing list			
	Charging compartment X1		Earphone X2
	Instruction manual & warranty card X1		Type-C charging cable X1



- Warm reminders**
- Do not attempt to remove or replace any parts in the product except for the operation method specifically indicated in the instruction manual.
 - Do not put the product into water or any other liquids.
 - If any liquid accidentally enters the product, immediately disconnect and remove the product.
 - To avoid electric shock, please make sure that your hands are not stained when installing or uninstalling the product.
 - Do not place this product near the heat source or directly expose it to the heat source.
 - Do not place this product in a strong electromagnetic environment, otherwise it will cause the product to fail.


Product specifications	
Version: BT-V5.4	Red and blue lights flash alternately
Transmission distance: ≥10 meters	The red light turns off for 1 second
Music time: about 8 hours	Red and blue lights flash alternately
Speaker size: Φ14.2mm	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Input impedance: 32Ω	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Charging time: about 1.5 hours	Headphones have a solid red light
Battery capacity: 90mAh/3.7V	Headphones flashing red
Rated input: 5V=90mA	Headset red light off
	Clear the pairing
	The red light turns off for 1 second

Specifications of charging compartment	
Battery capacity: 300mAh/3.7V	耳机充电提醒
Charging time: about 1.5 hours	耳机红灯长亮
Rated input: 5V=300mA	耳机红灯熄灭
	耳机充满电
	耳机红灯熄灭
	清除配对
	红灯长亮1秒熄灭




LED indicates the status	
Start	Red and blue lights flash alternately
Shut down	The red light turns off for 1 second
TWS pairing status	Red and blue lights flash alternately
Enter the device pairing state	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Disconnect	The red and blue lights in the main ear flash alternately, and the secondary ears are turned off
Low power tips for headphones	Headphones have a solid red light
Headphone charging	Headphones flashing red
The headphones are fully charged	Headset red light off
Clear the pairing	The red light turns off for 1 second

Instructions for charging silo (for reference only, subject to the physical object)	
Charging Case Fully Charged Status	The digital tube shows the current power, and the digits flash increment
Charging Case Fully Charged Headphones	The red light is on
Charging compartment fully charged headphones	The red light is out
Charge the headphones, charging case status	Digital tubes are displayed in the form of running lights to charge headphones
The charging case of the headphones is fully charged	Digital display is extinguished
Low power of charging compartment	The digital tube flashes every 0.5 seconds



Touch operation	
■ General mode	Volume reduction: Click the left headphone touch button (minimum prompt tone "dongdong")
■ Music playback mode	Volume plus: Click the right headphone touch button (maximum prompt tone "dong dong")
■ Call mode	Play/Pause: Double-click the touch key
■ Game/Music Mode	Previous song: Three-click the touch button of the left earphone
	Next song: Three-click the right headphone touch button

Restore factory settings	
Method 1: Power-on unconnected state. After 5 times of hitting the left/right headphones, turn off the left/right ear.	长按左/右耳机触摸键2秒
Method 2: Power-on connection status. Click the left/right headphones 5 times in a row, press for 10 seconds in 3 seconds, clear the pairing information between the headphones and the BT device, and then turn off (prompt "power off")	长按左/右耳机触摸键2秒切换游戏/音乐模式(提示音"game mode"/"music mode")




The name and content of harmful substances in the product	
Part name	Harmful substances
Printed circuit board components	Pb, Hg, Cd, Cr(VI), PBB, PBDE
Small structural parts such as shell	Pb, Hg, Cd, Cr(VI), PBB, PBDE

Warranty statement	
Disclaimer:	This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only and the content will also be updated on the web at any time without additional separate notice.
Warranty statement:	The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair, free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.
The above guarantee does not apply to the following situations:	1. Exceeding the validity period of three guarantees;
	2. Altering the warranty card, the product code does not match the product body;
	3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
	4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
	5. Damage caused by sharp objects;
	6. Disconnection or tearing caused by excessive load;
	7. Damage caused by unauthorized disassembly;
	8. Products with signs of burning or flooding;
	9. Damage caused by unauthorized disassembly;
	10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
	11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.



Warranty statement	
Disclaimer:	This user manual does not have any form of guarantee, position expression or other implication. The products, specifications and information mentioned in this user manual are for reference only and the content will also be updated on the web at any time without additional separate notice.
Warranty statement:	The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired, free repair, free replacement if the manufacturer confirms that it cannot be repaired, repaired or replaced product, continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). The date of purchase is subject to the date of the sales invoice, if the date of purchase cannot be determined, the warranty period shall be thirteen (13) months from the date of production. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.
The above guarantee does not apply to the following situations:	1. Exceeding the validity period of three guarantees;
	2. Altering the warranty card, the product code does not match the product body;
	3. Failure or damage caused by misuse, abuse or improper transportation, use, maintenance or storage;
	4. Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accidents;
	5. Damage caused by sharp objects;
	6. Disconnection or tearing caused by excessive load;
	7. Damage caused by unauthorized disassembly;
	8. Products with signs of burning or flooding;
	9. Damage caused by unauthorized disassembly;
	10. Aging, discoloration, abrasion, rupture and other losses that occur during the normal use of the product;
	11. If the original identification label of the product is changed or damaged, this guarantee will become invalid.

Warranty Service	
Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	
User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	



Warranty Service	
Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	
User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	

Warranty Service	
Dear user, this warranty card is the proof of your future warranty application, please cooperate with the seller to fill it out and keep it for future use!	
User info	
User name	Email
Contact number	Postal code
Mailing address	
Product information	
Product name	Product number
Product barcode / Serial number / Batch number	
Vendor information	
Name	
Address	
Contact number	Postal code
Sales date	Invoice number
Remark	



TRANSFORMERS

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.