







Freq. Stability NVNT a 5180MHz Ant2




Freq. Stability NVNT a 5200MHz Ant2




Freq. Stability NVNT a 5240MHz Ant2




Freq. Stability NVNT n20 5180MHz Ant2




Freq. Stability NVNT n20 5200MHz Ant2




Freq. Stability NVNT n20 5240MHz Ant2




Freq. Stability NVNT n40 5190MHz Ant2




Freq. Stability NVNT n40 5230MHz Ant2




Freq. Stability NVNT ac20 5180MHz Ant2




Freq. Stability NVNT ac20 5200MHz Ant2




Freq. Stability NVNT ac20 5240MHz Ant2



Freq. Stability NVNT ac40 5190MHz Ant2




Freq. Stability NVNT ac40 5230MHz Ant2




Freq. Stability NVNT ac80 5210MHz Ant2

D.6 Duty Cycle


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	97.46	0.11	0.37
NVNT	a	5200	Ant1	97.83	0.1	0.37
NVNT	a	5240	Ant1	98.18	0.08	0.37
NVNT	n20	5180	Ant1	97.41	0.11	0.44
NVNT	n20	5200	Ant1	97.41	0.11	0.44
NVNT	n20	5240	Ant1	97	0.13	0.44
NVNT	n40	5190	Ant1	94.87	0.23	0.9
NVNT	n40	5230	Ant1	94.87	0.23	0.9
NVNT	ac20	5180	Ant1	97.42	0.11	0.44
NVNT	ac20	5200	Ant1	97.42	0.11	0.44
NVNT	ac20	5240	Ant1	97	0.13	0.44
NVNT	ac40	5190	Ant1	94.87	0.23	0.9
NVNT	ac40	5230	Ant1	94.92	0.23	0.89
NVNT	ac80	5210	Ant1	90	0.46	1.85




Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1




Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT n20 5180MHz Ant1




Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1




Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1




Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1




Duty Cycle NVNT ac20 5240MHz Ant1



Duty Cycle NVNT ac40 5190MHz Ant1




Duty Cycle NVNT ac40 5230MHz Ant1




Duty Cycle NVNT ac80 5210MHz Ant1


Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant2	97.83	0.1	0.37
NVNT	a	5200	Ant2	97.83	0.1	0.37
NVNT	a	5240	Ant2	97.83	0.1	0.37
NVNT	n20	5180	Ant2	97.84	0.1	0.44
NVNT	n20	5200	Ant2	97.41	0.11	0.44
NVNT	n20	5240	Ant2	97.41	0.11	0.44
NVNT	n40	5190	Ant2	94.87	0.23	0.9
NVNT	n40	5230	Ant2	94.87	0.23	0.9
NVNT	ac20	5180	Ant2	97.42	0.11	0.44
NVNT	ac20	5200	Ant2	97.42	0.11	0.44
NVNT	ac20	5240	Ant2	97.42	0.11	0.44
NVNT	ac40	5190	Ant2	94.92	0.23	0.89
NVNT	ac40	5230	Ant2	94.87	0.23	0.9
NVNT	ac80	5210	Ant2	89.83	0.47	1.89




Duty Cycle NVNT a 5180MHz Ant2




Duty Cycle NVNT a 5200MHz Ant2




Duty Cycle NVNT a 5240MHz Ant2




Duty Cycle NVNT n20 5180MHz Ant2




Duty Cycle NVNT n20 5200MHz Ant2




Duty Cycle NVNT n20 5240MHz Ant2




Duty Cycle NVNT n40 5190MHz Ant2




Duty Cycle NVNT n40 5230MHz Ant2




Duty Cycle NVNT ac20 5180MHz Ant2




Duty Cycle NVNT ac20 5200MHz Ant2




Duty Cycle NVNT ac20 5240MHz Ant2



Duty Cycle NVNT ac40 5190MHz Ant2



Duty Cycle NVNT ac40 5230MHz Ant2



Duty Cycle NVNT ac80 5210MHz Ant2