



Skapendy



Wireless Gaming Headset

VK84

VK84

Wireless Gaming Headset

English 1-10

Deutsch 11-18

Package Contents



Wireless Gaming Headset*1



User Manual*1



Charging Cable *1



2.4GHz USB Dongle*1

Product Features

- ✓ 1. Sound Quality: 50mm titanium-coated drivers for deep bass and clear highs.
Game mode ↔ Music mode
- ✓ 2. Ultra-Low Latency 2.4G Gaming: 2.4GHz USB dongle with ≤20ms delay for precise audio.
- ✓ 3. Ergonomic Excellence: Adjustable headbands and breathable ear cushions for comfort.
- ✓ 4. Voice Clarity: ENC Noise-Canceling Technology: Clear communication with teammates.
- ✓ 5. Exceptional Battery Life: 1200mAh battery Charging: 2.5 hours using a week.
- ✓ 6. Perfect Gift Idea: Ideal for Christmas and birthdays for boys, girls, family, and friends.

Before Using: Charging

1. Before using the wireless gaming headset for the first time, please charge it for at least 2 hours.
2. When the battery level falls below 10%, you will hear a "Low Battery" voice prompt.
3. It is advisable to avoid using high-power or low-quality chargers and charging cables for the headset. Please use the original charging cable included in the package to prevent damaging the headset or shortening its lifespan.
4. To maintain normal battery life, use the product at least once every two weeks and charge the headset in time after use.

Product Overview

1 M

Re-Pair(BT mode) -- Long press 3s
 Game mode↔Music mode -- Single click
 Clear BT pairing -- Long Press Volume
 up/down 6s

2

Mic On/Off -- Single click
 BT mode↔ 2.4G mode -- Long press 2s

3


Volume Up -- Single click
 Next Track -- Long press 2s

4

Volume down -- Single click
 Previous Track -- Long press 2s

5

Power On -- Long press 3s
 Power Off -- Long press 4s
 Play/Pause -- Single click
 Answer Call -- Single click
 End Call -- Single click
 Reject Call -- Long press 2s
 Call Back -- Double clicks



Warm Tips

1. Compatible with devices: PS5, PS4, PC, Mac, laptop, mobile phone, Nintendo Switch
2. Not compatible with Xbox.
3. The microphone is not available when connected to the Nintendo Switch.
4. Bluetooth mode is not compatible with PS4/PS5.
5. If the device is powered on and not paired with a device, it will automatically shut down after five minutes.
6. For your safety, refrain from using the headset while cycling or driving, and avoid listening to music at high volumes for extended periods. Handle with care to prevent any damage to the appearance or functionality. Specifications are subject to change without prior notice.


How to Use the Two Modes

Long press the mic for 2 seconds to switch to Bluetooth mode and Dongle mode.

1. Bluetooth Mode


- Delay ≤ 48ms
- Compatible with PC/Mac/Nintendo Switch/Mobile;
- Bluetooth mode employs 5.4 Bluetooth technology to establish a wireless connection with devices, allowing you the freedom to move while enjoying audio.

- ① Turn on the headset and enable Bluetooth on your device (Computer, Mobile phone, Mac, Nintendo Switch). Set it to discoverable mode and search for new devices. Find "**VK84**" in the searched device list and click to pair.
- ② Bluetooth mode Voice Prompt & LED Light:
"Bluetooth Mode" : Flashing blue light
"Bluetooth Connected" : Breathing blue light
"Bluetooth Disconnected" : Flashing blue light



2. 2.4GHz Dongle Mode

- Delay $\leq 20\text{ms}$ (Ultra Low Latency)
 - Compatible with PC/PS4/PS5; If you're using USB dongle to connect a Mac or Nintendo Switch, you'll need a USB-A to USB-C adapter (package not included).
- ① Plug the USB 2.4GHz Dongle into the device's port (PC, PS4, PS5) and turn on the headset. The LED light will be green and flash while waiting for pairing.
 - ② 2.4G Dongle Mode Voice Prompt & LED Light:
 - "Dongle Mode" : Flashing green light
 - "Dongle Connected" : Breathing green light
 - "Dongle Disconnected" : Flashing green light



Tips for setting up the device when the headphone is connected

1. PC connection settings

- Open "Control Panel" and click "All Control Panel Items."
- Right-click on "Wireless Gaming Headset" Gaming Headset and select "Set as Default Device."
- Go to the "Recording" tab, then right-click on "Wireless Gaming Headset" and select "Set as Default Device."

2. Mac connection settings

- Click on "System Preferences."
- Navigate to "Sound."
- In the "Output" tab, right-click "Wireless Gaming Headset" and select "Set as default device."
- In the "Input" tab, right-click "Wireless Gaming Headset" and select "Set as default device."

3. PS4/PS5 connection settings

- Click "Settings" on the screen.
- Go to the "Devices" tab.
- Click the "Audio Devices" tab.
- Set "Wireless Gaming Headset" as the default device for both "Input Device" and "Output Device" by right-clicking it.
- Adjust "Volume Control (Headset)" as needed.

4. Nintendo Switch connection settings

- Turn on your Nintendo Switch then plug the Nintendo Switch into the docking station and connect the monitor.
- Connect the wireless adapter to a USB port on your Nintendo docking station.
- Press the power button on the headset for 3 seconds to power on.

Specifications

Model	VK84	Working Voltage	3.3V-4.2V
Charging Method	USB C	Battery Capacity	1200mAh
Bluetooth version	Version 5.4	Battery Charging Voltage /current	4.2V/1A
Wireless/Bluetooth Range	≅ 8m/26ft		
Drive Diameter	Φ50 mm	Frequency Response Range	20Hz~20kHz
Charging time	about 2.5 hrs		
Battery life	about 50 hrs		

Warranty Policy

Skapendy products have a 12-month limited warranty from the original purchase date. If any issues arise, please contact our support team for assistance. We're here to help you resolve any problems. For more information, visit the Skapendy official website.

Website: skapendy.store

Email address: Skapendy@outlook.com

FCC CAUTION

Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

FCC COMPLIANCE

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CLASS B DEVICE NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RADIATION EXPOSURE

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC Label Location:

The FCC ID: 2BATE-VK84 for product model No. VK84 is printed on the baffle under the ear pad of headset. In accordance with FCC Rule §15.19(a)(5), since this label is not visible during normal operation, its location is explicitly stated in the user manual. The complete FCC labeling information is also provided on the product's outer packaging.



CAUTION:

RISK OF EXPLOSION IF BATTERY IS REPLACED WITH INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO INSTRUCTIONS.
THE SYMBOL INDICATES DC VOLTAGE.



RECYCLING

This product is marked with the WEEE symbol (Waste Electrical and Electronic Equipment). It must be processed according to European Directive 2012/19/EU for recycling or dismantling to minimize environmental impact.

Product Warranty

Dear customers:

Hello! To apply for after-sales service, please fill out the product warranty card according to your actual situation. Then send the completed warranty card back to the merchant where you purchased the product. Thank you!

1、 Please tick the reason for after-sales:

☐Quality ☐Style look ☐Uncomfortable

other: _____

2、 Please tick the after-sale options you need:

☐Replacement ☐Repair ☐Return

3、 Please give us your valuable comments: _____

Note: Please consult the merchant for the specific after-sales address.

Paketinhalt



Wireless Gaming Headset*1 Benutzerhandbuch*1 Ladekabel *1 2.4 GHz USB-Dongle*1

Produktmerkmale

- ✓ 1. Klangqualität: 50-mm-Treiber mit Titanbeschichtung für tiefen Bass und klare Höhen.
Game mode ↔ Music mode
- ✓ 2. Ultra-Niedrige Latenz 2.4G Gaming: 2,4-GHz-USB-Dongle mit ≤20ms Verzögerung für präzisen Ton.
- ✓ 3. Ergonomische Exzellenz: Verstellbare Kopfbänder und atmungsaktive Ohrpolster für Komfort.
- ✓ 4. Stimmklarheit: ENC-Rauschunterdrückungstechnologie: Klare Kommunikation mit Teamkollegen.
- ✓ 5. Außergewöhnliche Akkulaufzeit: 1200-mAh-Akku. Laden: 2,5 Stunden für eine Woche Nutzung.
- ✓ 6. Perfekte Geschenkidee: Ideal für Weihnachten und Geburtstage für Jungen, Mädchen, Familie und Freunde.

Vor der Verwendung: Aufladen

1. Bevor Sie das drahtlose Gaming-Headset zum ersten Mal verwenden, laden Sie es bitte mindestens 2 Stunden lang auf.
2. Wenn der Batteriestand unter 10% fällt, hören Sie einen "Low Battery" Sprachhinweis.
3. Es ist ratsam, keine Hochleistungs- oder minderwertigen Ladegeräte und Ladekabel für das Headset zu verwenden. Bitte benutzen Sie das original im Lieferumfang enthaltene Ladekabel, um Schäden am Headset oder eine Verkürzung der Lebensdauer zu vermeiden.
4. Um eine normale Batteriebensdauer aufrechtzuerhalten, verwenden Sie das Produkt mindestens einmal alle zwei Wochen und laden Sie das Headset rechtzeitig nach der Verwendung auf.

Product Overview

1 M

Erneutes Koppeln (BT-Modus) ---
 3 s lang drücken
 Spielmodus ↔ Musikmodus --- Einzelklick
 BT-Koppelung löschen ---
 6 s lang drücken Lautstärke hoch/runter

2

Mikrofon ein/aus --- Einzelklick
 BT-Modus ↔ 2.4G-Modus --- 2 s lang drücken

3


Lauter --- Einzelklick
 Nächster Titel --- 2 s lang drücken

4

Leiser --- Einzelklick
 Vorheriger Titel --- 2 s lang drücken

5

Einschalten --- 3 s lang drücken
 Ausschalten --- 4 s lang drücken
 Wiedergabe/Pause --- Einzelklick
 Anruf annehmen --- Einzelklick
 Anruf beenden --- Einzelklick
 Anruf ablehnen --- 2 s lang drücken
 Zurückruf --- Doppelklick



Wichtige Hinweise

1. Kompatibel mit Geräten: PS5, PS4, PC, Mac, Laptop, Mobiltelefon, Nintendo Switch
2. Nicht kompatibel mit Xbox.
3. Das Mikrofon ist nicht verfügbar, wenn es mit dem Nintendo Switch verbunden ist.
4. Der Bluetooth-Modus ist nicht kompatibel mit PS4/PS5.
5. Wenn das Gerät eingeschaltet ist und nicht mit einem anderen Gerät gekoppelt wird, schaltet es sich nach fünf Minuten automatisch aus.
6. Benutzen Sie das Headset aus Sicherheitsgründen nicht beim Radfahren oder Autofahren und vermeiden Sie es, über einen längeren Zeitraum hinweg Musik mit hoher Lautstärke zu hören. Gehen Sie vorsichtig damit um, um Schäden am Aussehen oder an der Funktionalität zu vermeiden. Die Spezifikationen können ohne vorherige Ankündigung geändert werden.

So verwenden Sie die beiden Modi

Halten Sie das Mikrofon 2 Sekunden lang gedrückt, um in den Bluetooth-Modus und den Dongle-Modus zu wechseln.

1. Bluetooth Mode

- Verzögerung $\leq 48\text{ms}$
- Kompatibel mit PC/Mac/Nintendo Switch/Mobilgeräten;
- Im Bluetooth-Modus verwendet es die Bluetooth-Technologie 5.4, um eine drahtlose Verbindung mit Geräten herzustellen, was Ihnen die Freiheit gibt, sich zu bewegen, während Sie Audio genießen.


① Schalten Sie den Kopfhörer ein und aktivieren Sie Bluetooth auf Ihrem Gerät (Computer, Mobiltelefon, Mac, Nintendo Switch). Setzen Sie es in den Suchmodus und suchen Sie nach neuen Geräten. Finden Sie **"VK84"** in der Liste der gefundenen Geräte und klicken Sie darauf, um eine Verbindung herzustellen.

② Bluetooth-Modus Sprachansage & LED-Licht:

"Bluetooth Mode": Blinkend blaues Licht


"Bluetooth Connected": Atmend blaues Licht

"Bluetooth Disconnected": Blinkend blaues Licht



2. 2.4GHz Dongle Mode

- Verzögerung $\leq 20\text{ms}$ (Ultra-Geringe Latenz)
 - Kompatibel mit PC/PS4/PS5; Wenn Sie einen USB-Dongle verwenden, um eine Verbindung zu einem Mac oder Nintendo Switch herzustellen, benötigen Sie einen USB-A auf USB-C Adapter (nicht im Lieferumfang enthalten).
- ① Stecken Sie den USB 2,4-GHz-Dongle in den Anschluss des Geräts (PC, PS4, PS5) und schalten Sie das Headset ein. Die LED-Anzeige wird grün und blinkt, während auf das Pairing gewartet wird.
 - ② 2,4-GHz-Dongle-Modus Sprachansage & LED-Licht:
 - "Dongle Mode": Blinkend grünes Licht
 - "Dongle Connected": Atmend grünes Licht
 - "Dongle Disconnected": Blinkend grünes Licht



Tipps zur Einrichtung des Geräts, wenn der Kopfhörer angeschlossen ist**1. PC Verbindungseinstellungen**

- Öffnen Sie die "Systemsteuerung" und wählen Sie "Alle Elemente der Systemsteuerung".
- Klicken Sie mit der rechten Maustaste auf "Wireless Gaming Headset" Gaming-Headset und wählen Sie "Als Standardgerät festlegen".
- Wechseln Sie zum Tab "Aufnahme", klicken Sie mit der rechten Maustaste auf "Wireless Gaming Headset" und wählen Sie "Als Standardgerät festlegen".

2. Mac Verbindungseinstellungen

- Klicken Sie auf "Systemeinstellungen".
- Navigieren Sie zu "Ton".
- Klicken Sie im Tab "Ausgabe" mit der rechten Maustaste auf "Wireless Gaming Headset" und wählen Sie "Als Standardgerät festlegen".
- Im Tab "Eingabe" klicken Sie mit der rechten Maustaste auf "Wireless Gaming Headset" und wählen Sie "Als Standardgerät festlegen".

3. PS4/PS5 Verbindungseinstellungen

- Klicken Sie auf dem Bildschirm auf "Einstellungen".
- Gehen Sie zum Tab "Geräte".
- Klicken Sie auf den Tab "Audiogeräte".
- Klicken Sie mit der rechten Maustaste auf "Wireless Gaming Headset" und wählen Sie "Als Standardgerät für Eingabe und Ausgabe festlegen".
- Passen Sie die "Lautstärkeregelung (Headset)" nach Bedarf an.

4. Nintendo Switch Verbindungseinstellungen

- Schalten Sie Ihre Nintendo Switch ein, verbinden Sie die Nintendo Switch mit der Dockingstation und schließen Sie den Monitor an.
- Stecken Sie den drahtlosen Adapter in einen USB-Anschluss Ihrer Nintendo-Dockingstation.
- Drücken Sie die Ein-/Aus-Taste am Headset 3 Sekunden lang, um es einzuschalten.

Technische Spezifikationen

Modell	VK84	Arbeitsspannung	3.7V-4.2V
Aufladen	USB C	Batteriekapazität	1200mAh
Bluetooth-Version	Version 5.4	Batterielade-Spannung/ Strom	4.2V/1A
Kabellose/Bluetooth-Reichweite	≅ 8m/26ft		
Treiberdurchmesser	Φ50 mm	Frequenzbereich	20Hz~20kHz
Ladezeit	ca. 2,5 Std.		
Akkulaufzeit	ca. 50 Std.		

Garantiebedingungen

Skapendy Produkte haben eine begrenzte Garantie von 12 Monaten ab dem ursprünglichen Kaufdatum. Falls Probleme auftreten sollten, kontaktieren Sie bitte unser Support-Team für Unterstützung. Wir sind hier, um Ihnen bei der Lösung jeglicher Probleme zu helfen. Für weitere Informationen besuchen Sie bitte die offizielle Website von Skapendy.

[Website:skapendy.store](https://www.skapendy.store)

[Email address:Skapendy@outlook.com](mailto:Skapendy@outlook.com)



RECYCLING

This product is marked with the WEEE symbol
(Waste Electrical and Electronic Equipment).

It must be processed according to European Directive 2012/19/EU for
recycling or dismantling to minimize environmental impact.

Produktgarantie

Liebe Kunden:

Hallo! Um unseren Kundendienst in Anspruch zu nehmen, füllen Sie bitte die Produktgarantiekarte entsprechend Ihrer tatsächlichen Situation aus. Senden Sie dann die ausgefüllte Garantiekarte an den Händler zurück, bei dem Sie das Produkt gekauft haben. Vielen Dank!

1. Bitte markieren Sie den Grund für den Kundendienst:

☐ Qualität ☐ Aussehen ☐ Unbequemlichkeit

Andere: _____

2. Bitte kreuzen Sie die benötigten Kundendienstoptionen an:

☐ Austausch ☐ Reparatur ☐ Rückgabe

3. Bitte teilen Sie uns Ihre wertvollen Kommentare mit: _____

Hinweis: Bitte erkundigen Sie sich beim Händler nach der genauen Adresse
für den Kundendienst.



Skapendy

Dongle Model No.: D4

Model No.: VK84 FCC ID: 2BATE-VK84, 2BATE-D4



RoHS

Made in China

Raccolta differenziata: verifica le disposizioni del tuo Comune.