


Car wireless charging stand

F22



Instruction Manual

1. Parameter Description

Product Name:Car wireless charging stand

Power:15W/10W/7.5W/5W

Transmission distance :1-8MM

Charging interface:TYPE-C


Packing list:

Car bracket x 1, instruction manual x 1

Data cable x 1,

hook clamp x 1(Optional selection)

2. Functional components



3. Specification parameters

1. Model: F22

2. Material: PC+ABS+glass

3. Input voltage/current: 5V/2A, 9V/1.67A

4. Output power: 15W/10W/7.5W/5W

5. Charging power: 110K-205KHz

6. Charging distance: 0-8MM

7. Support specifications: charging in accordance with Qi wireless charging protocol

8. Devices that support QC wireless fast charging, such as,

IPhone: iPhone 17 Series/16 Series/15 Series/14 Series

iPhone 13 series/12 series/iPhone XS Max,

iPhone XR, iPhone X, iPhone 8, 8x

HUAWEI: Mate60 series/50 series/40 series/30 series

/20 series P70 series/P60 series/P50 series

Samsung: S8-S20 series/Note8-Note10 series

4. instructions

1. Connect the car wireless charging device to the compatible data cable during use.

2. Connect the USB end of the data cable to the rechargeable interface on the car (e.g. cigarette lighter conversion charger and car USB charging interface)

3. The device clamp can clamp the air outlet end of the air conditioner and also prevent other places that can be clamped.

4. Install the device on the hook and clamp ball head, place the clamp arm upwards, secure the bracket, and open the horizontal screen lock button. Connect the 5-9V DC power supply, the ambient light will remain on (long press the ambient light button to turn off the ambient light, short press the ambient light button to change color), touch the arm opening button to open the arm, place the phone arm tightly, and automatically detect charging. Touch the rotation button to make the phone vertical. Touch the arm opening button, and the device will automatically rotate horizontally to open the arm and remove the phone.

5. This device has overvoltage protection, over temperature protection, magnetic field protection, and short circuit protection. If there is an abnormality in the device, it will automatically stop working.

5.Precautions

1. Do not excessively squeeze or collide with the equipment.

2. Do not use wireless chargers in severely high-temperature, humid, or corrosive environments to avoid damaging the device's circuitry.



Thank you for using this product!

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.