8.5 in w x 11 in h


11in
(279.4mm)

ROLLER RABBIT

Water Resistant Speaker



OVERVIEW



CHARGE FOR 3 HOURS BEFORE FIRST USE

INCLUDES
- Water Resistant Speaker
- USB-C Charging Cable

OPERATION INSTRUCTION

Functionality	Operation Instruction
Power On/Off (Pairing by phone/other devices if first use)	**Long press** ⏻ for 2 seconds to power on/off the speaker, search the pairing name on your device to connect. (Bluetooth® will default at startup unless a Micro SD card is inserted.) Bluetooth® Pairing Name: Club RR
Disconnect paired device	**Long press** ▷ for 2 seconds to disconnect paired device. * If TWS paired, to disconnect the speakers with your device, **Long press** ▷ on any speaker for 2 seconds.
TWS Pairing/Paired/Unpair mode (Required 2 X TTFB158 speakers)	**Powered on both of the 2 speakers, Long press** ▷ on any speaker for 2 seconds to enter into the pairing mode. It will automatically search and pair with the second speaker, a tone will be heard while the 2 speakers paired. **Long press** ▷ of any speaker for 5 seconds, 2 speakers will be disconnected from each other.
Answer Calls/End Calls **Reject the Calls** **Redial the Call** **Play/Pause**	**Short press** ▷ to Answer Calls/End Calls. (Only at Bluetooth® mode) **Long press** ▷ for 2 seconds to Reject the Calls. (Only at Bluetooth® mode) **Double press** ▷ to Redial the Call. (Only at Bluetooth® mode) **Short press** ▷ to Play/Pause.
Switch Mode (Bluetooth® Mode/Micro SD card Mode)	**When the Micro SD card (not included, up to 32GB) is inserted. Short press** ⏻ to Switch mode. SD port supports to read the MP3 and WAV files from the Micro SD card, but not support data storage/transfer by USB-C cable. Once the Micro SD card is inserted into this port, it is defaulted at startup. Music will play in a loop in Micro SD card mode.
Volume Down/Up **Previous Song/Next Song**	**Short press** ▭ / ✛ to control Volume. **Long press** ▭ / ✛ for 2 seconds to switch Previous Song/Next Song.
RGB LEDs On/Off **RGB LEDs Cycle Shifting**	**Long press** ❄ for 2 seconds to RGB LEDs on/off. **Short press** ❄ RGB LEDs Cycle Shifting. The RGB lights will turn on by default. 15 different RGB lights in cycle.

⚠ WARNING:
CHOKING HAZARD—Small parts.
Not for children under 3 years.

only at Target

© 2026 Target. The Bullseye Design is a registered trademark of Target Brands, Inc. All rights reserved.

Only at Target.com

8.5in
(215.9mm)

Front

Charging	DC 5V 1A	Recommend fully charging before first use. USB-C cable to a DC 5V/1A adapter (Not included). A full charge takes about 3 hours. A warning tone when battery power is low.

LED INDICATOR STATUS

	BLUE – Fast flashing	Paring/Disconnect device/TWS mode disconnect device (Host speaker)
	BLUE – Slow flashing	Play music
	BLUE – Solid light	Pairing successful/Pause status in Micro SD card mode/TWS mode disconnect device (Sub-speaker)

CHARGING LED STATUS

	RED – Solid light	Charging
	RED light off	Fully charged

NOTES:
1. This device can only connect to one phone/device at a time.
2. If the device is disconnected, paused or inactive (no audio input detected) for 10 minutes, it will automatically shut down.
3. After restarting in Bluetooth® mode, the device(s) will automatically reconnect to the last connected device.
4. Keep your paired device within 33 feet of the speaker for best performance.
5. When receiving a call, the ringtone plays and music pauses automatically.

SPECIFICATIONS
- Power Input: 5V ⎓ 1A
- Built-In Battery: 3.7V DC, 1200mAh
- Bluetooth® Pairing Name: Club RR
- Water Resistant: IPX5

TROUBLESHOOTING AND TIPS
- Device not responding? Long press ⏻ to restart.
- Won't turn on? Recharge the battery and try again.
- Won't charge? Make sure you're using a 5V/1A power supply and the cable isn't damaged.
- No sound? Adjust the volume on both the speaker and your device.
- Device not showing up in Bluetooth® Settings? Disconnect the speaker from other devices first, then try pairing again.
- No sound after inserting the Micro SD card? Check the song files are MP3 or WAV format, Also check the card for damage. The speaker only supports Micro SD cards up to 32GB.

NEED SOME HELP?
Can't connect? Not accepting phone calls? Just have a question?

Call us at: 1-833-TGT-Tech
Target Corp. Minneapoils. MN, 55403

SAFETY
- Do not immerse this device in water
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth

ROLLER RABBIT BC

FCC ID: 2BAXW-TFB164 Model: TTFB158 DPCI: 335-00-0360 Input: 5V ⎓ Max 1A Made in China
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
RF Exposure Information
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Back