


Hearth&Hand
WITH MAGNOLIA

Bluetooth® Speaker



Include

- Bluetooth® Speaker
- Power adapter
- HDMI Cable
- AUX Cable

Power on/off

- Toggle "POWER" switch to turn the power on/off, Red light is always on when power on, and will turn off when the device is power off.

MIC on/off

- Toggle "MIC" switch to turn the MIC on/off.

Bluetooth® Mode

- Turn Mode knob to Bluetooth® mode, the voice will be heard.
- Use Bluetooth® settings on your device to pair with "Hearth&Hand 14".
- The Bluetooth® mode turns when connected successfully, the voice will be heard.
- Turn the volume knob to adjust the volume.
- Disconnect Bluetooth® settings on your device. Bluetooth® will become unpaired if your device is outside of range (33 feet).

NOTE: Please keep the distance between the connected Bluetooth® devices less than 33 feet to ensure working properly.

AUX Mode

- Turn Mode knob to AUX mode, the voice will be heard, LED indicator will be red.
- Connect the AUX cable.
- Turn the volume knob to adjust the volume.

HDMI ARC Mode

- Turn Mode knob to HDMI mode, the voice will be heard, LED indicator will be red.
- Connect the HDMI ARC cable.
- Turn the volume knob to adjust the volume.

1

Front

Volume Use Instructions

- Turn the volume knob to adjust the volume.
- Short press the "VOLUME" knob to switch to MIC volume adjustment. If do not operate for 3 seconds, it will automatically return to speaker volume adjustment.
- Long press the "VOLUME" 5 seconds, Bluetooth® disconnect, Long press the "VOLUME" 10 seconds resetting.

EQ key Use Instructions

- Low frequency section control, push up the low Switch is increase, push down the low Switch is decrease.
- Medium frequency section control, push up the medium Switch is increase, push down the Medium Switch is decrease.
- High frequency section control, push up the high Switch is increase, push down the high Switch is decrease.

Troubleshooting and Tips

- If the device is not working correctly, try turn off the device and turn it on again.
- If the device won't charge, make sure the power supply DC 15V 2A, and not damaged
- If the device makes no sound, adjust the volume
- If the device makes no sound or doesn't show as an available device in Bluetooth® Mode, make sure it is not already connected to another device. If so, please ensure to disconnect with that device before trying to pair with the desired device.

SPECIFICATIONS:

- Power Input: 15V $\approx$ 2A
- Bluetooth® Pairing Name: Hearth&Hand 14

Need some help?

Can't get it to pair? Not accepting phone calls? Just have a question?



Call us at: 1-833-TGT-Tech

Safety

- Do not use near any water source
- Do not modify or repair this device
- Do not use in high temperatures or extreme weather
- Do not use chemical detergents to clean your device, use a soft dry cloth



FCC ID: 2BAXW-TFB246 Model:Kasa DPCI: 324-06-0089 Input: 15V $\approx$ Max 2A Made in China
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

2

Back

技术要求

1. 尺寸: 102x165mm, 公差: ± 1 mm
2. 材质: 80g书纸, 正反面单黑印刷, 折叠

产品型号:	B246
产品名称:	说明书
产品编码:	
日期:	2025年3月13日
版本:	A0