






Band38-5MHz-16QAM-38000-1RB#0-3000~1800

0-PASS




Band38-5MHz-16QAM-38000-1RB#0-18000~2700

0-PASS




Band38-5MHz-QPSK-38000-1RB#24-0.009~0.15

-PASS



Band38-5MHz-QPSK-38000-1RB#24-0.15~30-PA

SS




Band38-5MHz-QPSK-38000-1RB#24-30~1000-P

ASS



Band38-5MHz-QPSK-38000-1RB#24-1000~3000-

PASS




Band38-5MHz-QPSK-38000-1RB#24-3000~1800

0-PASS


Band38-5MHz-QPSK-38000-1RB#24-18000~2700

0-PASS




Band38-5MHz-16QAM-38000-1RB#24-0.009~0.1

5-PASS




Band38-5MHz-16QAM-38000-1RB#24-0.15~30-P

ASS




Band38-5MHz-16QAM-38000-1RB#24-30~1000-

PASS




Band38-5MHz-16QAM-38000-1RB#24-1000~3000


-PASS



Band38-5MHz-16QAM-38000-1RB#24-3000~18000-PASS




Band38-5MHz-16QAM-38000-1RB#24-18000~27000-PASS



Band38-5MHz-QPSK-38000-25RB#0-0.009~0.15

-PASS



Band38-5MHz-QPSK-38000-25RB#0-0.15~30-PA

SS



Band38-5MHz-QPSK-38000-25RB#0-30~1000-P

ASS



Band38-5MHz-QPSK-38000-25RB#0-1000~3000-

PASS




Band38-5MHz-QPSK-38000-25RB#0-3000~1800

0-PASS



Band38-5MHz-QPSK-38000-25RB#0-18000~2700

0-PASS




Band38-5MHz-16QAM-38000-25RB#0-0.009~0.1

5-PASS



Band38-5MHz-16QAM-38000-25RB#0-0.15~30-P

ASS




Band38-5MHz-16QAM-38000-25RB#0-30~1000-

PASS



Band38-5MHz-16QAM-38000-25RB#0-1000~3000


-PASS




Band38-5MHz-16QAM-38000-25RB#0-3000~180
00-PASS




Band38-5MHz-16QAM-38000-25RB#0-18000~270
00-PASS




Band38-5MHz-QPSK-38225-1RB#0-0.009~0.15-
PASS



Band38-5MHz-QPSK-38225-1RB#0-0.15~30-PAS
S



Band38-5MHz-QPSK-38225-1RB#0-30~1000-PA
SS




Band38-5MHz-QPSK-38225-1RB#0-1000~3000-P
ASS




Band38-5MHz-QPSK-38225-1RB#0-3000~18000
-PASS




Band38-5MHz-QPSK-38225-1RB#0-18000~27000
-PASS



Band38-5MHz-16QAM-38225-1RB#0-0.009~0.15
-PASS




Band38-5MHz-16QAM-38225-1RB#0-0.15~30-PA
SS



Band38-5MHz-16QAM-38225-1RB#0-30~1000-P
ASS




Band38-5MHz-16QAM-38225-1RB#0-1000~3000-
PASS




Band38-5MHz-16QAM-38225-1RB#0-3000~1800
0-PASS



Band38-5MHz-16QAM-38225-1RB#0-18000~2700
0-PASS



Band38-5MHz-QPSK-38225-1RB#24-0.009~0.15
-PASS



Band38-5MHz-QPSK-38225-1RB#24-0.15~30-PA
SS