




Band38-5MHz-QPSK-38225-1RB#24-30~1000-P

ASS



Band38-5MHz-QPSK-38225-1RB#24-1000~3000-

PASS




Band38-5MHz-QPSK-38225-1RB#24-3000~1800

0-PASS



Band38-5MHz-QPSK-38225-1RB#24-18000~2700

0-PASS




Band38-5MHz-16QAM-38225-1RB#24-0.009~0.1

5-PASS



Band38-5MHz-16QAM-38225-1RB#24-0.15~30-P

ASS



Band38-5MHz-16QAM-38225-1RB#24-30~1000-

PASS



Band38-5MHz-16QAM-38225-1RB#24-1000~3000

-PASS




Band38-5MHz-16QAM-38225-1RB#24-3000~180

00-PASS




Band38-5MHz-16QAM-38225-1RB#24-18000~270

00-PASS




Band38-5MHz-QPSK-38225-25RB#0-0.009~0.15

-PASS




Band38-5MHz-QPSK-38225-25RB#0-0.15~30-PA

SS



Band38-5MHz-QPSK-38225-25RB#0-30~1000-P

ASS



Band38-5MHz-QPSK-38225-25RB#0-1000~3000-

PASS



Band38-5MHz-QPSK-38225-25RB#0-3000~1800



Band38-5MHz-QPSK-38225-25RB#0-18000~2700

