






Band41-5MHz-QPSK-41565-1RB#24-30~1000-P
ASS




Band41-5MHz-QPSK-41565-1RB#24-1000~3000-P
PASS




Band41-5MHz-QPSK-41565-1RB#24-3000~1800
0-PASS




Band41-5MHz-QPSK-41565-1RB#24-18000~2700
0-PASS




Band41-5MHz-16QAM-41565-1RB#24-0.009~0.1
5-PASS




Band41-5MHz-16QAM-41565-1RB#24-0.15~30-P
ASS



Band41-5MHz-16QAM-41565-1RB#24-30~1000-P
PASS




Band41-5MHz-16QAM-41565-1RB#24-1000~3000-P
-PASS




Band41-5MHz-16QAM-41565-1RB#24-3000~180

00-PASS




Band41-5MHz-16QAM-41565-1RB#24-18000~270

00-PASS




Band41-5MHz-QPSK-41565-25RB#0-0.009~0.15

-PASS




Band41-5MHz-QPSK-41565-25RB#0-0.15~30-PA

SS




Band41-5MHz-QPSK-41565-25RB#0-30~1000-P

ASS




Band41-5MHz-QPSK-41565-25RB#0-1000~3000-

PASS




Band41-5MHz-QPSK-41565-25RB#0-3000~1800

0-PASS




Band41-5MHz-QPSK-41565-25RB#0-18000~2700

0-PASS



Band41-5MHz-16QAM-41565-25RB#0-0.009~0.1

5-PASS



Band41-5MHz-16QAM-41565-25RB#0-0.15~30-P

ASS



Band41-5MHz-16QAM-41565-25RB#0-30~1000-

PASS



Band41-5MHz-16QAM-41565-25RB#0-1000~3000

-PASS




Band41-5MHz-16QAM-41565-25RB#0-3000~180

00-PASS



Band41-5MHz-16QAM-41565-25RB#0-18000~270

00-PASS




Band41-10MHz-QPSK-39700-1RB#0-0.009~0.15

-PASS




Band41-10MHz-QPSK-39700-1RB#0-0.15~30-PA


SS



Band41-10MHz-QPSK-39700-1RB#0-30~1000-P
ASS




Band41-10MHz-QPSK-39700-1RB#0-1000~3000-P
PASS



Band41-10MHz-QPSK-39700-1RB#0-3000~1800
0-PASS




Band41-10MHz-QPSK-39700-1RB#0-18000~2700
0-PASS



Band41-10MHz-16QAM-39700-1RB#0-0.009~0.1
5-PASS




Band41-10MHz-16QAM-39700-1RB#0-0.15~30-P
ASS



Band41-10MHz-16QAM-39700-1RB#0-30~1000-P
PASS




Band41-10MHz-16QAM-39700-1RB#0-1000~3000
-PASS




Band41-10MHz-16QAM-39700-1RB#0-3000~180

00-PASS




Band41-10MHz-16QAM-39700-1RB#0-18000~270

00-PASS




Band41-10MHz-QPSK-39700-1RB#49-0.009~0.1

5-PASS




Band41-10MHz-QPSK-39700-1RB#49-0.15~30-PA

SS




Band41-10MHz-QPSK-39700-1RB#49-30~1000-

PASS



Band41-10MHz-QPSK-39700-1RB#49-1000~3000-

PASS



Band41-10MHz-QPSK-39700-1RB#49-3000~180

00-PASS



Band41-10MHz-QPSK-39700-1RB#49-18000~270

00-PASS