






Band41-15MHz-QPSK-41515-75RB#0-3000~180
00-PASS




Band41-15MHz-QPSK-41515-75RB#0-18000~270
00-PASS




Band41-20MHz-QPSK-39750-1RB#0-0.009~0.15
-PASS




Band41-20MHz-QPSK-39750-1RB#0-0.15~30-PA
SS



Band41-20MHz-QPSK-39750-1RB#0-30~1000-P
ASS




Band41-20MHz-QPSK-39750-1RB#0-1000~3000-
PASS



Band41-20MHz-QPSK-39750-1RB#0-3000~1800
0-PASS




Band41-20MHz-QPSK-39750-1RB#0-18000~2700
0-PASS




Band41-20MHz-16QAM-39750-1RB#0-0.009~0.1

5-PASS



Band41-20MHz-16QAM-39750-1RB#0-0.15~30-P

ASS




Band41-20MHz-16QAM-39750-1RB#0-30~1000-

PASS



Band41-20MHz-16QAM-39750-1RB#0-1000~3000

-PASS




Band41-20MHz-16QAM-39750-1RB#0-3000~18000-

00-PASS



Band41-20MHz-16QAM-39750-1RB#0-18000~27000-

00-PASS




Band41-20MHz-QPSK-39750-1RB#99-0.009~0.1

5-PASS




Band41-20MHz-QPSK-39750-1RB#99-0.15~30-PA

SS



Band41-20MHz-QPSK-39750-1RB#99-30~1000-
PASS




Band41-20MHz-QPSK-39750-1RB#99-1000~3000-
-PASS




Band41-20MHz-QPSK-39750-1RB#99-3000~18000-
00-PASS




Band41-20MHz-QPSK-39750-1RB#99-18000~27000-
00-PASS




Band41-20MHz-16QAM-39750-1RB#99-0.009~0.15-
15-PASS




Band41-20MHz-16QAM-39750-1RB#99-0.15~30-P
ASS



Band41-20MHz-16QAM-39750-1RB#99-30~1000-
-PASS



Band41-20MHz-16QAM-39750-1RB#99-1000~3000-
0-PASS




Band41-20MHz-16QAM-39750-1RB#99-3000~18000-PASS




Band41-20MHz-16QAM-39750-1RB#99-18000~27000-PASS




Band41-20MHz-QPSK-40620-1RB#0-0.009~0.15-PASS




Band41-20MHz-QPSK-40620-1RB#0-0.15~30-PA



Band41-20MHz-QPSK-40620-1RB#0-30~1000-PASS



Band41-20MHz-QPSK-40620-1RB#0-1000~3000-PASS




Band41-20MHz-QPSK-40620-1RB#0-3000~18000-PASS



Band41-20MHz-QPSK-40620-1RB#0-18000~27000-PASS



Band41-20MHz-16QAM-40620-1RB#0-0.009~0.1
5-PASS




Band41-20MHz-16QAM-40620-1RB#0-0.15~30-P
ASS



Band41-20MHz-16QAM-40620-1RB#0-30~1000-
PASS




Band41-20MHz-16QAM-40620-1RB#0-1000~3000-
-PASS



Band41-20MHz-16QAM-40620-1RB#0-3000~18000-
00-PASS



Band41-20MHz-16QAM-40620-1RB#0-18000~27000-
00-PASS



Band41-20MHz-QPSK-40620-1RB#99-0.009~0.1
5-PASS



Band41-20MHz-QPSK-40620-1RB#99-0.15~30-PA
SS