





Band41-20MHz-QPSK-40620-1RB#99-30~1000-
PASS




Band41-20MHz-QPSK-40620-1RB#99-1000~3000
-PASS



Band41-20MHz-QPSK-40620-1RB#99-3000~180
00-PASS




Band41-20MHz-QPSK-40620-1RB#99-18000~270
00-PASS



Band41-20MHz-16QAM-40620-1RB#99-0.009~0.
15-PASS




Band41-20MHz-16QAM-40620-1RB#99-0.15~30-P
ASS



Band41-20MHz-16QAM-40620-1RB#99-30~1000
-PASS



Band41-20MHz-16QAM-40620-1RB#99-1000~300
0-PASS




Band41-20MHz-16QAM-40620-1RB#99-3000~18000-PASS



Band41-20MHz-16QAM-40620-1RB#99-18000~27000-PASS




Band41-20MHz-QPSK-41490-1RB#0-0.009~0.15-PASS




Band41-20MHz-QPSK-41490-1RB#0-0.15~30-PA



Band41-20MHz-QPSK-41490-1RB#0-30~1000-PASS




Band41-20MHz-QPSK-41490-1RB#0-1000~3000-PASS




Band41-20MHz-QPSK-41490-1RB#0-3000~18000-PASS




Band41-20MHz-QPSK-41490-1RB#0-18000~27000-PASS



Band41-20MHz-16QAM-41490-1RB#0-0.009~0.1
5-PASS




Band41-20MHz-16QAM-41490-1RB#0-0.15~30-P
ASS



Band41-20MHz-16QAM-41490-1RB#0-30~1000-
PASS




Band41-20MHz-16QAM-41490-1RB#0-1000~3000
-PASS



Band41-20MHz-16QAM-41490-1RB#0-3000~18000-PASS




Band41-20MHz-16QAM-41490-1RB#0-18000~27000-PASS




Band41-20MHz-QPSK-41490-1RB#99-0.009~0.1
5-PASS




Band41-20MHz-QPSK-41490-1RB#99-0.15~30-PA
SS



Band41-20MHz-QPSK-41490-1RB#99-30~1000-
PASS




Band41-20MHz-QPSK-41490-1RB#99-1000~3000-
-PASS



Band41-20MHz-QPSK-41490-1RB#99-3000~18000-
00-PASS




Band41-20MHz-QPSK-41490-1RB#99-18000~27000-
00-PASS




Band41-20MHz-16QAM-41490-1RB#99-0.009~0.15-
PASS




Band41-20MHz-16QAM-41490-1RB#99-0.15~30-P
ASS




Band41-20MHz-16QAM-41490-1RB#99-30~1000-
-PASS



Band41-20MHz-16QAM-41490-1RB#99-1000~3000-
0-PASS




Band41-20MHz-16QAM-41490-1RB#99-3000~18000-PASS




Band41-20MHz-16QAM-41490-1RB#99-18000~27000-PASS




Band41-20MHz-QPSK-39750-100RB#0-0.009~0.15-PASS




Band41-20MHz-QPSK-39750-100RB#0-0.15~30-PASS



Band41-20MHz-QPSK-39750-100RB#0-30~1000-PASS



Band41-20MHz-QPSK-39750-100RB#0-1000~3000-PASS



Band41-20MHz-QPSK-39750-100RB#0-3000~18000-PASS



Band41-20MHz-QPSK-39750-100RB#0-18000~27000-PASS