


80*95mm

ICE COOLING FAN
MAGNETIC WIRELESS CHARGER




user manual

Product Specifications

Material:ABS+magnet
Input:5V/2A,9V/3A,15V/3A
output:25W

Instructions for use and operation

1. When connect the equipment to power, wireless charger will keep standby mode . When put mobile on the equipment, the ice cooling and fan will be opened, RGB will be lighted .
2. When double click switch, ice cooling will be turn off, the fan also be turn off after 10 seconds . Click switch for one time again, ice cooling and fan will be turn on .
3. when take off the phone on the progress of charging, wireless charging and ice cooling will be turn off at first, the fan will be turn off at 10 seconds later.
4. Please install the position of threaded hole to the holder of live stream, it can charging and abstract heat at the same time, it will keep phone still on low temperature .



FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.