Quick Start Guide

Quick start guide



Please put this user manual at hand for easy reference.

Introduction

Thank you for choosing notebook computer.

The purpose of this guide is to let users know and familiarize themselves with our products as soon as possible. Here, we briefly introduce the key layout and definition with pictures and words.

Catalogue

1. Notes before use ····· 02
2. Key layout and definition ····· 03
3. Key description ····· 04
4. Desktop introduction ····· 05
1. Startup screen ····· 05
2. Application program interface introduction ····· 06
3. Start menu ····· 06
4. Multitasking operation world ····· 11
5. Basic operation ····· 11
1. Sleep state, next to the computer and restart ····· 11

1、Precautions before use

1. The product is suitable for use in non tropical areas below 2000 meters. The mark on the nameplate indicates that the product is suitable for use in non tropical areas

2. Prevent the laptop from falling to the ground or receiving other strong impacts.

3 do not use this product for a long time in an environment that is too cold, too hot, too humid or too dusty. Do not expose your laptop to the sun.

4 avoid using this product in strong magnetic field and strong electrostatic environment as far as possible.

5. Once water or any other liquid splashes onto the laptop, it should be turned off immediately and not used before drying.

6 do not use any detergent or other liquid containing chemical ingredients to clean the laptop, so as to avoid damage due to corrosion and moisture. If it is necessary to clean, wipe it with dry soft cloth and paper towel.


7. The company does not assume any and all responsibilities arising from the loss or deletion of internal materials of the machine caused by abnormal software and hardware operation, maintenance or any other accident.

8 please back up important materials at any time to avoid loss


9 do not disassemble the notebook computer by yourself; Otherwise, you will lose the right of warranty.

10 this product supports 3G dongle network cards of most mainstream brands. 3G dongles may be different. It is recommended that you test it to ensure that it is free of any problems before purchase.

2、Key layout and definition



3、Key Description:




4、Desktop introduction

1. Windows10 startup screen: in the startup screen, you can see many fixed programs in the image. These applications are displayed in the form of "magnetic links". Just click on them and you can easily access them. You need to sign in to your Microsoft account before the application can fully run



2. Application program interface
introduction in addition to the applications that have been fixed on the startup screen, you can also start other applications in all applications, such as other software applications connected to the laptop.



5、Basic operation

1. Sleep state, shutdown and restart



4. Multi task operation interface
If you click "task view", the running program will be displayed. We can enter the application or delete it.










3. Start menu
In PC mode, press the start icon to display the start menu, including: start, device, settings, sharing and search programs.



General: File Manager, settings, power and all applications
Power Supply
Can enter sleep / shut down / restart the laptop
File manager
Can help you search for files and applications in your laptop.
Set up
Can help you set up your laptop
All applications
More applications can be scanned



The operation center is a notification center that can quickly set up the wireless network and Bluetooth of notebook computers

Quality assurance card

Information filled in by the user:

Name of user		Purchase date	
Contacts		contact number	
Contact address			
Dealer Name		Product category	
Product Name		serial number	
Dealer seal			

Warranty terms

1. In case of performance failure within seven days after the goods are sold, the goods (excluding man-made damage) must be replaced (subject to our inspection), but excluding man-made damage.
2. The goods are guaranteed for one year from the date of sale. Accessories are not covered by the warranty.
3. The warranty service is only valid for normal use.
4. Any man-made damage, self-disassembling, improper use and other external damage are not covered by the warranty. The card must be provided. If the card is not provided or altered without permission, the company has the right to handle it as non warranty.

Guarantee

User File

User Name		Buying Date	
Address		Telephone	
Dealer Name		Model NO.	
Commodity name		Odd Numbers	

Guaranteeltem

1. Days upon date of purchase, if there is function problem, we should offer Genuine item subject to good and packing maintain perfect
2. Year upon date of purchase, we will guarantee to keep the goods in repair (not including damage)
3. Guarantee service is subject to normally using
4. All of damage by man-made,we open the housing,tear off the sticker, unnecessarily using,or losing this Guarantee card,we will not guarantee.

Warning -laitement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.