

mibro

Mibro EarClip 2


用户手册

用户手册

感谢您购买本产品,使用前请仔细阅读并严格遵循使用说明书和注意事项并妥善保管,以备查阅。

温馨提示:当您收到本产品后,请在首次使用前先充电。

产品图解



- ① LED灯孔
- ② 多功能触摸键
- ③ 喇叭孔
- ④ 电量指示灯
- ⑤ 通话麦克风
- ⑥ 耳机充电接触针
- ⑦ Type-C充电口


产品充电

请于首次使用前将耳机入仓, 连同充电仓连接充电线充满电

- 把耳机放入对应的耳机槽, 确保耳机充电触点接触金属片;
- 当耳机的红灯蓝光交替闪烁时表示耳机正在充电中;
- 当充电仓为耳机充满电时, 充电仓白灯与耳机白灯同时亮;
- 当耳机进入低电时, 每5分钟低电提示, 同时耳机每5秒白灯闪烁两次。

当充电仓白灯闪烁时, 此时请为充电盒充电

- 插入USB为充电仓充满电时, 白灯常亮为充满;
- 连接USB适配器为其充电 (充电电流不超过1A);
- 长时间不使用时, 每三个月至少充电一次。



连接蓝牙



- ① 首次使用时, 打开充电盒盖子取出双耳机进行佩戴, 耳机将自动开机, 当听到提示音后, 耳机进入蓝牙配对模式;
- ② 打开您的手机系统蓝牙, 搜索到蓝牙名称 "Mibro EarClip 2" 并点击该设备名进行配对, 配对成功后耳机会发出提示音;
- ③ 耳机会记录上一次设备连接状态, 再次佩戴使用时, 会听到提示音表明双耳已连接, 可以正常播放设备音乐。

APP绑定

- ① 请扫描二维码下载“Mibro Audio”App。(右图所示)
- ② 设备绑定: 进入“设备”页面, 点击“添加设备”, 选择设备名称“Mibro EarClip 2”完成配对绑定。
- 确保设备电量充足, 蓝牙已开启, 手机与设备距离小于 10 米。



APP使用

AI自由对话

覆盖85种语言的实时语音对话, 随身知识库。

AI跨语言翻译

支持160+语种跨语言即时翻译, 包含通话翻译、拍照翻译、同声传译三大核心场景。

AI会议记录

高效生成会议记录, 会后自动生成会议要点总结和结构化思维导图。

睡眠舒缓音乐

内置多种舒缓白噪音、舒缓放松音乐随心听。

功能使用

来电状态

接听/挂断 双击任一耳机



唤醒语音助手 长按任一耳机



来电拒接 长按3秒任一耳机



音乐状态

播放/暂停 双击任一耳机



上一曲 三击左耳



下一曲 三击右耳



关闭蓝牙

以下情况之一耳机将自动关机

- ① 耳机放回充电盒;
- ② 从充电盒中取出后5分钟内没有设备连接;
- ③ 耳机电量低时(请及时充电)。



安全信息

使用和操作设备前, 请阅读并遵守以下注意事项, 确保设备性能最优化, 避免出现危险或非法情况。

- 产品信息和认证标示位于充电盒内。
- 为了防止可能出现的听力损伤, 请勿长时间用高音量使用本产品。
- 请遵守所在地区或国家的相关规定, 驾车时请勿使用本产品。
- 请勿将产品拆解、撞击、挤压、投入火中及高温环境中, 避免机械方式碾压或切割电池, 可能会导致爆炸。
- 产品内含不可拆卸的锂电池, 请勿自行更换电池, 以免损坏电池或设备。电池只能由授权服务中心更换且必须更换相同型号的电池; 更换不正确型号的电池, 会破坏防护措施, 导致起火、爆炸、电池漏液等。若电池出现严重鼓胀, 请勿继续使用。
- 请勿将旧电池扔进生活垃圾中, 应按当地法律法规要求处理本设备及废旧电池。
- 请勿在雷暴天气下使用本产品, 雷暴可导致设备工作异常, 并增加触电的危险。
- 请勿将电池置于极高温或极低气压环境下, 可能会导致爆炸或易燃液体或气体泄漏。
- 本产品并非玩具, 产品本体及配件内含小部件可能会造成孩童窒息或导致其他伤害, 请将产品放置在孩童接触不到的地方。



如接触部位皮肤出现红肿等症状时, 请立即停止使用并咨询医生。

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
耳机主体	○	○	○	○	○	○
电 池	✕	○	○	○	○	○
充 电 盒	○	○	○	○	○	○

本表格依据SJ/T11364-2014的规定编制。

- 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572规定的限量要求以下。
- ✕ 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。

本产品符合RoHS环保要求: 目前国际上尚无成熟技术可替代或减少电路组件的部分电子组件, 钢及铜合金的铅含量。



本标识内的数字表示产品(除电池外)在正常使用状态下, 环保使用期限为10年。

部件上的环保使用年限标识优先于产品上任何与之相冲突或不同的环保使用期限标识。本产品所有环保使用期限是指在产品说明书规定的使用条件下使用本产品不发生有毒有害物质泄露的安全年限。

性能故障及售后条例

名称	性能故障表
Mibro EarClip 2	1、使用过程中耳机无声； 2、通话过程中，对方听不到声音； 3、无法充电，充电指示灯不亮。

非保修条例

- 1、因用户使用造成的磨损脏污，如划痕、颜色改变的；以及接触化学试剂、尖锐物体碰伤、掉落挤压变形等人为损坏的情况；
- 2、未经授权维修、碰撞、误用、疏忽、滥用、进水、事故，以及使用非本产品标准配件造成故障的情况；
- 3、撕毁、涂改标贴、伪造防伪标识等情况；
- 4、因不可抗力造成的损坏；
- 5、不符合《性能故障表》所列性能故障的情况。

若有售后服务需求，请联系Mibro客服：

网址：www.mibrofit.com

邮箱：service@mibrofit.com

注意：

说明书中的产品、配件等插图均为示意图，仅供用户参考。由于本产品的更新升级，产品实物与示意图可能会有差异，请以实物为准！

请妥善保管该说明书及购买凭证。

● 商品最终解释权归Mibro品牌所有！

FAQ/疑难解答

一、为什么耳机触控功能有时候无响应？

- 1.可能是未正确触摸到触控区域导致无响应，请参照《使用说明书》的图示；
- 2.连续触摸的速度过慢，请确保触摸2次或者3次操作快速连续完成；
- 3.手指脏污或液体过多，造成触控区域不灵敏，请保持手指表面和耳机触控提示区域干净，再进行触控操作。

二、耳机听不到声音，或左右耳机声音不一致。

- 1.确认耳机处于工作状态；
- 2.确认耳机的音量大小是否合适；
- 3.确认耳机是否与手机正常连接；
- 4.请调整左右耳机佩戴完全一致；
- 5.请将耳机放回充电盒内，5秒后再取出重新连接使用；
- 6.请检查耳机电量是否过低，请将耳机放回充电盒内充满电再取出使用。

三、耳机通话效果不好

- 1.耳机的有效使用距离为10米，请确认耳机在有效使用距离内，且耳机与手机间无障碍物阻隔；
- 2.检查麦克风孔是否有灰尘或异物堵塞；
- 3.请确认耳机通话音量调节过小/静音；
- 4.请检查耳机电量是否过低，电量过低会影响耳机性能。

四、设备保养

- 1.带锂电池的产品若长时间不使用，请至少确保每三个月充一次电；
- 2.保持产品干燥，勿放在潮湿的地方，以免影响产品内部电路；
- 3.需避免在激烈运动或出汗较多时使用本产品，防止汗水渗透到产品内损坏本产品；

4. 勿将产品放置在太阳直射或者温度高的地方。高温会缩短电子部件的使用寿命、损坏电池、使某些塑料部件变形；
5. 勿试图拆开产品，如果非专业人员，可能会损坏产品；
6. 勿使用烈性化学制品、清洁剂清洁耳机；
7. 不要用尖体在产品表面上乱划和用硬体撞击产品，以免损坏外壳和影响外观。

包装明细

充电盒 x1个、耳机 x2个、说明书 x1本。

产品参数

耳机基本参数：

蓝牙型号	XPEJ017	电池容量	30mAh(每只)
蓝牙版本	V6.0	充电时间	约2小时
传输距离	≤10m/33ft	音乐时间	约4小时 70%音量
耳机重量	约4.2g(每只耳机)	待机时间	约12小时
防水级别	IPX4	输入参数	5V = 30mA
电池类型	聚合物锂电池		

充电盒基本参数：


电池容量	250mAh	充电时间	约2小时
输入参数	5V = 200mA	电池类型	聚合物锂电池
最小充电功率	0.125W	盒子重量	约30.7g
最大充电功率	1.15W		

User Manual

Thank you for purchasing this product, before using, please read carefully and strictly follow the instructions and precautions and keep it in a safe place for reference.

Note: Please fully charge it with the charging case before the first use when you receive the product.

Product Overview



- ① LED Light Hole ② Multi-function Button
- ③ Soundhole ④ Charging compartment status indicator
- ⑤ Microphone ⑥ Charging Pin
- ⑦ USB-C Charge input


Charging

Please put the buds into the box before the first use, and connect the charging cable with the charging box to fully charge.

- Place the earbuds in their respective slots, ensuring that the charging contacts make contact with the metal plates;
- When the white light on the earbuds stays on, it indicates that they are charging;
- When the charging case has fully charged the earbuds, both the white light on the charging case and the white light on the earbuds will turn off;
- When the earbuds reach a low battery level, a low-battery alert will sound every 5 minutes, and the white light on the earbuds will flash twice every 5 seconds.

When the charging box is low power, the light goes off, please charge .

- When the white light of the charging case flashes, it means that the earbuds are charging;
- When the charging case charging compartment, the white light of the charging compartment is solid to indicate that the battery is fully charged.
- Connect USB adapter to charge it (charging current shall not exceed 1A).
- If it is not used for a long time, it shall be charged at least once every three months.



Getting Starts



- ① Open the cover of the charging box and take out the double buds for wearing. The buds will automatically turn on. When prompt tone is heard, the buds will enter the Bluetooth pairing mode.
- ② Open your mobile phone system Bluetooth, search for the Bluetooth name "Mibro Earbuds 5" and click the device name to pair. The buds will prompt tone if the pairing is successful.
- ③ The buds will record the last connection status of the device. Take out two buds and wear them properly, you will hear prompt tone indicating that both buds are connected and the device music can be played normally.

Connect the APP

- 1 Please Scan the QR code to download the "Mibro Audio" App.
(As shown in the right image)
- 2 Device Pairing: Go to the "Devices" page, tap "Add Device," select the device name "Mibro Earbuds 6" to complete the pairing process.
- 3 Make sure the device has sufficient battery power, Bluetooth is turned on, and your phone is within 10 meters of the device.



Functions

Incoming call status

Double Press:
Double tap on any headset



Wake up voice assistant
Long press left and right ear



To reject an incoming call,
press and hold either earbud
for 3 seconds.



Music status

Double Press:
Play/Pause



Previous Three strikes
to the left ear.



Next song Three strikes
to the right ear.



Getting Off

The earbuds turn off automatically if:

- 1 You put earbuds back to the charging case.
- 2 When earbuds leave the charging case, but haven't connect to any devices within 5 minutes.
- 3 When the earphone battery is low (please charge it in time).



Using the App

AI Free Conversation

Real-time voice conversations covering 85 languages, portable knowledge base.

AI Cross-Language Translation

Supports instant cross-language translation for 160 languages, including three main scenarios: call translation, photo translation, and simultaneous interpretation.

AI Meeting Minutes

Efficiently generates meeting records, automatically creates meeting summary points and structured mind maps afterward.

Sleep Soothing Music

Built-in various soothing white noise and relaxing music for listening at will.

Safety Instructions

Before using and operating the equipment, read and observe the following precautions to ensure optimal performance and to avoid dangerous or illegal situations.

- Product information and certification labels are located inside the charging case.
- To prevent possible hearing damage, do not use this product at high volume levels for extended periods of time.
- Please observe the relevant regulations in your region or country and do not use this product while driving.
- Do not disassemble, hit, crush, put into fire or high temperature environment, avoid crushing or cutting the battery mechanically, which may lead to explosion.
- The product contains a non-removable lithium battery, please do not replace the battery yourself to avoid damage to the battery or the device. The battery can only be replaced by an authorized service center and must be replaced with the same type of battery; replacing the battery with an incorrect type will damage the protective measures, resulting in fire, explosion, battery leakage, etc. Do not continue to use the battery if it is severely inflated.
- Do not dispose of the old batteries in household garbage. Dispose of the equipment and used batteries as required by local laws and regulations.
- Do not use this product in thunderstorms, which can cause the equipment to work abnormally and increase the risk of electric shock.
- Do not subject the battery to extremely high temperatures or low air pressure.
- This product is not a toy, and the body and accessories are not intended to be used as a toy.
- This product is not a toy, the product body and accessories contain small parts that may cause children to asphyxiate or cause other injuries.
- This product is not a toy, and the small parts contained in the product body and accessories may cause children to suffocate or cause other injuries, so please keep the product out of children's reach.



If symptoms such as redness and swelling appear on the skin at the site of contact, discontinue use immediately and consult a physician.

Name and content of hazardous substances

Part name	Hazardous substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Earbuds	○	○	○	○	○	○
Battery	×	○	○	○	○	○
Charge Box	○	○	○	○	○	○

This table is prepared in accordance with SJ/T 11364-2014.

- Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit specified in GB/T 26572.
 - ×
- It means that the content of the hazardous substance in at least one homogeneous material of the component exceeds the limit specified in GB/T 26572.

This product meets the ROHS environmental protection requirements: there is no mature technology in the world to replace or reduce the lead content of some electronic components of circuit components, steel and copper alloys.



The numbers within this logo indicate that the product (except batteries), under normal use, has an The environmental protection use period is 10 years.

The Eco-Friendly Use Period markings on parts take precedence over any conflicting or different Eco-Friendly Use Period markings on the product. The Eco-Friendly Service Life of this product is the period of time during which this product can be used without leakage of toxic or hazardous substances under the conditions of use specified in the product manual.

Trouble shooting and after sales regulations

Name	Trouble shooting
Mibro Earbuds 6	1. The earbuds is silent during use. 2. During the call, the other party cannot hear the sound. 3. Unable to charge, the charging indicator is not on.

Non warranty regulations

1. Wear and dirt caused by users' use, such as scratches and color changes; As well as damage caused by contact with chemical reagents, sharp objects, falling, extrusion and deformation.
2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.
3. Tearing, altering labels, forging anti-counterfeiting marks, etc.
4. Damage caused by force majeure.
5. Non compliance with performance faults listed in the performance fault table.

If you need after-sales service, please contact Mibro customer service:

Website: www.mibrofit.com

Email: service@mibrofit.com

Attention:

The illustrations of products and accessories in the manual are schematic diagrams for users' reference only. Due to the update and upgrading of this product, the actual product may be different from the schematic diagram. Please take the actual product as the standard.

● Mibro brand owns the final right to interpret the goods.

FAQ

A. Why the headset touch function sometimes does not respond?

1. The touch area may not be touched correctly to cause no response, please refer to the instructions in the "User's Manual";
2. The speed of continuous touch is too slow, please make sure to touch 2 or 3 times to complete the operation quickly and continuously;
3. Dirty fingers or too much liquid, resulting in the touch area is not sensitive, please keep the surface of the fingers and the headset pressing. Please keep the surface of your fingers and the headset pressing area clean, and then touch the operation.

B. the headset can not hear the sound, or left and right headset sound inconsistent.

1. Confirm that the headset is in working condition;
2. Confirm that the volume of the headset is appropriate;
3. Confirm whether the headset is normally connected to the phone;
4. Please adjust the left and right headset wearing exactly the same;
5. Please put the headset back into the charging case and take it out after 5 seconds to reconnect it for use;
6. Please check whether the headset power is too low, please put the headset back to the charging box full of electricity before taking out to use.

C.the headset call effect is not good.

1. The effective use distance of the headset is 10 meters, please make sure that the headset is within the effective use distance and that there is no obstacle between the headset and the cell phone. Please make sure that the headset is within the effective using distance and there is no obstacle between the headset and the cell phone;
2. Check whether the microphone hole is blocked by dust or foreign matter;
3. Please make sure the volume of the headset is adjusted too low/mute;
4. Please check whether the headset battery is too low, low battery will affect the performance of the headset.

D.Equipment maintenance

1. If the product with lithium battery is not used for a long time, please make sure it is charged at least once every three months;
2. Keep the product dry, do not put in a wet place, so as not to affect the internal circuitry of the product;
3. Avoid the use of this product in intense exercise or sweating more, to prevent sweat penetration into the product damage this product;

4. Do not place the product in the sun or in a place with high temperature. High temperatures can shorten the life of electronic components, damage batteries, and deform some plastic parts;
5. Do not attempt to disassemble the product, if non-professionals, may damage the product;
6. Do not use strong chemicals, cleaning agents to clean the headset;
7. Do not use the pointed body on the surface of the product scratching and hard body impact on the product, so as not to damage the shell and affect the appearance.

Package Contents

Charging Box X1, Earbuds X2, User Manual X1.

Basic Parameters

Earbuds Basic Parameters:

BT Model	XPEJ017	Battery Capacity	30mAh (Per Earbuds)
BT Version	V6.0	Charging Time	About 2 hours
BT Range	≤10m/33ft	Play Time	About 4 hours
Input	5V = 30mA	Stand By	About 12 hours
Waterproof	IPX4	Weight	About 4.2 g (Per Earbuds)
Battery Type	Lithium ion polymer		

Charge Box Basic Parameters:

Battery Capacity	250mAh	Charging Time	About 2 hours
Input	5V = 200mA	Battery Type	Lithium ion polymer
Weight	About 30.7g		
Maximum charging power	1.15W		
Minimum charging power	0.125W		

FCC label information:

FCC ID: 2BAYW-XPEJ017

Model No.: XPEJ017



网 址: www.mibrofit.com

邮 箱: service@mibrofit.com

制造商: 甄十信息科技(上海)有限公司

地 址: 上海市闵行区紫星路588号2幢4015室

出口商: 甄十信息科技(深圳)有限公司

地 址: 深圳市龙华区民治街道民乐社区星河WORLD二期E栋1401、1402、1403、1408.

Web: www.mibrofit.com

Support: service@mibrofit.com

Manufacturer: ZhenShi Information Technology (Shanghai) Co., Ltd.

Address: Room 4015, Building 2, No.588 Zixing Road, Minhang District,
Shanghai, China

Exporter: ZhenShi Information Technology (Shenzhen) Co., Ltd.

Address: RM1401-1403,1408, Tower E, Galaxy World, Minzhi Street,
Longhua District, Shenzhen, China



RoHS



FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.