

无线耳机

使用说明书

M10

产品示意图



耳机参数配置

产品型号: M10
播放时间: 约4小时
操作方式: 触控操作
有效距离: ≥ 10米

版本: 5.3
通话时间: 约4小时
充电时间: 约1小时
喇叭: 铜环 8mm

包装清单

1. 充电盒*1 2. 左右耳机*1 3. 大号耳帽*2
4. 产品手册*1 5. 充电线*1

WIRELESS HEADSET

Operating instruction

M10

Product diagram



Headset Configuration

Product model: M10 Version: 5.3
Running time: about 4 hours Call time: approximately 4 hours
Operation mode: touch control Charging time: about 1 hour
Effective distance: ≥10 m Horn: copper ring 8mm

Packing list

1. charging box *1 2. Left and right earphones *1
3. Large ear cap *2 4. Product Manual *1 5. Charging cable *1

充电仓配置参数

喇叭功率: 5mW
充电时间: 约1小时
输入电压: 5V/500mAh

佩戴方式

打开充电仓盖,取出右耳耳机,将耳机喇叭端轻轻放入右耳耳道,再轻轻摆动耳机不晃动为宜。用同样方法佩戴左耳耳机。

操作方式

1. 开机
(1)打开充电仓盖子,取出耳机,自动开机,耳机呼吸灯闪烁。
(2)耳机在关机状态,长按耳机触摸板3秒开机
2. 关机
(1)将耳机放回充电仓,耳机自动关机充电
(2)耳机在开机状态下,长按耳机触摸板5秒关机

双耳配对连接

1. 打开充电仓盖子,取出耳机自动开机,耳机呼吸灯闪烁,进入自动组队状态,其中一个耳机灯灭,或者快闪变慢闪,表示组队成功。
2. 打开设备无线列表,搜索找到“TWS”


3. 点击连接“TWS”即可连接。如果连接失败,将耳机放回充电仓盖上盖子,然后重复上面操作步骤即可。

4. 双耳同时离开与设备正常连接距离后,耳机进入回连蓝牙耳机状态,5分钟内未完成回连成功,双耳将自动关机。

- 5、耳机开机之后,未连接手机之前,三击双耳任意一边自动切换中英文语言(单中文或单英文的产品无此功能)

首次连接设备后,下一次耳机重启开机,会自动连接上一次配对设备

双耳触控操作



耳机充电:耳机放入充电盒自动充电
充电呼吸灯闪烁,充满后熄灭
充电盒低电:数码管个位数闪烁
充电盒充电:数码管个位数闪烁,充满100停止

F&Q

- 1、问:怎么只有一个耳机有声音?
答:将两个耳机同时放回充电盒,关盖充电,然后在取出看是否恢复双耳模式。如未恢复,恢复出厂设置即可解决
2、问:手机无法连接耳机?
答:将手机上配对的M10删除,再配对连接即可
3、问:怎么听歌/通话没有声音?
答:安卓手机在手机连接记录的右边有一个设置图标,点击进入,将两个音频选项取消勾选再重新选择,苹果手机在设置通用辅助功能进入音频通话方式,选择自动,如果本来就是自动,更改为其他选项,然后在更改为自动,如未恢复,删除配对记录重新连接尝试
4、问:怎么有卡顿/断线?
答:如果使用耳机时,周边有大量的Wi-Fi设备, 4G信号, 大功率电器等等产生干扰,可能会出现卡顿,断线情况,更换环境或者重新配对连接可以恢复正常。

注意事项

- 1、请使用正规渠道有安全认证的充电器进行充电
2、使用耳机时适量的调节音量大小以免损伤听觉
3、正确使用产品避免高空掉落或重复挤压
4、儿童请在成人陪同下使用避免误食
5、远离高温或潮湿等极端环境
6、请勿拆卸本产品

特别声明

该设备符合FCC规则第15部分。操作需满足以下两个条件: (1) 本设备不得产生有害干扰, 并且 (2) 本设备必须接受接收到的任何干扰, 包括可能導致不希望的操作的干扰。

未经会费责任方明确批准的任何更改或修改都可能導致用户操作设备的极限失效。

附注: 本设备已经过测试。符合B类数字设备的限制, 根据FCC规则第15部分。这些限制旨在对住宅安装中的有害干扰提供合理的保护。本设备产生、使用并能辐射射频能量。如果不按说明书安装和使用, 可能会对无线电通信造成有害干扰。但是, 不能保证在特定的安装中不会发生干扰。

如果此设备确实对无线电或电视接收造成有害干扰, 您可以通过关闭和打开设备来确定。鼓励用户尝试通过以下一个或多个措施来纠正干扰:

- 调整接收天线的方向或位置。
 - 加大设备与接收器之间的距离。
 - 将设备连接器与接收器连接的电路不同的插座上。
 - 请咨询经销商或有经验的无线电/电视技术人员以获得帮助。
- 该设备已被评估, 以满足一胎的射频暴露要求。本装置可在便携式曝光条件下使用, 不受限制

special announcement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Pairs of ears connected

1. Open the cover of the charging compartment, take out the earphone and start it automatically Breath light flashing, go into automatic platoon mode, one of them If the headphone indicator is off or blinking slowly, the team is successfully formed.

2. Open the device wireless list and search for "TWS"

3. Click "TWS" to connect. If the connection fails, put the earphone back into the charging bin and cover it, and then repeat the above steps.


4. When both ears leave the normal connection distance with the device at the same time, the headset will enter the wireless headset connection state. If the connection is not successful within 5 minutes, the headset will automatically switch down.

- 5、 After the headset is turned on and before the mobile phone is connected, three clicks on either side of both ears will automatically switch between Chinese and English languages

(After the headset is turned on and before the mobile phone is connected, three clicks on either side of both ears will automatically switch between Chinese and English languages)

After the device is connected for the first time, the headset will automatically connect to the last pair device when it is restarted next time

Binaural touch operation



Play / pause music
Under music status, tap the L/R earphone once
Play the previous song
Under music status, tap L earphone 2 times
Play next song
Under music status, tap R earphone 2 times
Under music status, 3 times tap L earphone volume +
Under music status, 3 times tap R earphone volume -
Answer the phone
Tap the L/R headset
Refuse to answer the call
Long press L/R earphone for 2 seconds
Voice assistant
Long press L/R for 1.5 seconds

Earphone charging: Put the earphone into the charging box to automatically charge, close charging cover, charging indicator light red light, red light off after full
Charging box low power: The single digit of the nixie tube flashes
Charging box charging: The single digit of the digital tube flashes, and it stops when it is full of 100

F&Q

1. Q: How come only one earphone has sound?
A: Put the two earphones back into the charging bin at the same time, close the cover to charge, and then take them out to see whether the dual-ear mode is restored.
If the fault is not rectified, restore the fault to factory Settings
2. Q: The phone can't connect to the headset?
A: Delete the paired M10 on the mobile phone, and then make the paired connection.
3. Q: How can I listen to music/talk without sound?
A: Android phones have a setting icon on the right side of the phone connection record. Click enter to select two audio/connect and then re-select. Enter audio call mode in Setting General Accessibility, and select Automatic, if it is automatic, then other options, and then change to automatic, if not restored, Delete the pairing record and retry attempt.
4. Q: Why is there a stutter/stutter?
A: If you use headphones, there are a lot of Wi-Fi devices, 4G signals, high power appliances and so on interference, stuttering and discontinuous conditions may occur, and the connection can be restored by changing the environment or re-pairing..

Matters needing attention

1. Please use a charger with safety certification from a formal source for charging.
2. Adjust the volume of headphones to avoid damage to hearing.
3. the correct use of the product to avoid falling from high or heavy extrusion
4. Children should be accompanied by adults to avoid accidental ingestion
5. Stay away from extreme environments such as high temperature or humidity
6. Do not disassemble the product