

TWS V5.3

Wireless headset

M19

instructions

Specification of Earbuds

① Product Name: F9

② Wireless version : V5.3

③ Protocol: Supports HFP 1.7, HSP 1.2, AVRCP 1.6, SPP 1.2 and PBAP 1.0

④ Speaker Diameter : 8mm

⑤ Working distance: 10m-20m

⑥ Call Time: 4 H (1 time full charged)

⑦ Play Music Time: 4 H (1 time full charged)

⑧ Standby time:650H (With charger case)

⑨ Frequency:2402MHz~2480MHz

⑩ Battery type: 3.7V, >30mA Li Battery

⑪ Charging Time: 2H

⑫ Working Temperature: -10°-55°

Specification of charger case:

① Input current: 5V==1A

② Output current: 5V==1A

③ Battery type: 3.7V 600mAh Li Battery

④ Charging time: 2H

How to operate the earbuds:

① Make sure that the charging case has electricity. If the charging compartment is out of power, please fully charge the

charging compartment;(Pick up the two earbuds and put them back on the cover. The charging compartment indicator lights up to indicate that there is power. If it does not light, it means no power.)

② Take the two earbuds out of the charging case and wear them on the left and right ears respectively. The earphones will automatically turn on and automatically pair;(Voice prompt: power on, left channel, right channel, waiting for connection).

③ Turn on the phone Bluetooth and click on the connection pair name " TWS " to connect (voice prompt "Connected").

How to pairing

Setting

Bluetooth Turn off

Enter into the Settings

< Setting

Bluetooth Turn off

Select Bluetooth in your device

< Setting Bluetooth

Bluetooth Bluetooth

Bluetooth Name: TWS Disconnected

Others X7

Turn on bluetooth in your device settings Select tws " in your device's bluetooth settings to connect

< Setting Bluetooth

Bluetooth Bluetooth

Bluetooth Name: TWS Connected

Others

Bluetooth Paired

Warming remain

For the first time to use the earbuds or for a long time to no use, please charge the charging case and earphones before, Please keep it in an unobstructed and effective environment within 10 meters. Otherwise, it may be stuck and disconnected.

Indicator description:

① Charge the earbuds: Put the earbuds into the charging case and cover it to charge.
earbuds indicator: Lights up red when charging, and red light when fully charged. The charging case flashes green and the light is off after charging.

② Charge the charging case: Plug the 5V/1A USB into the charging port to charge. During charging, the middle digit of the charging stand display indicates the charging case power. When the number is displayed as "100", the battery is fully charged.
Charging case indicator light: The charging flashes green light, and the light is off after charging.

③ Charge to the mobile phone; 3 Charge the mobile phone: Connect USB Cable to USB port of case to charge the mobile phone.ChargingCase indicator light : Light will turn green when charging and turn off when fully charged

In master-slave synchronous binaural mode, double-click on one of the headphones is the previous song, and double-click the other headset is the next song!

NEXT Songs

PREV Songs

Double click One of them

This headset (As "A")

Double click Another one

This headset (As "B")

The functions of volume + / - are as follows: quickly triple tap "a" for volume +, and triple click "B" for volume-

Volume+

Volume-

3 times

As above (Mark "A")

3 times

As above (Mark "B")

Single Earbud Mode

Version 5.1 can achieve seamless connection, master-slave synchronization, no need to distinguish the primary and secondary. At present, single ear use does not need to switch signals, only need to connect a good signal name for the first time, and then take out any earphone, can automatically complete the connection. There is no need to pair single ear connection separately. If single ear signal is connected separately, which makes it impossible to use both ears, you only need to delete one ear signal, Team up again manually once again!

Headset signal name

"L"Headset signal name: TWS

"R"Headset signal name: TWS

Specification of Earbuds

① Product Name: F9

② Wireless version : V5.3

③ Protocol: Supports HFP 1.7, HSP 1.2, AVRCP 1.6, SPP 1.2 and PBAP 1.0

④ Speaker Diameter : 8mm

⑤ Working distance: 10m-20m

⑥ Call Time: 4 H (1 time full charged)

⑦ Play Music Time: 4 H (1 time full charged)

⑧ Standby time:650H (With charger case)

⑨ Frequency:2402MHz~2480MHz

⑩ Battery type: 3.7V, >30mA Li Battery

⑪ Charging Time: 2H

⑫ Working Temperature: -10°-55°

Specification of charger case:

① Input current: 5V==1A

② Output current: 5V==1A

③ Battery type: 3.7V 600mAh Li Battery

④ Charging time: 2H

How to operate the earbuds:

① Make sure that the charging case has electricity. If the charging compartment is out of power, please fully charge the

charging compartment;(Pick up the two earbuds and put them back on the cover. The charging compartment indicator lights up to indicate that there is power. If it does not light, it means no power.)

② Take the two earbuds out of the charging case and wear them on the left and right ears respectively. The earphones will automatically turn on and automatically pair;(Voice prompt: power on, left channel, right channel, waiting for connection).

③ Turn on the phone Bluetooth and click on the connection pair name " TWS " to connect (voice prompt "Connected").

How to pairing

Setting

Bluetooth Turn off

Enter into the Settings

< Setting

Bluetooth Turn off

Select Bluetooth in your device

< Setting Bluetooth

Bluetooth Bluetooth

Bluetooth Name: TWS Disconnected

Others X7

Turn on bluetooth in your device settings Select tws " in your device's bluetooth settings to connect

< Setting Bluetooth

Bluetooth Bluetooth

Bluetooth Name: TWS Connected

Others

Bluetooth Paired

Warranty Card

Warranty certificate, please fill in and keep it safely

ProductName

Sales date

Shop

After sale service

Packing details:

Item Name	Quantity
Bluetooth earbuds	2 pcs
Charger case	1 pcs
User manual	1 pcs
Eartips	2 pcs
Use charger line	1 pcs

TWS V5.3

无线耳机

M19

使用说明书

产品描述

耳机功能参数:

① 产品型号: F9

② 无线版本: V5.3

③ 支持协议: Supports HFP 1.7 HSP 1.2, A2DP 1AVRCP 1.6 SPP 1.2 and PBAP 1.0

④ 喇叭直径: 8mm

⑤ 工作距离: 10m-20m

⑥ 通话时间: 4 iH (满电单次使用)

⑦ 音乐播放时间: 4 H (满电单次使用)

⑧ 频率范围: 2402MHz~2480MHz

⑨ 电池类型: 3.7V, >30mAh 锂离子聚合物电池

⑩ 耳机充电时间: 2H

⑪ 工作温度: -10°C-55°C

移动充电仓参数:

① 输入电流: 5V==1A

② 输出电流: 5V==1A

③ 电池类型: 3.7V, 600mAh 锂电池

④ 充电仓充电时间: 2H

使用说明:

① 确保充电仓有电, 如果充电仓没电请给充电仓充满电; (把两只耳机拿起来再放回盖好盖子, 充电仓指示灯亮表示有电, 不亮表示没电)

配对示意图

设置

蓝牙 关闭

进入设置

< 设置

蓝牙 关闭

选择蓝牙选项

< 设置 蓝牙

蓝牙 未连接

确保蓝牙开关处于 ON状态, 搜索设备名: TWS 点击蓝牙名进入连接

< 设置 蓝牙

蓝牙 已连接

蓝牙连接成功

温馨提示:

首次使用或长时间不用, 请务必给充电舱和耳机充电后再使用, 请保持在10米内无阻碍的有效环境使用, 否则可能出现卡顿和断连。

指示灯说明:

① 给耳机充电: 把耳机放入充电舱, 盖好盖子即可充电。
耳机指示灯: 充电时亮红灯, 充满后红灯灭。充电舱闪绿灯, 充电后灯灭。

② 给充电舱充电: 把5V/1A的USB插入充电口, 即可充电。充电期间, 充电座显示屏中间数字表示充电舱电量, 当数字显示为 "100", 表示电量已充满。
充电舱指示灯: 充电闪绿灯, 充完电后灯灭。

③ 充电舱给手机充电: 拿USB连接充电舱放电口, 即可给手机充电。
充电舱指示灯: 充电亮绿灯, 充完电后灯灭。

功能操作:

开机: 长按触摸多功能键3秒开机, 或从充电仓中取出自动开机。

关机: 长按触摸多功能键5秒 (红灯常亮) 关机, 或直接把蓝牙耳机放回充电仓, 耳机自动红灯亮自动关机。

通话接听和挂断: 手机来电, 短按耳机触摸按键一次即接听。通话结束后, 再短按耳机触摸按键即为挂断通话。

拒接来电操作: 长按触摸主耳机多功能键3秒, 拒绝接听来电。

启动手机siri功能或语音控制功能: 长按触摸主耳机或副耳机主按键约1S听到提示音“嘟”后松手,手机siri功能已经启动, 短按按键结束此功能。

5.1版本在双耳模式下, 是不分主副耳的, 双击其中一只耳机是下一曲 (作为A), 双击另外一直耳机就是上一曲 (作为B)

下一曲

上一曲

双击 (作为 "A")

双击 (作为 "B")

加减 (+-) 音量操作: 快速三击作为 "A" 这只耳机是音量 "+" 快速三击作为 "B" 这只耳机是音量 "-", 也可以直接通过操作手机上面的音量调节音量大小

音量+

音量-

三击 (作为 "A")

三击 (作为 "B")

单耳使用方法: 5.1版本可以实现无缝连接, 主从同步无需区分单双耳, 也就是只要连接上组队好的信号, 就无需在去连接单耳的信号了, 取出任意一只耳机, 都可以完成自动连接, 单耳使用状态下取出另外一只耳机, 也会立刻完成组队进入双耳模式!

注: 单耳使用时

主耳机 (R) 信号名称: TWS

副耳机 (L) 信号名称: TWS

二次以上使用操作: 和已经连接使用过的手机---打开手机蓝牙, 同时拿出充电仓内的耳机, 不需要任何操作, 即会和手机自动连接上了。如果二次以上使用不同的手机, 需要按照使用说明中操作步骤操作后方可使用。

特别提示: 耳机出厂前已经做到了组队。如果出现左、右耳机不能组对, 同时开机后请双击任意一只耳机, 等待几秒钟, 看到其中一只耳机灭灯, 就代表组队成功了。(如果手机已经连接了单耳信号, 请一定先删除掉信号并关闭手机蓝牙, 在按前面方法完成组队)

注: 此操作也是清除手机与耳机之间的组队记录, 故这时需要将手机之前的蓝牙配对记录删除, 然后重新搜索连接。

护理及保养:

① 将蓝牙耳机放入口袋前, 请将蓝牙耳机放回充电仓, 避免碰撞所导致的误操作。

② 请勿使用具有磨损性的清洁剂清理蓝牙耳机。

③ 请勿将蓝牙耳机暴露在高温过高的地方。

④ 请勿将蓝牙耳机长时间暴晒。

⑤ 请勿让蓝牙耳机靠近火源。

⑥ 请勿将蓝牙耳机掉落、撞击、刮差、扭曲、敲打、碾压、投入水中等。

⑦ 使用蓝牙耳机时请将远离磁体、电器和扬声器附近。

⑧ 请勿将蓝牙耳机放置于极端温度中 (使用环境工作温度范围 -10°C -55°C)

⑨ 请勿将蓝牙耳机暴露潮湿的环境中

⑩ 若长时间不使用蓝牙耳机, 请充满电并隔一个星期冲一次电, 延长蓝牙耳机使用寿命。

安全指导:

① 充电仓请使用标准5V充电器 (4.9-5.5V)

② 充电仓与蓝牙耳机充电时请勿放在易燃易爆物品旁边。

③ 请勿拆卸充电仓与蓝牙耳机, 或将其它物品插入产品内, 以避免产品损坏甚至给你带来伤害。

严重警告:

请勿在充电时使用本产品, 请使用厂家指定的适配器给本品充电, 内置锂电池切勿拆开放置火中, 不可让金属品接触或短路电极, 不可碰击或挤压电池, 避免放置于潮湿腐蚀或过热 (>60°C) 环境中。

商品保修卡 (保修细则)

一、由购买日起至三个月保修期内, 机件如有发生故障时, 经本公司技术人员证实故障属正常使用下发生, 将提供免费修理及零配件更换服务。

二、在下列情况, 公司将拒绝提供保修服务;
a. 产品曾被错误操作, 疏忽使用或因天灾人祸等意外事件引到机件损坏。
b. 产品被非本公司技术人员修理及改造。
c. 产品机身号曾被转换、涂改或删除。
d. 产品不按原厂提供安装指示。

三、此保修卡提供之免费服务并不包括产品附件, 及其它装饰等项目。

四、本公司将不负责任何于器材损坏而招致直接或间接损失。

五、本保修卡内容若有修改, 恕不另行通知。

保修卡

保修凭证, 请认真填写妥善保管

产品型号

售出日期

购买商店

售后电话

包装清单:

名 称	数 量
蓝 牙 耳 机	2 pcs
充 电 收 纳 盒	1 pcs
说 明 书	1 pcs
耳 帽	2 pcs
充 电 线	1 条

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.