型号：H40-TS10图偲

尺寸：80*95mm

材质：128g铜版纸（风琴折）

80mm

95mm

英文

TOUTCE

TS10



Wireless Bluetooth Headset

Please read this manual
carefuly before using the earphone

Packing list

Earphone X2

Charging Case X1

Instructions Manual X1

Type-C Charging Cable X1

Ear caps X2(L/S)

Product idtroduction

(1) Do not try to disassemble or replace the product except for the operation mode specified in the instructions Any part of.
(2) Do not put the product into water or any other liquid, this product is not waterproof design.
(3) If any liquid accidentally enters the product, immediately disconnect and remove the product Product.
(4) In order to avoid electric shock, please ensure that your hands are free from water when installing or unloading the product.
(5) Do not place the product near the heat source or expose it directly near the fire source.
(6) Do not place this product in an environment with strong electromagnetic force, otherwise it will cause product failure.

Product standard

Product model : TS10
Bluetooth version: V5.4
Transmission distance: ≥10m
Battery capacity: 35mAh
Duration: about 4 hours (earphone)
Charging time: about 2 hours (earphone)
Rated input: 5V ⎓ 35mA

Charging case specifications

Battery capacity: 400mAh
Charging time: about 2 hours
Rated input: 5V ⎓ 400mA
Rated power:1.48Wh
(All technical information is subject to actual performance)

Charge the charging box
Connect the charging case to the 5V power adapter with the Type-C charging cable
(Warm tip: When opening and closing the lid, the white light flashes 10 times, please charge the charging box in time)

Rated input: 5V ⎓ 35mA(earphone)

5V ⎓ 400mA(Charging case)

LED Indicator Status

Product status	Indicator light definition
earphone in/out of the charging case	When the earphone enters the charging compartment, the corresponding white light will turn on. When the earphone is out of the charging bay, the corresponding white light is turned off.
Charging in the charging case	The charge cell power number blinks, and the low current white light blinks 10 times.
Charging complete	The charging compartment is fully charged, and the white light will turn off after 10 seconds
The charging compartment closes the lid to charge the earphone	Put the earphone into the charging compartment and close the cover to charge. The white light will be turned off after 10 seconds
Charging case low battery prompt	Low battery of charging bin: When opening and closing the cover, the white light flashes 10 times.
Charging case full battery prompt	The charging compartment is fully charged, and the white light will turn off after 10 seconds

Product Operation Instructions

① Power on
None (Open the cover and start automatically)

② Power off
None (automatic shutdown with closed cover)

③ pair
Step 1: Bluetooth pairing is automatically entered after the device is turned on
Step 2: Open the Bluetooth list of smart devices, search for "TS10" and connect

Touch key operation

Conventional mode

Voice assistant :L/R ear touch 3 times

Music playback mode

Pause/Play: Click the left/right earphone
Previous song: Double-click the left earphone
Next: Double-click the right earphone

Phone hands-free

Answer: Click the left/right earphone
Reject: Double-click the left/right headphones
Hang up: Double-click the left/right headphones

Noise reduction, transparent mode switching

Press and touch with left/right ear for 3 seconds
Default off, transparent, noise reduction (Cyclic switching)

Clear away pairing/factory data reset

- Left/right ear touch 5 times (not connected condition)

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.