


# R/C CAR INSTRUCTIONS

## RC CAR & TRANSMITTER

ON/OFF




Press the ON to turn on the power of the remote control car and start the remote control car.

FORWARD  
BACKWARD

ON/OFF


TURN LEFT  
TURN RIGHT



## BATTERY INSTALLATION

### battery Installation for vehicle


### battery Installation for transmitter



- 1 Remove the bottom screw of the remote control car and open the remote control car shell
- 2 Connect the RC car power cord to the battery power cord. When installing, place the power cord at the bottom of the battery compartment.

Note: Only use the special charger for battery charging


Remove the battery cover screw of the remote control and open the battery cover.





USE 2 x 1.5V "AA" SIZE BATTERIES (NOT INCLUDED)

## OPERATION MANUAL OF REMOTE CONTROL



FORWARD




LEFT TURN



BACKWARD




RIGHT TURN



# 遥控车使用说明书

## 遥控车和遥控器的操作

开关




按下开关键打开遥控车电源, 启动遥控车。

前进/后退

电源  
开关


左转弯/  
右转弯




## 电池的安装方法

车体装入电池示意图

遥控器装入电池示意图



将遥控器电池盖螺丝取出,  
打开电池盖。



2x1.5V “AA” 电池 (不包含)

注意: 1. 请勿混合使用新旧电池。  
2. 请勿混合使用碱性电池和充电电池。



❶ 将遥控车底部螺丝取出打开  
遥控车外壳

❷ 将遥控车电源线与电池电源线进行连接。  
安装时请将电源线贴合电池槽底部。



注意: 必须使用专用充电器进行充电, 确保技术参数适合充电器

## 遥控操作说明



前进




左转弯



后退



右转弯



## **FCC warning statements:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.