

FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) If this device does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WHEN USING A KEYBOARD:

1. Maintain proper posture and avoid excessive force on the keys.

2. Use regular breaks to prevent hand fatigue.

3. Clean the keyboard regularly to remove dust and dirt.

4. Avoid dropping the keyboard to the floor.

5. Keep the keyboard in a suitable environment, free from extreme temperatures or humidity.

Remember these tips for a comfortable and durable keyboard experience.



GUARANTEE
Non-human damage
12-month warranty

产品基础

PRODUCT BASIC INFORMATION



说明书
Manual



拔轴键帽器
Switch and Keycap Puller



键盘
Keyboard



Type-C 数据线
Type-C Cable



接收器
Receiver

● 尺寸: 392.5(L) x 144.9(W) x 44.6(H) ± 2
Size: 392.5(L) x 144.9(W) x 44.6(H) ± 2

● 键数: 98 keys
Num of Keys: 98 keys

● 背光: RGB
Backlit: RGB

● 轴体: 机械轴体
Switches: Mechanical switches

● 版本: 有线/2.4G/BT
Version: USB-C wired/2.4G wireless/BT

指示灯

INDICATORS

1 Num



灯常指示: 充满电时, 灯常闪烁绿色五次
Light bar indication: When fully charged, the light bar flashes green five times

2 Win



WIN Lock (WIN键指示灯常在键盘上, 打开亮白光, 关闭暗背光)
WIN Lock (WIN Lock indicator is made on the button, turn on the white light, turn off with the backlight)

3 CapsLock



— Caps Lock

4



低电量: F12键持续闪烁红光
Low battery: F12 key continuously flashes red light

5



USB

有线模式
Wired mode

BT模式
BT Mode

2.4G模式
2.4G Mode

有线模式

WIRED MODE

1



USB

有线模式
Wired mode

连接USB设备, 按下滚轮切换至USB模式
Connect the keyboard to the device using a USB cable and press the scroll wheel to switch to USB wired mode.

USB

有线模式
Wired mode

2



USB

有线模式
Wired mode

连接USB设备, 按下滚轮切换至USB模式
Connect the keyboard to the device using a USB cable and press the scroll wheel to switch to USB wired mode.

USB

有线模式
Wired mode

BT连接

BT CONNECTION

1



BT

BT模式
BT Mode

长按滚轮三秒开机, 短按滚轮切换至BT模式
Long press scroll wheel for 3 seconds to power on, short press to switch to BT mode.

BT

BT模式
BT Mode

长按任意键Fn+Q/W/E/3秒不动, 比如Fn+Q, 此时Q键快速闪烁, 表示已进入配对状态, 需等待指示灯在闪烁状态。
To pair the keyboard, press and hold any of the key combinations of Fn+Q/W/E for 3 seconds. Take Fn+Q for example, the Q key will quickly flash to indicate pairing mode, while a slow flash indicates reconnection mode.

3. 打开手机/手机BT, 搜索并连接设备, 搜索显示的名称: KZZI-K98 (连接Windows以上系统版本, 移动设备等)
To connect the device, open your computer or mobile devices' BT settings and search for "KZZI-K98". Select it to establish the connection. Note that it is compatible with Windows 8 and above systems, as well as mobile devices.

4. 以此类推: 重复以上步骤, Fn+Q/W/E 可同时存储3组BT设备, 短按Fn+Q/W/E, 即可在不同BT设备之间切换。
Similarly, Repeat the previous steps to connect and pair each desired BT device using the Fn+Q/W/E key combinations. Short press Fn+Q/W/E to switch between the stored devices.

(温馨提示: 使用切换前, 请先配对好3组BT)
(Reminder: Please pair the 3 BT devices before switching between them.)

2.4G连接

2.4G RECEIVER CONNECTION

1



2.4G

2.4G模式
2.4G Mode

长按滚轮三秒开机, 短按滚轮切换至2.4G模式
Long press scroll wheel for 3 seconds to power on, short press to switch to 2.4G mode.

2.4G

2.4G模式
2.4G Mode

长按Fn+P 3秒, P键快速闪烁时插入接收器, P键停止闪烁即配对成功。
Long press Fn+P for 3s, insert the receiver when the P key rapidly flashes, and successful pairing is indicated when the P key stops flashing.

3. P键持续闪烁表示键盘在配对模式。
Slow flashing P key indicates keyboard in reconnection mode.

(温馨提示: 出厂时2.4G接收器已配对, 无需自行再次配对, 此方法只适用于2.4G无法连接的情况使用, 设置一次即可, 无需每次都设置)
(Note: 2.4G receiver comes pre-paired. This method is only for troubleshooting 2.4G connection issues. Set it up once and no further setup is required.)

电池电量提示

KEYBOARD BATTERY LEVEL INDICATION AND CHECK

键盘背光可显示当前电池电量状态
The keyboard's lighting can display the current battery level status.



(无线模式下查看)
View in wireless mode

按Fn+ENTER 查看当前电量情况
Pressing Fn+ENTER allows you to view the battery level status. Each key from "1" to "10" represents a specific battery level range.

比如:
For example:

1 背光亮 表示此时电量10%的电量
The backlight of the "1" key is illuminated, indicating that the keyboard's current battery level is at 10%.


2 背光亮 表示此时电量20%的电量
The "1" and "2" keys are both illuminated, indicating that the keyboard's current battery level is at 20%.

以此类推
Similarly

11 背光同时亮, 表示此时电量100%
When the backlighting illuminates from 1 to 11 simultaneously, it indicates that the keyboard battery is at 100% charge.

背光控制

BACKLIGHT CONTROL



Fn + J] INS
支持多种背光效果切换
Multiple Backlight Effects Switch

Fn + Del Scrk
背光亮度 +
Backlight Brightness +

Fn + Home Prtsc
背光亮度 -
Backlight Brightness -

Fn + PgUp Pause
窗口锁定
Window Lock

Fn + PgDn END
恢复出厂设置(长按3秒)
Restore Factory Settings(Press And Hold For 3 Seconds)

Fn + \ / : |
背光亮度 +
Backlight Brightness +

Fn +
背光亮度 -
Backlight Brightness -

Fn + Win
窗口锁定
Window Lock

Fn + space bar
恢复出厂设置(长按3秒)
Restore Factory Settings(Press And Hold For 3 Seconds)

Fn + < >
背光单色切换
(仅适用于RGB版本)
Backlight Monochrome Switching
(Only Applicable to RGB Versions)

Fn + < >
背光速度 -
Backlight Speed -

Fn + < >
背光速度 +
Backlight Speed +

Fn + Esc
关闭 / 打开灯光
Turn Off / On Backlight

Fn + =+
切换灯光效果
Switch light bar lighting effect

Fn + Num+
灯光亮度 +
Light bar brightness +

Fn + Num-
灯光亮度 -
Light bar brightness -

Fn + < >
背光单色切换
(仅适用于RGB版本)
Backlight Monochrome Switching
(Only Applicable to RGB Versions)

Fn + < >
背光速度 -
Backlight Speed -

Fn + < >
背光速度 +
Backlight Speed +

Fn + Esc
关闭 / 打开灯光
Turn Off / On Backlight

Fn + =+
切换灯光效果
Switch light bar lighting effect

Fn + Num+
灯光亮度 +
Light bar brightness +

Fn + Num-
灯光亮度 -
Light bar brightness -

Fn + < >
背光单色切换
(仅适用于RGB版本)
Backlight Monochrome Switching
(Only Applicable to RGB Versions)

Fn + < >
背光速度 -
Backlight Speed -

Fn + < >
背光速度 +
Backlight Speed +

Fn + Esc
关闭 / 打开灯光
Turn Off / On Backlight

Fn + =+
切换灯光效果
Switch light bar lighting effect

Fn + Num+
灯光亮度 +
Light bar brightness +

Fn + Num-
灯光亮度 -
Light bar brightness -

Fn + < >
背光单色切换
(仅适用于RGB版本)
Backlight Monochrome Switching
(Only Applicable to RGB Versions)

Fn + < >
背光速度 -
Backlight Speed -

Fn + < >
背光速度 +
Backlight Speed +

Fn + Esc
关闭 / 打开灯光
Turn Off / On Backlight

Fn + =+
切换灯光效果
Switch light bar lighting effect

Fn + Num+
灯光亮度 +
Light bar brightness +


Fn + Num-
灯光亮度 -
Light bar brightness -

Fn + < >
背光单色切换
(仅适用于RGB版本)
Backlight Monochrome Switching
(Only Applicable to RGB Versions)

Fn + < >
背光速度 -
Backlight Speed -

Fn + < >
背光速度 +
Backlight Speed +

Fn + Esc
关闭 / 打开灯光
Turn Off / On Backlight



ISED STATEMENT:
English: This device contains **Imported**

English: This device contains Know-how/secret transfer(s) (know/secret) that comply with Innovation, Science and Economic Development Canada's Know-how/secret (RSS/s). Operation is subject to the following two conditions:

- (1) This device may not cause interference,
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

The digital apparatus complies with Canadian ICES-30 (2010) (ICES-30).

Français: Cet appareil contient des données/sécrets/transferts (savoir/sécrets) qui sont conformes aux RSS/s de l'Innovation, des Sciences et du Développement économique Canada.

L'opération est soumise aux deux conditions suivantes:

- (1) Cet appareil ne doit pas provoquer d'interférences,
- (2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles de provoquer un fonctionnement indésirable de l'appareil.

[appareil] numérique du chien conforme canadien peut - 3 (3) / mns - 3 (3) /
This device meets the exemption from the routine evaluation limits in section
conformance with RSS 102 RF exposures, users can obtain Canadian health
and compliance test report is confirmed a l'exemption des limites d'exposition
section 2.5 du crr - 102 et conformé avec ces 102 de l'exposition au r/s, les
obtenir des données canadiennes sur l'exposition aux champs de rf et si ce
This equipment complies with Canadian health and compliance test report for
environmental test equipment est conforme aux limites d'exposition aux champs
Canada états pour un environnement non contrôlé.

BATTERIES

A warning that batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine.


- 1) Replacement of a battery with an incorrect type that can defeat a safeguard;
- 2) Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery. This can result in an explosion;
- 3) Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
- 4) A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

A circular logo with a red border. Inside the border, the word "WARRANTY" is written in red at the top and bottom. In the center, the number "12" is large and red, with the word "MONTHS" in smaller red letters below it.

GUARANTEE
Non-human damage
12-month warranty

背光录制


BACKLIGHT RECORDING



WINDOWS多媒体键

WINDOWS MULTIMEDIA KEYS

Windows系统 (FN+A: 切换到Windows系统)
In Windows mode (FN+A: Switch to Windows system)



MAC多媒体键

MAC MULTIMEDIA KEYS

MAC系統 (FN+S: 切換到MAC系統)
In macOS mode (FN+S: Switch to macOS system)



Thank you for choosing KZZI products! If you have any questions or need assistance, please feel free to contact us. Our team is dedicated to providing support and addressing your inquiries.

We highly value your feedback and suggestions as they help us continuously improve and enhance product quality. Once again, we appreciate your support for KZZI!