


INSTRUCTION MANUAL


PLEASE READ ALL INSTRUCTIONS CAREFULLY AND REMAIN FOR FUTURE USE



Packing included:

1. Wireless speaker-----1PCS
2. Charging cable-----1PCS
3. User manual-----1PCS

Button Overview



Switch and LED Light

1. Long press to turn on/off the device
2. Short press to change the LED light mode, or turn on/off the LED light.



Mode & Pause/Play

1. Long press to change the playing mode including FM, Bluetooth, White Noise, TF Card, USB, and Aux-in.
2. In music playing mode, short press to pause/play the music, in FM mode, short press to searching the FM radios automatically.



White Noise Time Setting

In white noise mode, single press to change the white noise time among 15-30-60mins.



Volume up / Next Track / Timer Setting

1. Long press to increase the volume up.
2. Short press to next track
3. In timer setting, use this button to adjust the time.
4. In FM mode, short press to change the FM channel.



Volume down/ Prev. Track/Timer setting

1. Long press to decrease the volume down.
2. Short press to previous track
3. In timer setting, use this button to adjust the time.
4. In FM mode, short press to change the FM channel.



Alarm Clock Setting

1. Click this button to setup the alarm clock,
2. Short press to change the alarm clock sound
3. Long press to turn off/on the alarm clock



Timer & Alarm Clock Setting

1. Short press enter into timer setting.
2. Long press to change the time format between 12hrs-24hrs.

Type-C

Connect the charging cable to speaker's Type-C port, insert the other end to a adapter in 5V(not include). A red light is on when charging, and will switch off when full charge is reached.



TF Card

Insert a Micro SD card. TF mode will be started automatically



USB

Insert a USB flash drive. USB mode will be started automatically



Auxiliary

3.5mm input jack enable the sound source connection with computers, digital media player, mobile phones and other audio-visual products.

Bluetooth Connection

Use cell phone or other device search Bluetooth pairing name Sunset Speaker to connect, and the prompt voice will remind the Bluetooth connected successfully.

Wireless Charger

- Before using the wireless function, please kindly use the 9V/2A charging cable to connect the power.
- Place the Qi enabled smartphone onto charging surface with device centered. The smart phone will show the charging status and it means phone is not aligned properly or foreign object is detected (FOD). If this occurs, check device alignment , make sure charging surface is clear of foreign objects, remove phone case if applicable and try again.

- The wireless charger supports power outputs up to 15 watt fast charging. 9V/2A Power source required for fast wireless charging.
- The charging surface ,phone and accessories will feel warm during or after charging.

Time Setting

Single click  inter into timer setting, The Hour digit will flash, short press  and  to change Hour time. Press  again to confirm the Hour time, and Minute digit will flash, short press  and  to adjust the Minute time and time setting done, press  to save the setting.

Alarm Clock Setting

Single click  inter into alarm clock setting. Short Press  and  to adjust the Hour time , press  to confirm the Hour time. And minute digit will flash, short press  and  to adjust the minute time, after setting done, press  to confirm the time setting, and inter into setting the alarm sound use  and  to choose the music. After choose the music, press  again to save the alarm clock setting. And alarm clock icon will light up.

Long press  to turn on / off the alarm clock.

Press any button to close the alarm ringing.

Technical Specification

Wireless Version	V5.3
Input	5V/3A; 9V/2A
Output Power	8W*2
Maximum Working Range	10 M
Music Playing Time	3-4Hours
Battery Type	1800mAh
Wireless Charging	15W
Product Size	18*10*8.5CM

•FCC ID STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.