

正面

140*210 MM

KLT-LITE

MAGNETIC WIRELESS TRAILER LIGHT KIT

INSTRUCTION

10 HOURS

Running Time

100M RATIO

Communication Range

IP67

Waterproof

12 V

Wide Working Voltage

» Package Content:

» Function Instruction:

Signal transmitter

Strobe light

Reset

Short press the button:
Start/end up to receive stop turn tail signals from the signal transmitter on the 7 to 5 way plug

Press and Hold for 6s:
The yellow strobe light is on

Long press and hold for 15s:
To reset matching between the signal transmitter and receiver when you get a replaced new light or a new 7 to 5-way plug.

Charging Port

You can charge lights with Dual USB Charging Cable

Running Tail Light

Brake

Brake light or Turn Signal light

Ground

反面

140*210 MM

» Specification:

Input Voltage: DC5V	Input Current: 2A
Working Voltage: DC12V	Radio Communication Range: 100 Meters
Battery Capacity: 3000MAH	Charging Time: 3Hours
Waterproof Rate: IP67	Operating Temperature: -25℃-65℃
100% Battery working time: 10 hours	

» Testing:

Check if the lights work correctly before each use.

Running Tail Light

Brake Light

Strobe Light

Reverse Light

» Dimension:

Battery Life:

100%

10Hours

75%

7Hours

50%

4Hours

25%

2Hours

The data of endurance of battery is for your reference, the it depends on the road condition and driving habit.

Important Note:

1. Fully charge the battery before use.
2. Check the battery life before use.
3. Check if the lights work correctly before each use.
4. Charge the battery every 6 months if not in use.
5. Check lights regularly when use for long hours.
6. Replaced lights need to be reset and paired.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum 20cm distance between the radiator and your body. Use only the supplied antenna.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.