


Uyole Voice Recorder User Manual



Contents

1. Product Introduction
2. App Download
3. User Account Center
4. App Operation
5. Transcription & Summary
Service
6. FAQ

1. Product Introduction



① Recording Mode Switch

② Record / Stop / Power Button

③ Type- C Charging Port

1.1 Quick Start



- ▶ Search for Uyole in the Apple App Store or Google Play, then download and install the Uyole app.
- ▶ Register your Uyole account.



- ▶ Short press the Record Button to wake up the device.
- ▶ Open Uyole App → connect via Bluetooth.



- ▶ Open Uyole App → connect via Bluetooth.

1.2 Recording Modes

 NOTE

Slide DOWN:
Meeting
Recording Mode




 CALL

Slide UP: Call
Recording Mode



Notic

For call recording: attach the recorder to the back of your phone (phone case may affect quality).



Start Recording

Short press 1s → 1
vibration

Stop Recording

Short press 1s → 2
vibrations

Power On / Off

Power Off: Long press
5s → 1 vibration

Power On: Short press
1s (screen off) → wait
5s

2. App Download Guide

- ① iOS: Search Uyole in App Store
- ② Overseas Android: Search Uyole in Google Play
- ③ China Android: Search in built-in app store
- ④ If unavailable: Scan QR code with browser



Android



iOS

3.1 User Account CenterUser

- ① Registrationr: Open App → Register; Enter phone / email → get verification code; Password: ≥8 characters (letters + numbers / symbols).

Email Or Phone Login

Please input email or phon...

Enter password

Forget Password

Register

Login

Register

Please input email or phon...

Please input verificati...

Fetch Verification

Enter password

Register

- ② After logging in, you can change your password or log out at Me > Account Security. Account deletion will permanently erase all data and files. Please proceed with caution.

My Device

UYOLE >

Purchase Record

>

Transfer Record

>

General Settings

>

Account Safety

>

User Feedback

>

Nick Name

UYOLE >

Email

Change Password

>

Logout

Unregister

Warn: Unregister will permanently delete personal data and files

4.1 App Operation

Device Connection:


- ① Turn on Bluetooth
- ② App → Folder icon → Connect device
- ③ Select “UYOLE- XXXXXX” to pair



4.1 App Operation

Bluetooth Conditions:

- 1.Connect the app to the device via Bluetooth.
- 2.Tap the transfer button next to the folder.




Wi-Fi Conditions:

- 1.When the file size is 3MB or larger, tapping the pending transfer button will pop up a prompt asking whether to use Wi-Fi for faster transmission.
- 2.After selecting Wi-Fi transfer, the device will create a Wi-Fi hotspot.
- 3.Connect your phone to the device's Wi-Fi hotspot and keep the connection active.


4.1 App Operation

- 4.The file will be automatically transmitted to the app via Wi-Fi.
- 5.The device will automatically turn off the Wi-Fi hotspot 10 seconds after transmission completes to reduce power consumption




4.2 Recording & Transcription


- ① Tap Microphone → enter recording page
- ② Blue mic: Start;



- ③ Red mic: Stop





- ④ Tap Edit to transcribe





4.3 Transcription

- ① Support 121 languages & multiple AI models





4.4 Summary

① After transcription is completed, you may use industry templates to adjust the content, then generate a meeting summary





4.5 Mind Map & Translation

① A mind map will be generated automatically after the meeting summary is completed. Transcribed text, summaries, and mind maps can be individually translated into other languages





4.6 Share & Export

- ① Tap the Share button to share and export audio files, transcribed text, meeting summaries, mind maps, and translation results.





4.7 File Management

- ① Tap the File Management icon in the upper right corner of the folder page to delete single or multiple files, or merge multiple files.



4.8 App Settings

- ① In Me > General Settings > App Settings: Adjust recording interval to reduce file size and speed up transcription
- ② Toggle local and cloud storage. On: dual backup; Off: phone only



5. Transcription & Summary Service

① Each device includes 300 minutes of free transcription & summary per month. Additional minutes require a paid plan; otherwise, the service will be unavailable. See the chart below for

97

<

Recharge Time Card



Recharge Times: 00:00:00
Device Times: 09:31:57

120 Minute

\$ 2.99

600 Minute

\$ 12.99

3000 Minute

\$ 59.99

6000 Minute

\$ 99.99

Membership Benefits

AI generated transcription and summary



Transcription Duration



Instant Translation



Online Transcription

Regular User



Audio Transcription



Cloud Sync



Share



Export Recordings



Multiple AI Summary Templates



Export Transcription & Summary

\$ 2.99

Read & Agreed

<<Duration Purchase Terms>>



WeChat Pay



Alipay

<

Recharge Time Card



shunx2008@126.com
Recharge Times: 08:00:00
Device Times: 19:47:30

120 Minute

\$ 2.99

600 Minute

\$ 12.99

3000 Minute

\$ 59.99

6000 Minute

\$ 99.99

Membership Benefits

AI generated transcription and summary



Transcription Duration



Instant Translation



Online Transcription

Regular User



Audio Transcription



Cloud Sync



Share



Export Recordings



Multiple AI Summary Templates



Export Transcription & Summary

\$ 2.99

Read & Agreed

<<Duration Purchase Terms>>



In-App Purchase

wechat & Alipay

Apple Pay

6 FAQ

6.1、Connection & Pairing

Q1: Cannot find device via Bluetooth / Connection failed

A: 1. Make sure the device is on and the screen is lit; 2. Turn Bluetooth off and on again; 3. Restart the APP; 4. Disconnect the device from other phones first; 5. Restart the recorder and try again.

Q2: Frequently disconnected after successful connection

A: 1. Keep close to the phone; 2. Avoid interference from other Bluetooth devices; 3. Clear APP cache and restart phone and device; 4. Low battery causes unstable connection.

6.2、Recording Problems

Q1: No sound / Low volume

A: 1. Ensure the microphone is unobstructed; 2. Switch recording mode (Meeting / Call); 3. Stay away from loud noise; 4. Attach the recorder to the back of the phone for call recording.

6 FAQ

Q2: Recording stops automatically / Files lost

A: 1. Check remaining storage; 2. Low battery auto-saves and powers off; 3. Disable battery saver and background cleanup; 4. Wait for saving before powering off.

Q3: Noise / Static / Background hum

A: 1. Stay away from electrical and wireless interference; 2. Do not cover the microphone; 3. Avoid moving the recorder frequently during call recording.

6.3、Transcription & AI Functions

Q1: Cannot transcribe audio / Transcription failed

A: 1. Check network connection; 2. Ensure sufficient transcription time; 3. Damaged, silent or overly long audio may fail; 4. Switch AI model or language and try again.

Q2: Transcription is very slow

A: 1. Long audio (over 30 minutes) takes time; 2. Use stable network; 3. Close background apps.

6 FAQ

Q3: Inaccurate transcription / Many typos

A: 1. Clear recording improves accuracy; 2. Select correct language and industry template; 3. Strong accents or overlapping speech affect results; 4. Avoid distant or noisy environments.

Q4: AI summary / mind map not generated

A: 1. Transcribe first before summarizing; 2. Ensure good network and sufficient time; 3. Too short or empty text cannot be summarized.

6.4、File & Storage Issues

Q1: Cannot find recordings / Failed to export

A: 1. Check in APP File Management / Local Records; 2. Enable storage permission; 3. Avoid clearing phone cache; 4. Files saved locally only if cloud storage is off.

Q2: Cannot share / Failed to send

A: 1. Check network; 2. Split large files before sharing; 3. Enable share permission; 4. Restart APP and try again.

6 FAQ

6.5、Device & Charging Issues

Q1: Device cannot power on

A: 1. Charge for at least 30 minutes before powering on; 2. Check charging cable and port; 3. Long press the power button for 5 seconds to force restart.

Q2: No response when charging / Cannot charge

A: 1. Replace charging cable and charger; 2. Clean dust in the charging port; 3. Extreme temperatures affect charging; 4. Reactivate the battery if unused for a long time; 5. Charge and discharge at least once a month.

Q3: Fast battery drain / Short standby time

A: 1. Avoid using in extremely hot or cold environments; 2. Contact after-sales service if the battery is degraded.

6 FAQ

6.6、App & System Issues

Q1: App crashes / freezes

A: 1. Update the app to the latest version;
2. Clear phone memory and app cache; 3.
Restart your phone; 4. Uninstall and
reinstall the app.

Q2: Inaccurate real-time translation

A: 1. Real-time translation is affected by
noise and segmented recording; 2. Speak
clearly at a steady speed; 3. Use a stable
network for better results.

7 FCC Statement:

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

7 FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.