

GPS Navigation System

**English & Deutsch
User Manual**

English: Page 1-13

Official Website: www.naviprovip.com

Customer Service Email: customersupport@naviprovip.com

Deutsch: Seite 14-28

Offizielle Website: www.naviprovip.com

E-Mail für Kundenservice: customersupport@naviprovip.com



English User Manual

Our products are Your Best Choice!

- Our company reserves the rights of final interpretation of the manual. The contents of this manual are subject to change without notice.
- Please read the instructions in this manual carefully and use only manufacture-specified original accessories to avoid unpredicted damage. Failure to follow the instructions will invalidate warranty and might endanger personal safety.
- Data of navigation electronic maps might be inconsistent with actual traffic signals due to transportation update. Please drive according to the latest road situation, follow the traffic regulations and signs.
- Operating the GPS navigator device while driving might cause serious accidents. Please shorten your time in viewing the navigator and use the voice prompt function. While driving, try to shorten your time in operating the navigator, such as, inputting addresses, changing settings or using other functions.
- Please back up the GPS software and data of the GPS navigator. We assume no responsibility for any loss caused by software corruption and/or data loss. If any questions with software, please send an email to **customersupport@naviprovip.com**. We will help you sort it out.
- The device comes with 1-year warranty. All warranty will be excluding man-made damage.
- Invoice: If you need an invoice, please send us a message on online shop, we will send you one in PDF format. Please kindly tell us the invoice title and which email address we should send it to.
- The pictures in the manual are subject to the material object. The content of the manual has been checked for accuracy and consistency. However, if any mistake is found, please kindly email to **customersupport@naviprovip.com**, or go to our official website **www.naviprovip.com**, find out our Support or Customer Service Center, just leave us a message, we would reply you within 24 hours. Thank you!

Begin to use

The product picture below is subject to the material object.

Component	Explanation
Power button	Powering on/ off and sleep
Speaker	Playing sounds (such as navigation prompt tones, music, etc.)
Reset hole	Press to factory default setting
Earphone jack	Connected with the earphone
T-flash card slot	Insert T-flash card to extend storage
MINI USB port	Connect with PC via MINI USB cable, or used as the charging port
Indicator light	Indicating the operating state of external power supply

The main functions are listed as below.

Function	Explanation
Navigation	Tap to enable navigation function;
FM	Go to FM function;
Music Player	MP3 and WAV files supported; Random, sequence and cycle play supported;
GPS Viewer	Display GPS infos and signal status
Tools	Go to the calculator and unit converter;
Setting	Volume, backlight, language, date/time, calibrate, USB, system info, factory reset and navi path setting;
Multimedia	WMV, ASF and AVI files supported;

Power Supply & Charging

The GPS can be powered by the built-in battery or external power supply. When the GPS navigator is unconnected to the charger, it is powered by the Li-polymer battery. When the GPS navigator is connected to the charger (included car charger and USB cable), it is powered by external power and the battery is charged.

[Note]

- 1) When you turn on the GPS navigator, you need to press the power button for 3-5 seconds.
- 2) Fully charge the GPS navigator with the charger before first use. Plug one terminal of the car charger into the USB port of the GPS navigator, then the other terminal to the charging port of electric source.
- 3) The charging indicator light is red during charging. Do not unplug the charge until the indicator light turns green which indicate the battery is fully charged. Please charge the GPS navigator when the battery is low or used up.(The indicator light is also green when not charge even if the battery is not fully charged.)
- 4) To avoid damage due to current surge, plug in the car charger after the automobile is started. To make sure the navigator always on, please keep charging the navigator during use it.
- 5) Please notice that if you charge the GPS by connecting it to the computer with the USB cable, it will be charged very slowly (or won't be charged in this case). So it's better to charge the

navigation by using the USB cable to connect with an AC adaptor (Power adaptor for your mobile phone or other electronics).

- 6) When the power supply is cut off, the GPS shows a screenshot to ask if you want to shutdown the device. If you don't choose any options it shows, the device will turn off automatically after 10s.
- 7) If your GPS won't be charged, try with the main charger or another car charger. Facing with the charge problem, please kindly contact us.

[Attention!]

The GPS navigator adopts internal non-removable Li-polymer battery. To avoid battery rupture, explosion, release hazardous substance or burn, do not unpack, pierce, strike on or discard the battery in fire or water.

GPS Signal Search: Not showing the correct map location after entering navigation

- 1) When first starting up your GPS, you are suggested to have GPS unit fully charged and then go outdoors to search for satellite. It will take about 30 minutes. If the GPS signal is strong enough, the unit will locate your current location automatically.
- 2) On the main menu, click 'GPS Info', there are 12 channels. If more than 3 channels have caught satellite, the signal of the GPS unit is good.
- 3) If not showing the correct map location after entering navigation, please check if the map of your location has been preloaded after finishing step1) and step 2) above. You can check it as the

following way: Navigation→Destination→find address→enter an address around your location.

Connecting a Computer

Turn on the GPS unit and check the USB setting first: Main menu→Setting→USB→choose 'Mass Storage'.

When connecting, a flashing USB stick on the screen which means it has been recognized by the computer successfully. Please notice that you need to turn on your GPS device first, while connecting to a computer. Otherwise, it won't be recognized.

[Attention!]

You cannot use the GPS unit, while connecting to a computer. It works only as a flash drive.

Navi Path Setting

Turn on the GPS unit and set Navi Path: click 'Main Menu' → 'Settings' → 'Navi Path'. Click the grey button on the right side of 'Navigation exe file path': double click 'ResidentFlash' → double click 'Navi' or 'US' → double click 'Navi.EXE' → Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Language Settings

For language setting, there are :

- 1) **Main menu:** Settings → Language → and then set the language you want. You can scroll down for more languages.
- 2) **For the language when entering the navigation:** please go

"Main menu → Navigation → Settings(Tools icon: 

→Regional(Flag icon) → Program Language(The first line) → set the language→Done". Then restart the Navigation program.

3) **For the voice command when driving:** please go "Main

menu → Navigation → Settings(Tools icon: ) → Sound and Warnings → Voice Language" to select the voice profile you want.

Backlight Settings

1) Backlight setting in Main menu → Settings →Backlight
→Please adjust the backlight brighter to avoid dark screen.

2) Backlight setting in Navigation System: Main menu →

Navigation → Settings (Tools icon: )→ Display → Current

Backlight →Please adjust the backlight brighter to avoid dark screen.

3) Night mode or day mode setting: Main Menu → Navigation→

Settings (Tools icon: )→ Map Settings → Colors →

Day/Night/Auto mode. Please set in as day mode to avoid dark screen.

4) Map Colour : Main Menu → Navigation → Settings (Tools

icon: )→ Map Settings → Day Map Colour/ Night Map Colour.

Please choose a bright one.

Voice settings: If you find it has No Voice on your GPS, please do following steps

1) Please check if you have turned on the FM function. If yes,

please turn it off: Main menu → FM → turn off "Use FM".

2) Please check the volume setting on the main menu: Main menu
→ Settings → Volume

3) Please kindly check the volume settings in navigation: Main

menu → Navigation → Settings (Tools icon: )→ Sound and

Warnings → Volume → Maximize all the volume tabs

4) Please change to another voice profile: Main menu →

Navigation → Settings(Tools icon: ) → Sound and Warnings →

Voice Language → select another voice and try that one.

Setting the Times

1. Main menu → Settings → Date&Time: time zone/hour
format/date format

2. Main Menu → Navigation → Settings (Tools

icon: )→Regional → Time Zone → Set time zone of your

location

Notice: Do not tick "Use Auto Time Zone", otherwise, the time might display incorrectly because the time changes according to the location of your GPS. If the GPS location is in another country, e.g. Germany, it will display the Germany time, not the correct time in Great Britain.

3. Main Menu → Navigation → Settings (Tools icon: ) →

Regional → Units and Formats → Time Format/Date Format/Date
Delimiter in 2nd page.

Connecting to FM

Regarding connecting the unit to your car stereo, please do the as following:

Click the icon "FM" on the main menu → tick "Use FM" and set a certain channel (please don't set the channel the same as or close to the local radio station) → turn on your car radio → set the same channel as the one you set in your GPS unit → then the sound of GPS can be played in your stereo. Now you can adjust the volume based on your personal interest.

[Notice] No sound will come out from the GPS unit if you turn on the FM.

Vehicle Settings

The default vehicle mode is truck mode.

You can change it according to your actual request as the following way:

Navigation → Settings(Tools icon: ) → Route Settings → Vehicle(chose your vehicle type and tick it). You have 7 vehicle modes between Car/Pedestrian/Bicycle/Emergency/Bus/Taxi/Truck(Lorry). After you selected the vehicle mode you need, then click the icon

'screw and spanner' , you can enter the basic information of your vehicle such as such as length, width, height and Max. Speed.

The following is the Max. Speed modification interface:




How can the current speed displayed on the map:


After you have entered the destination and started, you get an interface like the following figure:



You can also see that there are three options in the lower right corner: "Distance", "Time Left", "Speed Limit". Long press any icon, e.g. Speed Limit. You can get the following interface.



Please scroll down the display from the "Data Fields" position and find the "Speed" option. Then tap this option. You then get the following interface.



Now click the "Back" button and you can see the current speed on the map.



Search Methods

1. Find address: Main menu → Navigation → Destination → Find address → Input your address
2. POI search: Main menu → Navigation → Destination → Find places → Quick search/Custom search
3. Postcode search: Main menu → Navigation → Destination → Find address → Input your country and post code
4. Coordinate Search: Main menu → Navigation → Destination → more → Coordinate
5. Favorites: You can set some places you find as favorites so that you can find it quicker next time: Main menu → Navigation → Destination → Favorites
6. Inputting Additional Stops: Main menu → Navigation → Route Options → Edit Route → The first address you added will be the default start (You can start from your current GPS position) → click '+' to add additional stops → The last place you added will be

the destination.

How to Enter Postal Codes (For User from United Kingdom)

When searching for addresses by using the postal code this device differs from other devices when navigating by postal codes, it does support full UK postcodes.

After loading the navigation program, click the "Find address" icon and you will be presented with a page which asks for Country, Town etc. Click "Town field" and start to enter postcode.

Here's the info showing you how to enter postcode.

When you input the postal code, please make sure that there's a space in the middle. Example: for postcode G11 6BH, you would enter it like G—1—1—SPACE—6—B—H, not just G—1—1—6—B—H. There are five, six, and seven digit postal codes. With a six digit postal code, leave a space right in the middle, after the third digit. For five digits postal codes, leave a space after the second digit, and for 7 digits postal codes, leave a space after the fourth digit.

Route Plan Method Setting

Main Menu → Navigation → Settings(Tools icon: ) → Route

Settings → Route Planning

Method:(Fast/Green/Economical/Easy)

Changing from Kilometers to Miles



Click "Main Menu" → "Navigation" → "Settings(Tools

icon: )" → "Regional" → "Units and Formats" → "Distance":



Miles/feet&Miles/yards&Kilometres/metres

Why I can not finish the map viewer?

If you get the following interface and can not finish the map viewer, please click the option "Close". Thereafter, the option will change from "Close" to "Menu" option. Long press"Menu", then you can exit the map viewer.



[Attention!] After exit the map viewer, you should make the setting as follows: Main menu → click "Navigation" → Under this interface, you will see 3 small icons at the bottom. Please click the 2nd icon to check if you have ticked the setting "Skip navigation menu". If so, you should remove the hook.




Warning setting

Main Menu → Navigation → Settings (Tools icon: ) → Sound and

Warnings → Speed warning Setting:

- 1) Warn when speeding: click to chose "Audio and Visual/Disabled/Visual". Please notice speed warning is not active while choosing "Disabled".
- 2) Speed limit always visible: please tick it.
- 3) Warn when my speed is 100% of limit: suggest to set it as 100%



2D/3D View Mode Setting

Main Menu → navigation → Settings (Tools icon: ) → Map setting → View mode → Click to choose 2D/3D.

Factory Reset

Please back up the data before reset. There is a reset hole at the back of the GPS. Please kindly hold it down for about 5 seconds with a touch pen or a stick, then you can make a factory reset. You can also do the factory reset by clicking above symbol: Main

menu → Settings → Restore Set

After the factory reset you have to reset the navigation path:

Turn on the GPS unit and set Navi Path: click 'Main Menu' → 'Settings' → 'Navi Path'. Click the grey button on the right side of 'Navigation exe file path': double click 'ResidentFlash' → double click 'Navi' or 'US' → double click 'Navi.EXE' → Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Optional function (If available): Bluetooth Settings:

Hands-free via Bluetooth connection. You can synchronize the phone book on the GPS. You can make calls, answer the phone or listen to phone's music via GPS.

About Bluetooth connection, please first confirm that Bluetooth of your mobile phone and GPS are turned on.

1. Before connecting, you should first set the Bluetooth file:

Main menu → Click "Bluetooth" → Click "Setting": The default of the Bluetooth name is "JTDPN" and the PIN code is "0000." Click the keypad behind it and you can modify the name and PIN code.

2. If you want to connect GPS-Bluetooth to your phone, the steps are as follows:

Main menu → Click "Bluetooth" → Click "Search", then the GPS-Bluetooth will search your mobile → After finding the name of your phone's Bluetooth from GPS, it points to this interface and click it → Click the blue icon "✓" on the right side to connect the Bluetooth between the GPS and your mobile phone → Your

mobile will receive a pairing request. Please enter the PIN code and the Bluetooth connection will be ready.

3. Phone book sync: Main menu → Click "Bluetooth" → Click "PhoneBook", then the phonebook will be automatically synchronized by your mobile phone on the GPS.

Online Map Updates

Map Updates for Navigation sold on [Amazon.uk](https://www.amazon.co.uk)

1. Please access this website to download the maps:

<http://www.naviprovip.com>, click Downloads → EU Maps Update.

2. Choose the right maps for the country you want, and then download it. After successful downloading → unzip it on your computer.

Notice: The download maps files can't be read in your computer. It's not compatible with computers. But don't worry, the files are compatible on the GPS unit.

3. Connect the unit to your computer → open your GPS device on your computer → open the folder 'Navi' → folder 'CONTENT' → folder 'MAP' → find out the maps of the country you want to update → delete them → put on the new files → disconnect the computer → Done

Note: If you can not see the GPS device on your computer. Please turn on the GPS unit and click "Setting" > click "USB" > choose "MASS STORAGE" > click "✓" in the upper right corner of the page. Now you can see the GPS device on your computer when you connect to it. After disconnecting, remember to switch the USB connection mode back to the "MS ACTIVELY INC",

otherwise you will not be able to enter the Navigation page of the GPS unit.

4. Turn on the GPS unit and set Navi Path: 'Main menu'→'Settings'→'Navi Path'→click the grey button on the right side of 'Navigation exe file path' →click 'ResidentFlash'→click 'Navi'→'Navi.EXE'→Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Update the entire navigation file

If you accidentally delete all navigation files and cause the projector to malfunction and cannot be used normally, please follow the steps below to update the entire navigation file.

1. First enter the Google Drive website:

https://drive.google.com/file/d/1W8uOiUNtnEdTq5IDpSxiKuCqHIMevHnn/view?usp=share_link

Notice: As the map is updated every quarter, the link will change accordingly. Please contact our customer service team via email for the latest link.

2. Download the zip file (file name "Navi") to your computer and unzip it.

3. Use USB cable to connect the the GPS unit to computer, and the GPS unit will be recognized as the hard disk folder "Navi" on the computer.

Note: If you can not see the GPS device on your computer. Please turn on the GPS unit and click "Setting" > click "USB" > choose "MASS STORAGE" > click "✓" in the upper right corner of the page. Now you can see the GPS device on your computer

when you connect to it. After disconnecting, remember to switch the USB connection mode back to the "MS ACTIVESYINC", otherwise you will not be able to enter the Navigation page of the GPS unit.

4. Just right-click on the computer to format the hard disk folder "Navi". Then copy the downloaded and decompressed folder "Navi" to the hard disk folder, replacing the original folder "Navi".

5. Disconnect the GPS unit from the computer and reset the Navi Path: 'Main menu'→'Settings'→'Navi Path'→click the grey button on the right side of 'Navigation exe file path' →click 'ResidentFlash'→click 'Navi'→'Navi.EXE'→Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Map Updates for Navigation sold on [Amazon.com](https://www.amazon.com)

1. Please access this website to download the maps:

<http://www.naviprovip.com>, click Downloads →US Maps Update.

2. Choose the right maps for the country you want, and then download it. After successful downloading → unzip it on your computer.

Notice: The download maps files can't be read in your computer. It's not compatible with computers. But don't worry, the files are compatible on the GPS unit.

3. Connect the unit to your computer → open your GPS device on your computer→open the folder 'US'→folder 'CONTENT' →folder 'MAP' → find out the maps of the country you want to update → delete them → put on the new files → disconnect the computer →Done

Note: If you can not see the GPS device on your computer. Please turn on the GPS unit and click "Setting" > click "USB" > choose "MASS STORAGE" > click "✓" in the upper right corner of the page. Now you can see the GPS device on your computer when you connect to it. After disconnecting, remember to switch the USB connection mode back to the "MS ACTIVESYINC", otherwise you will not be able to enter the Navigation page of the GPS unit.

4. Turn on the GPS unit and set Navi Path: 'Main menu'→'Settings'→'Navi Path'→click the grey button on the right side of 'Navigation exe file path' →click 'ResidentFlash'→click 'US'→'Navi.EXE'→Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Update the entire navigation file

If you accidentally delete all navigation files and cause the projector to malfunction and cannot be used normally, please follow the steps below to update the entire navigation file.

1. First enter the Google Drive website:

<https://drive.google.com/file/d/1EYcP5vOZcdrxHn2WusTZsggePW6OmdW1/view?usp=sharing>

Notice: As the map is updated every quarter, the link will change accordingly. Please contact our customer service team via email for the latest link.

2. Download the zip file (file name "US") to your computer and unzip it.

3. Use USB cable to connect the the GPS unit to computer, and

the GPS unit will be recognized as the hard disk folder "US" on the computer.

Note: If you can not see the GPS device on your computer. Please turn on the GPS unit and click "Setting" > click "USB" > choose "MASS STORAGE" > click "✓" in the upper right corner of the page. Now you can see the GPS device on your computer when you connect to it. After disconnecting, remember to switch the USB connection mode back to the "MS ACTIVESYINC", otherwise you will not be able to enter the Navigation page of the GPS unit.

4. Just right-click on the computer to format the hard disk folder "US". Then copy the downloaded and decompressed folder "US" to the hard disk folder, replacing the original folder "US".

5. Disconnect the GPS unit from the computer and reset the Navi Path: 'Main menu'→'Settings'→'Navi Path'→click the grey button on the right side of 'Navigation exe file path' →click 'ResidentFlash'→click 'US'→'Navi.EXE'→Click on the green icon in the upper right corner '✓'. Then it will go back to page 'Navi Path'. Now, it's done.

Maps for downloading from our web

European Maps for Navigation sold on [Amazon.uk](#):

Germany, Albania, Ireland, Estonia, Andorra, Austria, Belarus, Belgium, Bosnia Herzegovina, Bulgaria, Poland, Denmark, Georgia, Vatican, Netherlands, Montenegro, Czech, Kosovo, Croatia, Latvia, Lithuania, Liechtenstein, Luxembourg, Romania, Malta, Macedonia, Moldova, Monaco, Norway, Portugal, Sweden,

Cyprus, San Marino, Slovakia, Slovenia, Spain, France, Greece, Hungary, Italy, United Kingdom, Gibraltar, Iceland, Australia, New Zealand etc...

US/CA/MX Maps for Navigation sold on [Amazon.com](https://www.amazon.com):

New_York, Canada, Mexico, Washington, Wisconsin, Wyoming, Virginia, West_Virginia, Virgin_Islands, Vermont, Texas, Utah, Tennessee, US_Virgin_Islands, Territorial_Waters_TA, Oklahoma, Pennsylvania, Ohio, South_Carolina, South_Dakota, Nebraska, Rhode_Island, Oregon, Puerto_Rico, North_Carolina, Michigan, North_Dakota, Northern_Mariana_Islands, New_Jersey, Guam,

New_Mexico, Nevada, New_Hampshire, Missouri, Montana, Mississippi, Minnesota, Maryland, Massachusetts, Maine, Iowa, Kentucky, Kansas, Louisiana, Illinois, Indiana, Idaho, Hawaii, Georgia, Florida, Delaware, District_of_Columbia, California, Alaska, Colorado, Connecticut, Arizona, Arkansas, Alabama

[Note] Amount of the maps changes according to the newest updated maps version.

Deutsche Bedienungsanleitung

Unseres Produkt ist Ihre beste Wahl!

- Unsere Firma behält sich das Recht vor, das Handbuch zu interpretieren. Der Inhalt dieses Handbuchs kann ohne vorherige Ankündigung geändert werden.
- Bitte lesen Sie dieses Benutzerhandbuch gründlich durch und verwenden Sie nur das vom Hersteller mitgelieferte Zubehör, um unvorhergesehene Schäden zu vermeiden.
- Wenn Sie die Anweisungen nicht befolgen, übernehmen wir keine Garantie. Darüber hinaus können Bedienungsfehler ein Sicherheitsrisiko darstellen.
- Die Daten der elektronischen Navigationskarten können aufgrund von Aktualisierungen der Verkehrssituation nicht mit den tatsächlichen Verkehrssignalen übereinstimmen. Bitte fahren Sie nach der aktuellen Straßensituation, folgen Sie den Verkehrsvorschriften und Schildern.
- Der Betrieb des GPS-Navigationsgeräts während der Fahrt konnte zu schweren Unfällen führen. Bitte verkürzen Sie Ihre Zeit bei der Bedienung des Navigators oder machen Sie die Vorarbeit vor der Verwendung gut, z.B. Adressen eingeben, Einstellungen ändern oder andere Funktionen verwenden und benutzen Sie die Sprachansage Funktion.
- Bitte machen Sie eine Sicherungskopie für die GPS-Software und Daten des GPS-Navigators. Wir übernehmen keine Verantwortung für Schäden, die durch Software-Beschädigung und/oder Datenverlust verursacht werden. Wenn Sie Fragen mit Software haben, senden Sie bitte eine E-Mail an **customersupport@naviprovip.com**. Wir helfen Ihnen, es zu klären.
- Das Gerät verfügt über eine 1-Jahres-Garantie. Alle Garantien werden von Menschen verursachten Schäden ausgeschlossen.
- Rechnung: Wenn Sie eine Rechnung benötigen, senden Sie uns bitte eine Nachricht im Online-Shop, senden wir Ihnen eine im PDF-Format. Bitte teilen Sie uns den Rechnungstitel mit und welche E-Mail-Adresse wir senden sollten.
- Der Inhalt des Handbuchs ist auf Richtigkeit und Konsistenz überprüft. Sollte dennoch ein Fehler gefunden werden, senden Sie uns bitte eine E-Mail an **customersupport@naviprovip.com**, oder besuchen Sie unsere offizielle Website **www.naviprovip.com**. Finden Sie unseren Kundendienst und lassen Sie uns einfach eine Nachricht, antworten wir Ihnen innerhalb 24 Stunden. Vielen Dank!

Vor der Benutzung

Komponente	Erläuterung
Netzschalter	Ein/ Aus und Ruhenodus
Lautsprecher	Abspielen vom Ton (z.B.Navigationstöne, Musik usw.)
Resetloch	Zur Werkseinstellung drücken
Kopfhörerbuchse	Verbinden mit dem Kopfhörer
TF-Kartensteckplatz	T-Flash-Karte einlegen
MINI USB-Anschluss	Mit PC über Mini-USB-Kabel verbinden oder als Ladeanschluss verwenden
Anzeige	Anzeige des Betriebszustandes mit externer Stromversorgung

Die Hauptfunktionen sind wie folgt aufgeführt.

Funktion	Erläuterung
Navigation	Tippen Sie darauf, um die Navigationsfunktion zu aktivieren
FM Sendung	Zur FM Funktion
Musik	Unterstützte MP3-und WAV-Dateien; Zufalls-, Sequenz-und Zyklus Wiedergabe unterstützt

Funktion	Erläuterung
GPS Infos	Anzeige von GPS-Informationen und Signalstatus
Werkzeug	Funktion von Rechner und Einheitenkonverter anzurufen
Einstellung	Einstellung für Lautstärke, Helligkeit, Sprache, Datum/Zeit, USB, System Infos, Werksreset und Navi Weg.
Multimedia	Unterstützte WMV-, ASF-und AVI-Dateien

Stromversorgung und Aufladung

Das GPS kann durch die eingebaute Batterie oder externe Stromversorgung angetrieben werden. Wenn der GPS-Navigator nicht mit dem Ladegerät verbunden ist, wird er von der Li-Polymer-Batterie mit Strom versorgt. Wenn der GPS-Navigator an das Ladegerät angeschlossen ist (Auto-Ladekabel und Mini USB-Kabel enthalten), wird es von externer Stromversorgung gespeist und die Batterie wird gerade geladen.

[Hinweis]

- 1) Wenn Sie den GPS-Navigator einschalten, müssen Sie den Netzschalter für 3-5 Sekunden drücken.
- 2) Laden Sie den GPS-Navigator vor dem ersten Gebrauch mit dem Ladegerät vollständig auf. Schließen Sie ein Ende des Auto-Ladegeräts an den USB-Port des GPS-Navigators an, das andere Ende an den Ladeanschluss der Stromquelle.

[Achtung!] Beachten Sie bitte, wenn Sie das GPS aufladen,

indem Sie es an den Computer mit dem USB-Kabel anschließen, wird es sehr langsam aufgeladen (oder in diesem Fall nicht geladen wird). So ist es am besten, die Navigation aufzuladen, indem Sie das USB-Kabel mit einem AC-Adapter (Netzteil für Ihr Handy oder andere Elektronik) verbunden haben.

- 3) Die Ladeanzeige leuchtet während des Ladevorgangs in Rot. Ziehen Sie das Ladegerät nicht ab, bis die Kontrollleuchte grün leuchtet und das Ladesymbol zeigt immer voll und mit einem Blitzsymbol an, was darauf hinweist, dass die Batterie vollständig aufgeladen ist. Bitte laden Sie den GPS-Navigator rechtzeitig, wenn der Akku fast leer oder verbraucht ist.

[Achtung!]

Wenn die Navigation nicht an das Ladegerät angeschlossen ist, leuchtet die Kontrollleuchte immer grün. Wenn das Navigationssystem mit dem Ladegerät verbunden ist und das Licht rot leuchtet, beweist dies, dass das Navi aufgeladen wird.

- 4) Um Schäden durch Stromstöße zu vermeiden, schließen Sie das Auto-Ladegerät nach dem Start des Fahrzeugs an. Das Navi hat normalerweise eine Akkulaufzeit in 20-45 Minuten. Wir schlagen Ihnen daher vor, das Navi mit Autoladekabel während langer Fahrt zu benutzen.
- 5) Wenn die Stromversorgung unterbrochen wird, zeigt das GPS einen Screenshot an, um zu fragen, ob Sie das Gerät herunterfahren wollen. Wenn Sie keine Optionen auswählen, schaltet sich das Gerät automatisch nach 10 Sekunden aus.
- 6) Falls Ihr Gerät sich nicht aufladen lässt, setzen Sie es zuerst

zum Werkstand zurück (Detaillierte Methode lesen Sie bitte die Anweisungen dieses Handbuchs von "Werkeinstellung vom GPS-Gerät" durch). Dann lassen Sie ihn bitte ruhig 6-8 Stunden aufladen. Wir haben da die folgenden Vorschläge: Benutzen Sie das Gerät bei der Aufladung bitte nicht. Probieren Sie, den Artikel mit dem Autoladekabel und USB-Kabel aufladen zu lassen. Falls das Gerät sich noch nicht aufladen lässt, senden Sie uns bitte eine Nachricht und werden wir Ihnen weitere Lösung zugeben.

[Achtung!]

Der GPS-Navigator übernimmt eine interne und nicht entfernbare Li-Polymer-Batterie an. Um Batteriebruch, Explosion oder Verbrennungen zu vermeiden, entpacken Sie die Batterie nicht und entsorgen Sie sie nicht in Feuer oder Wasser, auch nicht durchbohren oder anschlagen.

Montage der Halterung

Schauen Sie bitte das Video (**Video-Name: Bracket Installation**) auf unsere Webseite: www.naviprovip.com → klicken "Downloads" → klicken "Videos".

Einstellung der Sprachen

Falls die Standardsprache in Englisch ist, können Sie die Sprache zuerst ins Deutsch umstellen. So fällt es Ihnen leicht, das GPS zu bedienen. Oder schauen Sie das Video (**Video-Name: Language Setting**) auf unsere Webseite: www.naviprovip.com → klicken "Downloads" → klicken "Videos"

1) Systemsprache: Hauptmenü → klicken "Setting" → klicken