

65mmX85mm

JM28

Instructions for use
Please read the instruction manual in advance to facilitate subsequent use

Product Parameters

Product Name

Bluetooth version

Transmission distance

Horn diameter

Charging port

Sensitivity

Charging case battery

Headphone battery

Charging time (charging box)

Charging time (headphones)

Play time (headphones)

Standby time (headphones)

JM28

6.0

10M

Φ6mm

Type-C

114.5± 3dB

3.7V 300mAh

3.7V 30mAh

1.5-2H

1H

5H

30H (No connection)

Packing List

True wireless Bluetooth headset

Headphone charging case

Type-c Charging cable

manual

*2

*1

*1

*1

Operation Instructions

1.Basic description

1 Indicator light

2 Touch area

3 Breathable hole

4 Display

5 Type-C charging port

6 Screen switch

2. Download and use of APP

Scan the QR code to download the AI EarLink software

Bluetooth pairing

step one

Open the top cover of the charging compartment and the headphones will automatically turn on.

Step 2

Turn on your phone's Bluetooth and search for the device name: JM28

First time pairing

1. Open the charging compartment cover, and the headphones will automatically power on and enter the pairing state.

2. Open Bluetooth on your phone and search for the device name: "JM28", select it and connect.

Connect again

After pairing for the first time, you only need to open the lid of the charging compartment to reconnect again, and it will automatically reconnect.

*The above operations ensure that the product charging compartment is powered on.

Operating Instructions

1. Turn on and off the machine

Earphones on and off

Power on: Press and hold the headset touch function button for 3 seconds (headphone prompt tone: TONE sound) Indicator light: white and green lights flash alternately
Shut down: Press and hold the headset touch function button for 5 seconds (headphone prompt sound: TONE sound)Indicator light: white light flashes 3 times and turns off)

Display switch

Power on: Press and hold the button for 3 seconds to start the screen;
Shut down: Press and hold the button for 5 seconds, the shutdown interface will pop up, click to shut down

2. Mode selection

Phone Mode

Reject incoming calls: Long press for 2s
Incoming call: Click answer, then click Hang off

Music mode

Left ear double touch: Play the previous song
Touch the right ear: Play the next song
One Touch: Play/Pause

Ear mode

Three touches on the left ear: volume down
Three touches of the right ear: volume increases
Wake up SIRI: Press and hold for 1.5S

3. Screen instructions

Language settings

Swipe up or down to select the appropriate language and click to complete the switch.

Stopwatch

Can set duration or reset

calendar

Connect to mobile phone Bluetooth and automatically synchronize

Photograph

When the headset is connected to the Bluetooth of the mobile phone, you can control the mobile phone to take pictures by clicking on the camera icon.

Make a call

You can make calls while connected to Bluetooth

voice assistant

Click the icon to wake up the voice assistant

menu style

Provides 3 theme styles

wallpaper

Swipe left or right to switch wallpapers

equalizer

Available in 7 styles

music interface

Click the icon to play/pause and switch between previous and next song

volume

Volume increase/decrease

reset

Swipe right to reset

Shut down

Swipe right to shut down

Restart

Swipe right to restart

music mode

Music mode and game mode

Call reminder

Incoming calls can remind and display the number

Positioning function

Click to search for headphone location

flashlight

Click to light up the screen

Things to note

Hint

1. Please read this instruction manual carefully before using the product and keep it properly
2. For the first time, please fully charge this product first
3. If the product is not used for a long time (more than 1 month), please charge it
4. If the phone cannot search for Bluetooth headsets, please confirm whether the Bluetooth headset is in the "pairing state". If the pairing or connection is not performed for a long time, the Bluetooth headset pairing function will be turned off. Please turn on the Bluetooth headset to "pairing state". If the mobile phone program is wrong, please restart the phone: If the Bluetooth headset program is wrong, please restart the Bluetooth headset.

Warn

1. Do not remove or modify the headphones for any reason, otherwise it may cause ignition electronic components to break down or even completely damage this product. 2. Do not place the equipment at a temperature that is too low or too high (below 0°C or above 45°C). In the environment 3. Please avoid using the equipment indicator light near the eyes of children or animals 4. Please do not use the equipment in thunderstorms, as the equipment may not work properly. and increase the risk of electric shock
5. Do not wipe this product with oil or other volatile liquids.
6. Do not wet the device when it comes into contact with liquid

Warranty information

FCC WARNING: This equipment may generate or use radio frequency energy. Changes or modifications to this equipment may cause harmful interference unless the modifications are expressly approved in the instruction manual. The user could lose the authority to operate this equipment if an unauthorized change or modification is made.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
• The rating information is located at the bottom of the unit.

QUALIFIED CERTIFICATE

MODEL:

CHECKER:

DATE:

QC PASS

檢08

Model: JM28

FCC ID:2BBNW-JM28

Made in china