







802.11ax-40 MHz / 5965 MHz / Chain A




802.11ax-40 MHz / 5965 MHz / Chain B




802.11ax-40 MHz / 6205 MHz / Chain A




802.11ax-40 MHz / 6205 MHz / Chain B




802.11ax-40 MHz / 6405 MHz / Chain A




802.11ax-40 MHz / 6405 MHz / Chain B




802.11ax-40 MHz / 6445 MHz / Chain A




802.11ax-40 MHz / 6445 MHz / Chain B




802.11ax-40 MHz / 6485 MHz / CH107 2Tx TX0




802.11ax-40 MHz / 6485 MHz / Chain B




802.11ax-40 MHz / 6565 MHz / CH123 2Tx TX0




802.11ax-40 MHz / 6565 MHz / Chain B




802.11ax-40 MHz / 6725 CH155 2Tx TX0




802.11ax-40 MHz / 6725 MHz / Chain B




802.11ax-40 MHz / 6845 MHz / Chain A




802.11ax-40 MHz / 6845 MHz / Chain B




802.11ax-40 MHz / 6925 MHz / Chain A




802.11ax-40 MHz / 6925 MHz / Chain B




802.11ax-40 MHz / 7005 MHz / Chain A




802.11ax-40 MHz / 7005 MHz / Chain B




802.11ax-40 MHz / 7085 MHz / Chain A




802.11ax-40 MHz / 7085 MHz / Chain B




802.11ax-80 MHz / 5985 MHz / Chain A




802.11ax-80 MHz / 5985 MHz / Chain B




802.11ax-80 MHz / 6225 MHz / Chain A




802.11ax-80 MHz / 6225 MHz / Chain B




802.11ax-80 MHz / 6385 MHz / Chain A



802.11ax-80 MHz / 6385 MHz / Chain B



802.11ax-80 MHz / 6465 MHz / Chain A



802.11ax-80 MHz / 6465 MHz / Chain B