




Portable Wireless BT Speaker
Model: ST100
User Manual

Important Safety Information

- Please read this manual carefully and keep it for future reference.
- Use the product as instructed in this manual.
- Recommended operating temperature: 0-40°C.
- To prevent children from accidentally swallowing accessories (e.g., lanyard), keep them out of reach of children.
- This product is not a toy. Children under 14 years old must use it under adult supervision.
- Do not attempt to disassemble or replace any parts inside the product unless specifically instructed in this manual.
- Do not submerge the product in water or any other liquid. This product is not waterproof.
- If any liquid accidentally enters the product, disconnect it immediately and remove it from use.
- To avoid electric shock, ensure your hands are dry when installing or removing the product.
- Do not place the product near heat sources or expose it directly to open flames.
- Do not place the product in environments with strong electromagnetic fields, as this may cause malfunction.
- Before cleaning the product with a dry cloth, ensure it is powered off.
- Do not use strong acids, strong alkalis, gasoline, alcohol, or other chemical solvents to clean the surface. Use a neutral solvent or water if necessary.
- Ensure the operating voltage matches the local supply voltage before using the product. The operating voltage is shown on the product label.
- If the product is unused for an extended period, the battery may discharge. Please recharge the product promptly.
- Excessively high volume during use may damage hearing. Adjust the volume to a safe level.
- Dispose of electronic waste properly. Do not discard electronic devices, components, or batteries with household trash. To prevent pollution and harm to humans caused by hazardous substances, and to ensure resource recycling, follow local laws and regulations for disposal and recycling of this product.

Package Contents

Speaker x1	Type-C Charging Cable x1
Lanyard x1	User Manual x1

Product Specifications

Product Name: Portable Wireless BT Speaker
Model: ST100
Product Dimensions: 70x50 x 50 x 135mm
Product Weight: 115g
BT Version: V5.4
Effective Range: ~10m
Speaker Diameter: 30mm
Frequency Response: 20Hz-18kHz
Lithium Battery Rated Capacity: 3.7V / 400mAh
Output Power: 5W
Charging Time: ~3 hour
Playback Time: ~3 hours
Waterproof Rating: IPX7

Product Diagram

- Type-C Charging Port
- Increase Volume / Next Track
- Decrease Volume / Previous Track
- Power On/Off

Buttons and Functions

- Long press for 3 seconds: Power On/Off
- Short press: Play/Pause
- Double press: TWS Pairing
- Long press for 3 seconds: Next Track
- Short press: Increase Volume
- Long press for 3 seconds: Previous Track
- Short press: Decrease Volume

When not using the speaker, long press the **Power On/Off** button to power off and prevent battery drain.

Low Battery Alert and Auto Power-Off Function:
When the battery level is below 10%, the speaker will emit a warning tone. At this point, the speaker should be charged promptly.
When the battery level drops below 2%, the speaker will automatically power off.

Product Operating Instructions

- BT Mode**
 - Turn on the speaker: Long press the **Power On/Off** button for about 3 seconds to power on, and a prompt tone will sound.
- BT Connection**
 - Open the Bluetooth settings on your smart device, search for the BT name "ST100", and click to connect. A prompt tone will sound when the connection is successful.
 - When using the speaker again, device previously connected to this BT will automatically reconnect. If you need to connect a new device to the speaker, please disconnect the BT on the original device before connecting.
- TWS Mode**
 - With any two identical speakers powered on, double press the **Power On/Off** button on one of the speakers to enter "TWS pairing" mode. The TWS connection will be established within 15 seconds, and a prompt tone will sound upon successful connection.
 - Double press the **Power On/Off** button on either speaker to exit TWS mode.
- Indicator Light Status**
 - Charging Indicator:** The red light stays on during charging, and the red light turns off when fully charged.

Common Problems and Solutions

Problem	Solution
Indicator is lower red	Check if the battery level of the speaker is charged.
Not high playing strength	Turn off the speaker and restart it.
Not play back music	Make sure the Bluetooth connection is correct. If the connection is not successful, please restart the speaker and the device.
Not sound during playback	Check if the speaker is set to the correct volume.
Power indicator light is on	Check if the charging port is properly connected.



ポータブルワイヤレスBTスピーカー
モデル: ST100
取扱説明書

重要な安全情報

- 本取扱説明書をよくお読みいただき、大切に保管してください。
- 取扱説明書に従って正しく設置し、ご使用ください。
- 本製品は0-40°Cの範囲での使用を推奨します。
- 付属品（ストラップなど）をお子様が誤って飲み込まないよう、付属品を子供の手の届かない場所に保管してください。
- 本製品はおもちゃではありません。14歳未満のお子様は、必ず大人の監督のもとで使用してください。
- 取扱説明書に特別な指示がない限り、本製品の部品を分解したり交換したりしないでください。
- 本製品を水やその他の液体に浸さないでください。本製品は防水仕様ではありません。
- 万一水や液体が製品内部に入った場合は、直ちに電源を解除し、製品を使用から外してください。
- 故障を防ぐため、製品を取り付けた取り外しする際は、手が濡れていないことを確認してください。
- 本製品を乾燥の速く直接日光にさらされる場所に置かないでください。
- 強い電圧が発生する環境に本製品を置かないでください。それにより製品が故障する可能性があります。
- 本製品を取り扱うた中で、清掃する際に必ず電源をオフにしてください。
- 清潔な柔らかい布、中性洗剤または水を使用して清潔にしてください。
- 製品を解体する前に、動作電圧が地域の電源電圧と一致していることを確認してください。誤った使用は製品の性能に悪影響を及ぼします。
- 長期間使用しない場合、製品のバッテリーが放電する可能性がありますので、適時に充電してください。
- 使用中に音量が大きすぎると、聴覚に障害を与える可能性があります。音量を安全なレベルに調整してください。
- 本製品は電子機器と近接して使用しないでください。電子機器、部品、バッテリーを一度廃棄物と一緒に廃棄しないでください。有害物質による自然環境の汚染や人体への被害を防ぐため、資源のリサイクルを確保するため、廃品回収や地域の法律・規制に従って本製品を処分してください。

梱包内容

スピーカー x1	Type-C充電ケーブル x1
ストラップ x1	取扱説明書 x1

製品仕様

製品名: ポータブルワイヤレスBluetoothスピーカー
モデル: ST100
製品サイズ: 70 x 50 x 50 x 135mm
製品重量: 115g
BTバージョン: V5.4
有効範囲: ~10m
スピーカー直径: 30mm
再生出力: 5W
充電時間: ~3時間
再生時間: ~3時間
防水性能: IPX7

製品図解

- Type-C充電ポート
- 音量アップ / 次の曲
- 音量ダウン / 前の曲
- 電源オン/オフ

ボタンと機能

- 3秒押し: 電源オン/オフ
- 1秒押し: 再生一時停止
- ダブルクリック: TWSペアリング
- 3秒押し: 次の曲
- 1秒押し: 前の曲
- ダブルクリック: 音量アップ

スピーカーを誤作動しない場合は、**電源オン/オフ**ボタンを長押しして電源をオフにし、電力消費を減らしてください。

低電力警告および自動電源オフ機能:
残電力レベルが10%以下になると、スピーカーが警告音を発します。この場合、速やかに充電してください。
残電力レベルが2%以下になると、スピーカーは自動的に電源をオフにします。

製品操作説明

- BTモード**
 - Bluetoothモードをオンにする: **電源オン/オフ**ボタンを約3秒押し、電源が入り、音楽音が再生されます。
- Bluetooth接続**
 - スマートデバイスのBluetooth設定を開き、デバイス名"ST100"を検出して接続をクリックしてください。接続が成功すると音楽音が再生されます。
 - 再度このスピーカーを使用する際は、接続解除を完了して再度接続する必要があります。新しいデバイスと接続する場合は、必ずBluetooth設定をオンにしてください。
- TWSモード**
 - 任意の2つのスピーカーを充電状態で起動し、いずれか1つのスピーカーの**電源オン/オフ**ボタンをダブルクリックすると、TWSペアリングモードに入ります。15秒以内にTWS接続が成功し、音楽再生が開始されます。
 - いずれか1つのスピーカーの**電源オン/オフ**ボタンをダブルクリックすると、TWSモードを終了できます。
- インジケータライトの状態**
 - 充電インジケータライト: 充電中は赤いランプが点灯し、充電完了後は赤いランプが点滅します。

よくある問題と解決方法

問題	解決方法
電源が入らない	スピーカーの電源ボタンを約3秒押し、電源が入るまで待ちます。
音楽が再生されない	Bluetooth設定を確認し、正しいデバイスに接続されていることを確認してください。
音楽再生が途切れる	Bluetooth接続が安定していることを確認し、必要に応じて再接続してください。
音楽再生が途切れる	Bluetooth接続が安定していることを確認し、必要に応じて再接続してください。
音楽再生が途切れる	Bluetooth接続が安定していることを確認し、必要に応じて再接続してください。

365mm

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.