

User Instructions

SecuroSmart keypad

The following conditions are needed to add the SecuroSmart Keypad system:

- The LED on the fingerscanner must shine when connecting the door to a power supply.
- You must have the Pirnar app installed on your phone.

DOWNLOADING THE PIRNAR MOBILE APP - You can download the Pirnar app two ways:

- 1 Scan the QR code on the door's control panel.


Search for "Pirnar" on Google Play or the App Store.

First Startup: Upon the first connection of the entrance door to the electrical power supply, the SecuroSmart and SecuroSmart Keypad systems are automatically set to DEMO mode. This mode is indicated by a blue illumination around the reader.

Purpose of DEMO mode: In DEMO mode, the door can be unlocked with any fingerprint, allowing easy verification of the system's functionality after installation and electrical connection. This mode is intended exclusively for testing and is not suitable for regular use.


Switching to safe operating mode: After successfully adding the device to the PIRNAR app, the reader illumination changes to white, indicating that the system is ready for safe use. From this point on, the door can only be unlocked with authorized fingerprints and/or numeric codes added by the user through the app.






ADDING THE SECUROSART KEYPAD KEYPAD TO THE PIRNAR APP:

- 1 On the control unit, press and hold the reset button, then simultaneously press the power button. Release the power button while continuing to hold the reset button.
- 2 The keypad will count down from five to one. A successful factory reset is confirmed by a blue light on the reader.
- 3 Press number 8 and the green arrow. The SecuroSmart Keypad is now in pairing mode and can be detected and added to the PIRNAR app.





ADDING THE DOORBELL (INDOOR UNIT)

2.4

DEUTSCH

ENGLISH

FRANÇAIS

ITALIANO

SLOVENSKO

1 Plug the doorbell into a socket. Press and hold the pairing button until the LED indicator lights up blue.


2 On the keypad, press and hold the doorbell button.

3 Successful pairing of the doorbell and keypad is confirmed by a light and sound signal.

1



2




3



REMOTE ACCESS



- 1 Connect the Wi-Fi Bridge device, included with every door, in order to activate remote access. Wi-Fi Bridge must be kept in the same space as the door, at a maximum of 10 meters away.

Insert the included micro USB cable into the device. Plug the other end into the power supply. Plug the power supply into the wall outlet.



ADDING WI-FI BRIDGE

- 2 Click on "Add Device" + in the top right corner of the Pirnar app.
- 3 Wait for the app to find a device and click ADD, or choose Others (BLE) manually and follow the in-app instructions.



* PIRNAR'S ADVICE:





- Just rest your finger on the reader without sliding it around.
- The same administrator should save more than one fingerprint. We recommend allocating admin rights and fingerprints to more than one person. This will ensure that you will always have access to your device even when unpredictable circumstances arise (e.g. death in the family, new owner, divorce, etc.).



4 If a device was not found automatically, check whether the red LED is blinking slowly. If the red LED is not blinking, press and hold the device button for 5–10 seconds until the red LED begins blinking slowly.

5 Click the + symbol and add the Wi-Fi password (the device only supports 2.4 GHz Wi-Fi networks), then click “next”.

6 Confirm the added device or rename it if you prefer.







CONNECTING THE SECUROSMART KEYPAD WITH ADDED FUNCTIONS (E.G. ALEXA, GOOGLE ASSISTANT, SIRI, REMOTE ACCESS, ETC.)

- 1 Choose "Add Device".
- 2 Select the already added SecuroSmart Keypad.

- 3 Confirm all prompts.

- 4 Your device was added.
- 5 Control the device from the home menu.



SHARING THE DEVICE WITH OTHER USERS






The admin can share the device with other users who have the Pirnar app installed on their phone and a valid user account.

Sharing a device:



1 In the home menu, choose the "Profile" menu and then "Home Management".

2 Choose the default property "My Home".


3 Name the property and assign it a location – this will allow the app to give you information about the weather at your chosen location. If you want, select or add rooms in your home.





- 4 Choose "Add family member" and select the option "App Account".



- 5 Enter the required information.
Click on the "User rights" menu to set whether the new user is an admin or regular user.



- 6 Admins can change device settings, add new users, and add fingerprints.
Regular users can only track the log of unlocking and other history.



- 7 Click "Save" after entering all the information.

The user whose account you entered will receive an invitation to access your home through their app. When they confirm, they will receive permission to access the devices in your house within the scope of the rights you allocated to them.



UPDATING THE SECUROSMART KEYPAD

SecuroSmart Keypad supports OTA (over-the-air) updates. Whenever a new version is released, you will receive a notification the next time you open the app.

If your SecuroSmart Keypad is connected to Wi-Fi Bridge, then you must disconnect it from its power supply and turn on Bluetooth on your phone. The software will not update otherwise!




- 1 When you receive the update notification, select "Update Now".
- 2 Select "Update".
- 3 Select "Start Update".
- 4 Wait for the update to download. Do not use your phone during this time.

After updating the software, you can reconnect the Wi-Fi Bridge to the power supply and your SecuroSmart Keypad will automatically connect to it.



CHECKING YOUR SOFTWARE VERSION

- 1 Click the ellipsis symbol on the home menu for more options.
- 2 Select "Device Update".
- 3 This screen will show you what software version you currently have installed, as well as whether new versions are available.



APP FEATURES

The app provides you with a range of useful features:

- Sharing the device with other users
- Remote unlocking – to activate remote unlocking, you must add Wi-Fi Bridge to your app.
- Activity monitoring – use the app to see who enters your home and when
- Log of openings
- Emergency entering fingerprints
- Log of unsuccessful opening attempts

COMPATIBILITY WITH OTHER SMART HOME SOLUTIONS

The Pirnar app supports several smart solutions and assistants:

- Google Assistant
- Apple Siri
- Apple Watch
- Amazon Alexa

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

ISED Caution:

This device complies with ISED license-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device."

« Le présent appareil est conforme aux ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. »

Radiation Exposure statement

This equipment complies with FCC/ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator and your body.

Cet équipement est conforme aux limites d'exposition aux radiations FCC/ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec une distance minimale de 20 cm entre le radiateur et votre corps.