



MARSHALL.COM

Marshall

STOCKWELL III
PORTABLE LOUDSPEAKER


QUICK START GUIDE

GETTING STARTED



1. PRESS THE POWER BUTTON UNTIL THE SPEAKER TURNS ON.
2. PUSH AND HOLD THE BLUETOOTH BUTTON UNTIL THE LED TURNS TO A SLOW PULSE.
3. SELECT STOCKWELL III FROM YOUR SOUND DEVICE'S BLUETOOTH LIST.
4. DOWNLOAD THE MARSHALL APP AND FOLLOW THE IN-APP INSTRUCTIONS TO COMPLETE THE SETUP.

TOP PANEL



- 1. BLUETOOTH BUTTON**

Push and hold the Bluetooth button until the LED turns to a slow pulse to start pairing mode.
- 2. POWER BUTTON**

Press the power button to turn the speaker on or off.
- 3. BATTERY INDICATOR**

The five-segment battery indicator displays the battery charge.
- 4. AUDIO CONTROLS**

STOCKWELL III includes three controls for adjusting audio.
- I. Volume control

II. Bass control

III. Treble control
- 5. CUSTOMISABLE M-BUTTON**

Push the M-button to switch between EQ settings. The function of the M-button can be customised in the Marshall app.
- 6. MEDIA CONTROL**


Control the audio directly from the top panel when playing via Bluetooth:

I. Push once to play/pause

II. Push right/left to skip forwards/back

III. Hold right/left to fast forward/rewind.

SIDE PANEL




- 1. USB-C POWER INPUT/OUTPUT**

Charge the speaker by plugging it into a USB power source or plug in a USB-C device and use the speaker as a charging bank.
- 2. AUX 3.5 MM AUDIO INPUT**

Plug in an audio device with an analogue output via a 3.5 mm lead.
- Download the Marshall app to get the most out of your speaker. The full user manual is available in the app or at marshall.com

STRAP ATTACHMENT



- I. POSITION THE HOLE IN THE CARRY STRAP OVER THE PIN ON THE SIDE OF THE SPEAKER.
- II. GENTLY THREAD THE STRAP AROUND THE PIN UNTIL IT IS SECURE.
- III. REPEAT THE PROCEDURE ON THE OPPOSITE SIDE OF THE SPEAKER.
- Note: Make sure the carry strap is secured to the speaker on both sides before use.



All intellectual property in the product and packaging (including the Marshall trade mark, copyright, designs, and patents) are owned by Marshall Group AB and may not be used without permission. All rights reserved. The Bluetooth® wordmark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Marshall Group AB is under license. Google Play is a trademark of Google LLC. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Marshall Group AB, Centralplan 15, 111 20 Stockholm, Sweden. R1.0