



成品尺寸：70x100mm 80g书纸 单色印刷 风琴折



使用指南
User Guide

- 产品概述



- 1.LED灯
- 2.触摸位置
- 3.副麦
- 4.喇叭
- 5.通话主麦
- 6.充电触点

- 耳机功能操作说明


- 开机配对：手动模式则长触摸功能键2秒；自动模式仓内开盖取出开机，绿/白交替并有语音提示。
- 关机：手动模式则长触摸功能键6秒；自动模式耳机入仓合盖关机，白灯闪亮并有语音提示。
- 播放/暂停音乐：单击左耳或右耳多功能触摸键。
- 对耳配对完成：主耳绿/白交替，从耳绿灯闪亮。
- 重新连接：开机回连/回到有效距离，并有语音提示。

- 蓝牙耳机

- 接听电话：短触功能键。
- 挂断电话：短触功能键。
- 拒绝接听：长触功能键。
- 语音助手：长触左功能键松手。
- 游戏/音乐模式：长触右功能键松手，绿呼吸灯/-并有语音提示。
- 音乐播放/暂停：短触功能键。
- 上/下一曲：双击左功能键上一曲；双击右功能键下一曲。
- 音量调整：三击左功能键音量减；三击右功能键音量加，最大音量“嘟嘟”提示音。
- 恢复出厂：配对状态下四击功能键。
- 充电盒充电：充电时，屏百分比闪亮；充满时，屏百分比长亮，充满约2小时。
- 充电盒给耳机放电：仓显电量及跑马耳机绿灯长亮；耳机充满电，耳机指示灯与仓显示全熄灭，充满约2小时。

- 蓝牙配对

1.打开充电仓，取出耳机自动开机；请将蓝牙耳机和手机（或其他连接设备）的距离在 50CM的范围内，越近越好。




2.开启用户手机蓝牙功能（或其他蓝牙设备），进行搜索或扫描，此时手机会搜索到附近所有的蓝牙设备，点选搜索

- 规格参数

- 名称：蓝牙耳机
- 型号：
- 连接范围：≥10m
- 蓝牙版本：V5.3
- 耳机电池容量：30mAh*2
- 充电仓电池容量：330mAh

- 注意事项

- 切勿使用具有腐蚀性的清洁剂清理本产品。
- 切勿让本产品加热或靠近火源，如煮食炉。
- 切勿让本产品长时间受阳光直接照射。
- 切勿将本产品弃置于火中，避免发生爆炸。
- 切勿尝试拆开本产品作出任何修改，因为它并不包含任何维修组件。
- 切勿在雨中使用本产品。
- 如果长时期内不打算使用本产品，请您将它储存在干燥的环境中，并每月至少为耳机充电一次以延长寿命，避免极端的温度和灰尘。



1.LED light

2.Touch position

3.Accessorial wheat

4.Horn

5.Call main microphone


6.Charging contact

- Product Overview

- Refuse to answer: long touch the function key.
- Voice assistant: long touch the left function key to release.
- Game/music mode: long touch the right function key to release, green breath light/- and voice prompt.
- Music play/pause: short touch the function key.
- Previous/next song: Double click the left function key to previous song; Double click the right function key Next Song.
- Volume adjustment: cick the left function key three times to decrease the volume; Click the right function key three times to increase the volume, and the maximum volume "beep" prompt tone.
- Restore to factory: Four cick the function key under pairing status.
- Charging of charging box: the percentage of screen flashes during charging; When fully charged, the screen percentage will stay on for about 2 hours.
- The charging box discharges the earphones: the green light of the compartment display and the horse racing earphones is always on; The headset is fully charged, the headset indicator light and the compartment display are off, and the headset is fully charged for about 2 hours.

- Bluetooth pairing

1.Open the charging chamber, take out the headset and start it automatically; Please keep the distance between the Bluetooth headset and the mobile phone (or other connecting devices) within 50CM, the closer the better.



2. Enable the user's mobile phone Bluetooth function (or other Bluetooth devices) to search or scan. At this time, the mobile phone will search all nearby Bluetooth devices, and click Search



Search headset



Connection succeeded

- Specifications

- Name: Bluetooth headset
- Model
- Connection range: ≥ 10m
- Bluetooth version: V5.3
- Battery capacity of headset: 30mAh * 2
- Battery capacity of charging chamber: 330mAh

- Matters needing attention

- Do not use abrasive cleaners to clean this product.
- Do not allow this product to be heated or close to a fire source, such as a cooking stove.
- Do not expose the product to direct sunlight for a long time.
- Do not discard this product in fire to avoid explosion.
- Do not attempt to disassemble this product to make any modifications, as it does not contain any maintenance components.
- Do not use this product in rain.
- If you do not plan to use this product for a long time, please store it in a dry environment and charge the headset at least once a month to extend its life and avoid extreme temperatures and dust.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.