











Fdceligoo Dog training collar anti bark collar User Manual  Fdceligoo is designed to cultivate pet's good habits, not to punish them. Please do not overuse this product on pets. NOTE: Please read the user guide before using this product and keep the user guide properly.	Content Components Page 3 Product Description Page 4-5 Important Safety Information Page 6 Operating Guide Page 7-13 Main Features Page 14 How to Use of Test Light Tool Page 15 Training Tips Page 16 Pairing Instructions Page 17 Troubleshooting Page 18-22 Operating Environment & Maintenance Page 23	Components Handheld Remote Receiver Charging Cable Wrist Strap Screwdriver Test Light Tool Long Contact Point Conductive Silicone Cap	Product Description Handheld Remote Digital Display Beep Tone Adjustable Vibration Electric Shock Shock Boost Channel Display (1-4) Vibration Level (1-8) Sensitivity Level (1-8) Shock "+" Shock "-" Keypad Lock Screen Content Beep Vibration Static Keypad Lock Channel Display (1-4) Static Level Display (00-99) Battery Status (Remains)	Product Description Receiver Colorful Screen Contact Point Sensitivity ON/OFF Mode Switch	Important Safety Information WARNING Not for aggressive dogs. Do not use this Product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others if you are unsure whether this product is appropriate for your dog. Please consult your veterinarian or certified trainer. CAUTION Please read users manual carefully before using to avoid injury caused by improper use. Proper fit of the collar is important. A collar that is too long or made too tight on the pet's neck may cause skin damage. Ranging from redness to pressure ulcers, which is commonly known as bed sores. Avoid leaving the receiver on the dog for more than 12 hours per day. When possible Reposition the receiver on your dog's neck every 1-2h. Check the fit to prevent excessive pressure. Follow the instructions in this manual. Never connect a leash to the electronic collar; it will cause excessive pressure on the contacts. When using a separate collar for a leash, don't put pressure on the electronic collar. If a rash or sore is found, discontinue use of the collar until the skin has healed. Don't use an Adapter with the output greater than 5V1A to charge. Avoid contact with other metals while charging, as it may cause a short circuit. CAUTION Safety during on-leash training. It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase. This pet training device is not a toy, keep away from children.
Operating Guide Charging Instructions(2h charging time): When charging is completed, the white light will appear. Charge takes two hours respectively.  Wearing Instructions: The dog collar is between 8 inches-27 inches. Please adjust the collar and modes before putting it on the dog neck. 1.Adjust the dog collar length, make sure it fits your dog well. 	2.Insert the extra collar into the slider. If too long, you can cut parts and turn the end of the collar to avoid fraying.  3.Wear it on the dog's neck, put two fingers to test and adjust to the proper tightness.  CAUTION 1. The Contact Points must have direct contacts with dog's skin on the underside of neck. When properly fitted, you should be able to put a finger in between the Receiver Collar and dog's neck. Too loose: The receiver collar will move around the dog's neck. As a result, the dog may not respond well to the command while the contact points may hurt the dog's skin. Too tight: It may cause the dog breathing hard. 2. Do not shave the pet's neck as this may increase the risk of skin irritation. 3. The collar should not be worn for more than 12 hours per day. Or it may cause skin irritation.	3.Switch description of transmitter and Receiver: Turn ON the Receiver. Hold the M button for 1 seconds. Turn OFF the Receiver. Hold the M button for 2 seconds.  4.Switch lock description: Security Keypad: Lock or Unlock. 	5.Explanation of voice mode: Beep command: Delivers a beep tone with non-adjustable volume to the collar.  6.Description of the vibration mode (How to adjust the level, level instructions): Vibration command: Press the vibration key, the receiver will vibrate. Intensity adjustment: After pressing the side vibration button, adjust the vibration level (1-8) by the side vibration button. 	7.Instructions for the electric shock order (How to adjust the level, level instructions): Static button: Delivers currently selected level Static stimulation to the collar. Shock Boost that is 20% higher than the currently selected level. Static Intensity adjustment: After press the static button, adjust the static level by "+" and "-".  8.Channel switching instructions: Channel switching it is able to train 4 dogs at the same time. Press the channel button to select the dog to train. 	9.Description of the Auto command Auto command: Press the Auto key for 3 seconds, the receiver beeps, the dog icon and "sensitivity" will appear on the screen, the product enters automatic mode, then you will get a smart dog bark collar.  Dog bark collar turn on/off Turn on Short press the "M", the indicator light will be on, and you will feel "vibration". It indicates the dog bark collar has been successfully turn on. Turn off Long press the "M", the screen will off and you will feel "vibration". It indicates the dog bark collar has been successfully turn off. 4 Mode Press the "M" button to switch modes. Modes will be changed according to display. 
CAUTION 1. When the receiver in the automatic mode, the remote control does not in the automatic mode. Press the remote control and it will be a dog training collar, you can control it with the remote again.  2. When the receiver and remote control are in automatic mode at the same time you can only control the sensitivity(1-8) of the receiver with the remote. 	Main Features 4 Training Modes(Vibration, Beep, Shock and Shock Boost). 8-speed vibration adjustable and 0-99 shock adjustable. Receiver Collar IP67 Waterproof, Remote IP53 Waterproof. Remote Range 2000 FT. 2-Hour Rapid Charging Lithium Polymer Battery. Colorful Digital Display Shows Intensity Level, Battery and Dog Support 4 Receiver Collars with One Remote.	Use of the Test Light Tool A: Electric shock test 1. Make sure the Remote and Receiver Collar on. 2. Hold the Test Light Tool contacts to the Contact Points. 3. Press A Static button on the Remote Transmitter. The Test Light will be lighted.  B: As a tool to tighten or loosen the contact points For dog with shorter coats, use 2pcs shorter contact points. For dog with thicker coats, use 2pcs longer contact points. Install the conductive Silicone onto the contact point to make it softer. It may better to your dog's skin. 	Training Tips 1. Reward your dog with food / treats will usually help to achieve the best training result. 2. Do not use the device on dogs aged below 6-month, old, pregnant, easily frightened, aggressive, in heat, and in inferior health conditions. 3. Use verbal commands first, and complement with a corrective stimulus only as needed. Be consistent with your verbal commands, use the same words every time. Work with your pet on one behavior at a time to avoid confusion and frustration. 4. Use as little stimulus as possible and only to reinforce verbal commands when necessary. Do not over correct your dog. 5. For example, use the beep sound as warning by pressing the beep button. The dog will become conditioned to the beep preceding the corrective stimulus and will soon learn to recognize the beep as a warning along with your verbal command. 6. Do not rely on this product solely to train your dog. Some dogs will not respond to this product. We cannot guarantee the effectiveness of this or any trainer on your dog. If your dog shows signs of growling, biting or aggression while using the collar, discontinue use immediately and contact a professional trainer for advice. 7. It is recommended to train one dog at a time in a distraction-free environment, both to increase efficiency and to avoid temptation or distraction from other dogs.	Pairing Instructions (Note: You can skip this step as the device is factory paired.) Match the remote to the receiver: 1. Make sure the receiver is turned off. 2. Press and hold the receiver switch for 5 seconds until the digital light flashes quickly. 3. Press the remote control pairing button to pair the receiver. 4. Pairing is successful: the receiver will beep and the digital light will flash.  (Note: If you are only using one receiver, skip this step.) The following settings apply to multiple receivers with one remote.) Part I: Pairing a 2nd, 3rd or 4th Receiver. Pairing multiple receivers: 1. Make sure the receiver is turned off. 2. Press and hold the receiver switch for 5 seconds until the digital flashes quickly. 3. Press the channel key, select the channel in advance, and select the number you want. 4. Pairing is successful: the receiver will beep and the digital light will flash.	Question & Answer How to change the longer prongs for this collar? I don't think they are getting through my Labs thick hair. Answer: Just part the hair or trim it a bit. I have a dog with very thick neck of hair. I parted it with my hands. Just be sure remote is off then start on low setting and work your way up. If no response repeat steps of working prongs down hair remember to turn off or lock remote. Is the Vibration/ Shock safe for my pet? Answer: While the Vibration/ Shock is unpleasant, it is harmless to your pet. Electronic training devices require interaction and training from the owner to achieve desired results. Troubleshooting 1. My pet is not responding when I press a beep vibration or static button. Check the Receiver Collar if it is On.
Please check if the battery is low in either the Remote Transmitter or Receiver Collar.  Test the Receiver with the Test Light to confirm if shock functions normally.  • Increase the correction level. Refer to "Find the Best Stimulation Level For Your Dog".	• Make sure the Receiver Collar's Contact Points are placed snugly against your pet's skin.  2. Fail to match receiver with remote Ensure the receiver is connected to a power source (charging mode can only be activated while charging). Must hold the channel switch for more than 5 seconds, if not, matching will fail. If the problem persists after attempting as above, please contact us to confirm whether the receiver and the remote are of the same version. 	3. Remote/receiver does not response. 1) Verify if the Receiver Collar is on.  2) Verify if the battery of the Transmitter is fully charged.  3) Verify if the training collar has been paired. 	4) Check that the channel selected by the remote control is the same as the channel of the receiver.  How to replace the replacement strap 1. Remove the screws at both ends. 2. The replacement strap has arrows and left and right end marks. 3. Follow the prompts to attach the replacement strap to the receiver. 4. Tighten the screws and attach the straps to the length that fits your dog.	Operating Environment & Maintenance Do not use the product in the circumstances as follow: 1. Do not operate the devices under temperature of 104°F and above, doing so in such high temperature will decrease the performance of the batteries. 2. Do not use the set in places with strong electromagnetic interference. This will greatly compromise the performance of the product. 3. Avoid dragging the devices on hard surface or inflict excessive force on them. 4. Avoid using the devices in environment flooded with corrosive chemical, this may lead to color degrading, deforming, or cracking of exterior of the devices. Maintenance: 1. When not in use, please wipe clean both the Remote and Receiver with mild detergent. Turn off the Receiver, lock the keypad, put on the rubber lid on the Receiver's charging port, and store the set in a cool dry place. 2. During cleaning, wipe with soft cloth and mild detergent. Do not use hard brushes which may scratch the surface of the device. 5. If the Remote fell into water, pick it up quickly and turn off the power. Dry it with cloth as much as you can and let it out to dry. It should resume function normally once the moisture is dried out.	Customer Support Dear Customer, THANKS FOR YOUR ORDER! Your nice sharing will encourage us to improve our products and service, we will do our best to offer you a pleasurable shopping experience. We provide 12 months warranty, if any questions or problems about this bark collar, please feel free to contact us via email. fangfang2023@163.com Best Wishes Search Fdceligoo Bark Collar on Amazon for more product information.

FCC Caution:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

