


PRIME[®] outdoor & remote controlled SmartOutlets[™]

Rated for Indoor
and Outdoor use

Each Box Contains:
2 SmartOutlets
1 Remote Control
1 Wall Mounting Plate
1 Instruction Manual

Required tools:
Screwdriver (not included)



Let's get started by
downloading the App!
See step 1

Strain Relief:
See mounting instructions

Manual Override Button:
Push this button if you do not
have your smartphone and
remote and need to turn the
device ON or OFF

Indicator Light Colour Key:
Blue = Outlets are powered
Flashing Blue = Device is ready
to connect
Blue = Device is connected

2 Grounded Outlets:
Both outlets operate in unison

On/Off Buttons I:
Primary SmartOutlet[™]

On/Off Buttons II:
Secondary SmartOutlet[™]

Congratulations on your purchase of PRIME SmartOutlets + Remote Control!
After a fast and free download, the Prime Wire and Cable, Inc. App will walk you
through the complete setup process for your new SmartOutlets. The Remote
is preprogrammed and will work out of the box.

**1 Download the
Prime Wire and Cable, Inc. App
on your smartphone or tablet**

Scan the QR code to get the App, or search
Prime Wire and Cable, Inc.
in the App Store or Google Play Store

Download on the
App Store

GET IT ON
Google Play

**2 Plug in your device and the
SmartOutlets**

1. Ensure your device is switched to the ON position and plug it into the SmartOutlets
2. Plug SmartOutlets I & II into an outdoor rated GFCI receptacle and they will pair automatically during setup

**3 Open the
Prime Wire and Cable, Inc. App**

Set up your free account and follow the
on-screen guide to add devices, set schedules,
and control devices from anywhere

**4 Connect to Google Assistant,
Amazon Alexa or Siri Shortcuts using
the guide in the Prime App**

Follow the step by step
guides to connect your
Google Assistant, Alexa
or Siri Shortcuts

SAFETY INFORMATION & SPECIFICATIONS

THIS TIMER IS A "GROUNDED" DEVICE
The male plug contains a ground pin and is
only intended for use with a three-pronged
grounded outlet.



THIS TIMER IS FOR USE WITH A 125VAC POWER
SOURCE.

125VAC / 60Hz

DO NOT ATTACH A DEVICE THAT EXCEEDS THE
UNIT RATINGS:

15A / 1875W Resistive
8A / 1000W Tungsten
1/3 HP

Do not plug heaters or heat producing devices
such as coffee makers, toasters, clothes irons, etc.
into the SmartOutlets.

LIMITED 1 YEAR WARRANTY

Prime warrants this product to be free from manufacturing
defects for a period of one year from the original date of
purchase ("warranty period"). This warranty is limited to the
repair or replacement of this product only and Prime is not
liable for any consequential or incidental damage to other
products that may be used with this unit. This warranty is
effective only if this unit is returned to Prime not later than
thirty (30) days after the expiration of the warranty period.
Warranty is void if damage is due to neglect, misuse,
alteration, modification, improper installation, or repair by
other than Prime. This warranty is in lieu of all other
warranties express or implied. Some provinces do not allow
limitations on how long an implied warranty lasts or permit the
exclusion or limitation of incidental or consequential
damages, so the above limitations may not apply to you.

It is our experience that a product that fails prematurely due to
a manufacturing defect in materials or workmanship, will
generally do so very early in the product's life cycle, often the
first or second time the product is used. Products that are
returned for warranty inspection after months or years of
continuous reliable service are usually the result of normal
wear and tear, which is not considered a defect in materials or
workmanship and therefore is not covered by the warranty.

This warranty gives you specific rights, and you may also
have other rights which vary from province to province. If unit
should prove defective within the warranty period, return
within the time period set forth above prepaid with the original
purchase receipt to:

Prime Wire & Cable, Inc.
ATTN: Timer Warranty
1330 Valley Vista Drive
Diamond Bar, CA 91765
Service • (888) 445-9955 • www.primewirecable.com

FCC REGULATORY STATEMENT

WARNING: Changes or modifications to this unit not
expressly approved by the party responsible for
compliance could void the user authority to operate the
equipment.

This device complies with part 15 of the FCC rules.
Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received,
including interference that may cause undesired
operation.

Notes: This equipment has been tested and found to
comply with the limits for a Class B digital device, pursuant
to Part 15 of the FCC Rules. These limits are designed to
provide reasonable protection against harmful interference in
a residential installation. This equipment generates,
uses and can radiate radio frequency energy and, if not
installed and used in accordance with the instructions, may
cause harmful interference to radio communications.
However, there is no guarantee that interference will not
occur in a particular installation. If this equipment does
cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and
on, the user is encouraged to try to correct the interference
by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and
receiver.
3. Connect the equipment into an outlet on a circuit
different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV
technician for help.

FCC RF exposure statement:
The equipment complies with FCC radiation exposure
limits set forth for an uncontrolled environment. This
equipment should be installed and operated with minimum
distance between 20cm the radiator your body.

IC REGULATORY STATEMENT

Under Industry Canada regulations, this radio transmitter
may only operate using an antenna of a type and
maximum (or lesser) gain approved for the transmitter by
Industry Canada. To reduce potential radio interference to
other users, the antenna type and its gain should be so
chosen that the equivalent isotropically radiated power
(e.i.r.p.) is not more than that necessary for successful
communication.

This device complies with Industry Canada licence-exempt
RSS standards. Operation is subject to the following two
conditions: (1) this device may not cause interference, and
(2) this device must accept any interference, including
interference that may cause undesired operation of the
device.

INSTALLATION INSTRUCTIONS:

1. Install SmartOutlet to a vertical flat surface close to
a properly installed, outdoor rated, and grounded
receptacle.
2. Using a screw or hook (not included), secure the
mounting tab at the top of the SmartOutlet to a
wall or post.
3. If desired, the included wall plate can be mounted with
the included double sided tape to a wall. The remote
can be placed into the wall plate.

FAQ

• **How do I turn SmartOutlet On/Off if I do not have
my smartphone and remote?**

• Press the button on the front of the SmartOutlet
for manual On/Off control.

• **The indicator light on the front of the SmartOutlet
is not blinking rapidly. How do I make it blink
rapidly, so I can connect the SmartOutlet?**

• Press and hold the button on the front of the
SmartOutlet for 5 seconds. The indicator light
in the button will begin blinking rapidly, and is
ready to connect.

• **What if SmartOutlet doesn't connect to app?**

• Confirm SmartOutlet is powered on.

• Confirm SmartOutlet is waiting for network
configuration. Indicator light on SmartOutlet is
rapidly blinking.

• Confirm the SmartOutlet, smartphone/tablet, and
router are as close to each other as possible.

• Ensure the networks of the wireless router and
smartphone/tablet are unblocked.

• Confirm the network password is entered correctly.

• Confirm the wireless router is using a 2.4GHz Wi-Fi
Channel. Ensure the wireless router is broadcasting
and the Wi-Fi signal is not hidden.

• Confirm the wireless router's encryption method is
WPA2-PSK and authentication type is AES.

• Confirm that both are setup as automatic.

• If router enables MAC address filter, please remove
the device from the MAC filter list and ensure the
wireless router is allowing devices to be connected.

• Note that this 2-pack system does not accept any
other SmartOutlets to be added to its program.

RF exposure statement:

The equipment complies with IC Radiation exposure limit set forth
for uncontrolled environment. This equipment should be installed
and operated with minimum distance 20cm between the radiator
and your body.

- French:

Cet appareil contient des émetteurs / récepteurs exemptés de
licence conformes aux RSS (RSS) d'Innovation, Sciences et
Développement économique Canada. Le fonctionnement est
soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Cet appareil doit accepter toutes les interférences, y compris
celles susceptibles de provoquer un fonctionnement indésirable
de l'appareil.

Déclaration d'exposition RF:

L'équipement est conforme à la limite d'exposition aux radiations
de la IC établie pour un environnement non contrôlé. Cet
équipement doit être installé et utilisé avec une distance minimale
de 20cm entre le radiateur et votre corps.

• **How do I re-sync the remote if it does not switch a
SmartOutlet ON or OFF?**

• Only plug one SmartOutlet into a properly grounded
outlet at a time.

• Press ON button on remote until LED on
SmartOutlet flashes.

• Unplug SmartOutlet and repeat with other
SmartOutlet if needed. If re-sync fails, push power
button on SmartOutlet ON and push OFF button on
remote until SmartOutlet power button flashes.

• Repeat re-sync.

• Note that you may have to replace the CR2032, 3V
battery in the remote by removing the screw and
pushing the tabs on each side to pull out the
battery tray.

• This remote does not work with any other
SmartOutlets, only with this 2-pack system.

• For additional FAQ's please see the FAQ section
in the Prime Wire and Cable, Inc. App

• Profile -> FAQ

NOTE: Not for use in wet locations such as sinks, saunas,
showers or with aquariums.

**WARNING: DO NOT DISPOSE OF BATTERIES IN FIRE.
BATTERIES MAY EXPLODE OR LEAK.**

• Non-rechargeable batteries are not to be recharged.

• Batteries are to be inserted with the correct polarity.

• Exhausted batteries are to be removed from the product.

WARNING: CHOKING HAZARD - Small Parts.
Not for children under 3 years.

Costco Wholesale Canada Ltd.* ©2023 Prime Wire & Cable, Inc.

415 W. Hunt Club Road Diamond Bar, CA 91765

Ottawa, Ontario Service (888) 445-9955

K2E 1G5, Canada PST: 7am - 5pm

1-800-463-3733 www.costco.ca

* nearest affiliate au Québec sous le nom les Entreprises Costco

www.primewirecable.com

rev. 01-062023 KT

Apple, the Apple logo, and Siri are trademarks of Apple Inc., registered in the U.S. and
other countries.

App Store is a service mark of Apple Inc., registered in the U.S. and other countries.

Google, Google Home, Google Assistant, Android, the "Google Play" logo, and "Works
with Google Home" are trademarks of Google LLC.

Amazon, Alexa and all related logos are trademarks of Amazon.com, Inc. or its affiliates.

Prime Wire & Cable, Inc. is not affiliated with Apple, Google or Amazon.