


Remote Control Instruction Manual

Congratulations on your purchase of Outlets + Remote Control! The Remote is Pre-programming.



How do I re-sync the remote:

- How do I re-sync the remote if it does not switch a Remote control

Outlet ON or OFF?

- Only plug one Remote control Outlet into a properly grounded outlet at a time.
- Long press the button on the remote control socket for 3 seconds; after that, the indicator light on the remote control socket will remain lit continuously.
- Press the NO button on the remote control until the LED indicator on the remote socket blinks, and press ON/OFF to control the remote socket.
- Note that you may have to replace the 23A, Pressing down on the clips on either side will allow you to pull out the battery tray to access the 12V battery inside the remote control.

FCC REGULATORY STATEMENT WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two

conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC RF exposure statement: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Walmart warrants this product to be free from manufacturing defects for a period of one year from the original date of purchase ("warranty period"). This warranty is limited to the repair or replacement of this product only and Walmart is not liable for any consequential or incidental damage to other products that may be used with this unit. This warranty is effective only if such unit is returned to Walmart not later than thirty (30) days after the expiration of the warranty period. Warranty is void if damage is due to neglect, misuse, alteration, modification, improper installation, or repair by other than Walmart. This warranty is in lieu of all other warranties express or implied. Some provinces do not allow limitations on how long an implied warranty lasts or permit the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

It is our experience that a product that fails prematurely due to a manufacturing defect in materials or workmanship, will generally do so very early in the product's life cycle, often the first or second time the product is used. Products that are returned for warranty inspection after months or years of continuous reliable service are usually the result of normal wear and tear, which is not considered a defect in materials or workmanship and therefore is not covered by the warranty. This warranty gives you specific rights, and you may also have other rights which vary from province to province. 2026 Walmart Inc. All Rights Reserved. Distributed by/Distribuido por Walmart Inc., Bentonville, AR 72716 MADE IN VIETNAM, For customer service, please call 833-908-2024.