KiKF

iKF–Solo
Wireless Headphones

Please read this manual carefully before you operating. You can and retain it for future reference

WELCOME

Thank you for using the iKF– Solo , We hope you will enjoy it!

Official package including:
Headphone*1
Charging/Audio cable(TYPE– C USB)*1
User manual*1

BEFORE USE

Important Safety Instructions

1、Read these instructions。
2、Keep these instructions。
3、Heed all warnings。
4、Follow all instructions。
5、Do not use this apparatus near water。
6、Clean only with a dry cloth。
7、Only use attachments/accessories specified by the manufacturer。
8、Refer all servicing to qualified personnel。Servicing is required when the apparatus has been damaged in anyway, such as power=supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped。

WARNINGS/CAUTIONS

- Do NOT use the headphones at a high volume for any extended period。
- To avoid hearing damage, use your headphones at a comfortable, moderate volume level。
- Turn the volume down on your device before placing the headphones on your ears, then turn the volume up gradually until you reach a comfortable listening level。
- Do NOT use your headphones while driving for phone calls or any other purpose。
- Do NOT use the headphones with noise canceling on at any time the inability to hear surrounding sounds may present a danger to yourself or others, e.g., while riding a bicycle or walking in or near traffic, a construction site or railroad。Always follow applicable laws regarding headphone use。
- Remove the headphones, or use the headphones with noise canceling off and adjust your volume, to ensure you can hear surrounding sounds, including alarms and warning signals。
- Be aware of how sounds that you rely on as reminders or warnings may vary in character when using the headphones。
- Do NOT use the headphones if they emit any loud unusual noise, if this happens, turn the headphones off and contact iKF customer service。
- Remove headphones immediately if you experience a warming sensation or loss of audio。
- Do NOT use mobile phone adapters to connect headphones to airplane seat jacks, as this could result in injury or property damage due to overheating。
- Do NOT use the headphones as aviation communication headsets。

Contains small parts which may be a choking hazard, Not suitable for children under age 3。

This product contains magnetic material, Consult your physician on whether this might affect your implantable medical devices。

- To reduce the risk of fire or electrical shock, do NOT expose this product to rain, liquids or moisture。
- Do NOT expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the product。
- Do NOT make unauthorized alterations to this product。
- Use this product only with an agency-approved power supply that meets local regulatory requirements (e.g., UL, CSA, VDE, CCC)。
- If the battery leaks, do not allow the liquid to come in contact with the skin or eyes, if contact is made, seek medical attention。
- Do not expose products containing batteries to excessive heat (e.g, from storage in direct sunlight, fire or the like)。
- Do NOT wear the headphones while charging。
- The headphones do not play audio while charging

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in aresidential installation, This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However there is no guarantee that interference will not occur in a particular installation, If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the users encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna。
- Increase the separation between the equipment and receiver。
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected。
- Consult the dealer or an experienced radio/TV technician for help。

Changes or modifications not expressly approved by iKF could void the user' s authority to operate this equipment。

This device complies with part 15 of the FCC Rules standard(s), Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and(2) this device must accept any interference received, including interference that may cause undesired operations。

This device complies with FCC radiation exposure limits set forth for general population。

This transmitter must not be co- located or operating in conjunction with any other antenna or transmitter。

Getting assistance

For assistance with this product, please contact our customer service at the website where you purchased the product, leave a message or email us, we will answer as soon as possible。

Company: Dongguan Oumu Technology Co., Ltd.
Address: Room 315~ 319, Building D, Nanxin Industry International, Nancheng District, Dongguan City, Guangdong Province, China
Website: http://ikf.vip/cn
Email：support@163.com

SPECIFICATIONS

Model: iKF– Solo
Bluetooth version：V5.3
Power input: DC 5V
Input parameters: 500mA
Charging interface: TYPE– C USB
Battery capacity: 1000mAh
Charging time: about 2 hours
Supporting agreement: HSP/HFP/A2DP/AVRCP

HOW TO CHARGE

For the first time use, please fully charge the product。
Charging: The power indicator light is solid red
Full power: The red light of the power indicator is off
Charging time: 2 hours
Low battery alarm: Voice prompt once when the battery is low。

WARNINGS

When charging the headset,to avoid damage to the battery, it is recommended to use a 5V/2A charging head to charge, The power of the charging head should not exceed 24W。
Avoid using car charger(fast charging power bank or charging head with unknown power for charging, there may be situations where charging cannot be performed or the power consumption is too fast and the signal is poor。

INSTRUCTION



POWER ON/OFF

Power on: Long press the power button 2 seconds and hear the prompt that it is turned on;
Power off: Long press the power button 3 seconds and hear the prompt that it is turned off;

HEADPHONE STATUS

LED indicator

Turn on: Signal light flashing white and green
Turn off: The signal light is white for 2 seconds
Connection successful: light is red on
Incoming call status: Green light is on every 10 seconds
(When a call comes in, it will prompt the ringtone of the mobile phone synchronously, if the mobile phone does not support synchronous ringtone, prompt tone "Dididididi")
Low battery: The red light flashes quickly

iKF APP CONNECTION

Android phone connection

1、The Headphone is turned on and the Bluetooth of the mobile phone is turned on, and the APP is running on the page
2、❶ APP page pop-up window pops up the model, just connect
❷ On the home page of the APP, click "+" in the upper right corner to add a device
❸ After automatically searching for the device, click "Connect"。

iOS system device connection

1、Need to manually connect the headset on the iOS device Bluetooth page
2、Open the iKF APP page
3、❶ APP page pop-up window pops up the model, just connect
❷ On the home page of the APP, click "+" in the upper right corner to add a device
❸ After automatically searching for the device, click "Connect"。

HOW TO CONNECT

1、Long press the power button 2S and hear the prompt that it is turned on；

2、Open the Bluetooth interface of the mobile phone, search for "iKF– Solo", click to connect；

3、After the first pairing and connection is successful, the headset will automatically connect to the last mobile phone with a connection record every time it is turned on, and there is no need to repeat pairing。

BUTTON CONTROLS

Call with headset

Double-tap the power button	Answer
Tap the power button 4 times	Hand up
Long press the power button 2S	Incoming telegram Reject

Listen to music with headset

Tap the power button	Play/Pause
Tap the + button	Volume up
Tap the – button	Volume down
Long press the + button 2S	Skip track forward
Long press the – button 2S	Skip track backward
Tap the ANC button 4 times	Wake up voice assistant

Three modes switch

Tap the "ANC" button cycle through "Music Mode/ANC Mode/ Transparent Mode"

❶ → ❷ → ❸

Movie mode

Turn on: Double-tap the "ANC" button, and you will successfully enter the movie mode when you hear the prompt sound；
Turn off: Double-tap the "ANC" button, and you will successfully exit the movie mode when you hear the prompt sound。

Transparent Mode (Touch control)

Transparent mode (touch control) is enabled by default, if you are worried about accidental touch, you can turn off the control of the touch panel。
Turn on /off: Triple– tap the power button, and you will successfully entered the transparent touch mode when you hear the prompt:
Put your hand on the touch panel to turn on the transparent mode to hear the sound of the outside world, and release it to exit the transparent mode

Game mode

Turn on: Triple– tap the "ANC" button, and you will successfully enter the game mode when you hear the prompt sound；
Turn off: Triple– tap the "ANC" button, and you will successfully exit the game mode when you hear the prompt sound。

Reset

In the power– off state, press and hold the power button for 5 seconds to enter the re– pairing state。

Wired connection

The audio cable (Type-C port) is inserted into the headphone, the USB port is connected to the device you want to connect, the Bluetooth function is automatically turned off。
The USB ALCAD cable supports two functions of headphone charging and computer audio transmission。

External microphone

Insert the configured microphone into the microphone jack, the headset are aloane。
The headset can also use an external microphone in wired connection

TIPS

1、Make sure the headset and the connected device are within a valid connection range and there are not too many obstacles that interfere with the signal。
2、It is normal for the headset to be disconnected occasionally, Just like WiFi, occasionally the connection is unstable, It may be due to interference in signal transmission,,Please wait a moment or change the location to resolve;
3、When the headset cannot be connected to the device, please check whether the headset has power or is connected to other devices;
4、Please fully charge the Headphone once a month, if the Headphone is not used for a long time, the battery of the Headphones may be damaged。
5、The sound insulation and sound leakage of headphones are related to the way of wearing the headphones and the volume of the headphones。
You can adjust the wearing angle and degree of ear wrapping of the headphones in time according to the actual comfort of use, Please close the earhead from part of the headphone as much as possible。
6、Please use a standard– compliant charging head to charge the headset。
7、Do not wear the product for bathing, or use it in the rain, and do not soak the product in water, After each normal use, it is recommended to dry the sweat or stains on the headphone with a dry cloth, paper towel, etc., and then store it。

LIMITED WARRANTY

Warranty period、1 year from the date of product receipt

During the warranty period of the product, due to the quality of the product itself, please contact us with the warranty card and shopping records to receive a return authorization / free maintenance and shipping instructions。

Fault Table

1、Bluetooth headset cannot hear sound;
2、The other side cannot hear the voice during the call;
3、Unable to charge Bluetooth headset

The following conditions will not provide free repair：

1、Unauthorized maintenance, misuse, collision, neglect, abuse, accident, alteration, or damage or alteration of the appearance of the product;
2、The product exceeds the warranty period specified by the company;
3、Damage caused by self–disassembly;
4、Failures caused by accidents such as water ingress or falling, squeezing, etc;
5、Normal wear and det caused by use, such as scratches, damage caused by contact with chemical reagents, contact with sharp objects;
6、Outer packaging and accessories, gifts, services other than the products promised by the sales staff, and additional configurations and gifts;
7、Improper storage: If the product is exposed to abnormal humidity and temperature for a long time, the performance is damaged;
8、Failure or damage caused by force majeure;

KiKF

Focus on interesting musical products

We apologize for any inconvenience caused by any typographical or translation errors. If the content is corrected later, please forgive us without notice.

Made in China