


102.5*64.5MM 128克铜板纸 风琴折 双面印刷 Works with Apple Find My	Find TSA Lock 	Setting Up Your iPhone Compatibility The lock is only compatible with iPhone 8 series or later phones running iOS 14.5 or later with Two-Factor Authentication turned on. 1. Turn on Two-Factor Authentication for your Apple ID On your iPhone: Go to Settings > your name > Password & Security. Tap Turn On Two-Factor Authentication. Then tap Continue and follow the onscreen instructions. On your Mac: choose Apple menu > System Settings (or System Preferences), then click on your name (or Apple ID). Click Password & Security. Next to Two-factor Authentication, click Turn On and follow the onscreen instructions. On the web: Go to appleid.apple.com and sign in using your Apple ID. Answer your security questions, then tap Continue. Tap Continue when you see a prompt to update account security. Then tap Update Account Security and follow the onscreen instructions. 2. Turn on Find My A. Go to Settings. B. Tap your name, then tap Find My. C. Tap Find My iPhone and turn on Find My iPhone. 3. Turn on Bluetooth	4. Connect to a stable Wi-Fi or cellular network 5. Turn on Location Services Go to Settings > Privacy & Security > Location Services > turn on Location Services. Getting Started Power on Short press the lock's power button once, and a beep will sound to indicate that it is turned on. Power off To turn off the power, press the power button 3 times in a row (2 short presses and the last long press); after hearing two "beeps", the "lock" is turned off. If the lock has not been paired within 10 minutes, a beep will be heard and the power will automatically turn off. Turn on the power to continue pairing. Factory reset To reset, press the power button 5 times in a row (4 short presses and the last long press); after hearing a beep, the "lock" returns to factory setting. Pairing Your Lock 1. Ensure your iPhone is set up (see "Setting Up Your iPhone" above) and your	lock is powered on. 2. Open the Find My app. 3. In the Items tab, tap Add New Item. 4. Tap Other Supported Item (your iPhone will search for your lock). 5. Once your lock is detected, tap Connect. 6. Follow the onscreen steps to name it and register it to your Apple ID. 7. Ensure your lock appears in Items. If not, forget the device, perform a factory reset on the lock (see "Getting Started > Factory reset" above), then reconnect. * Do not leave Find My app while pairing lock. Locating Your Lock Locate your lock via the map 1. Open the Find My app. 2. Tap the Items tab. 3. Select your lock in the Items list. 4. Tap Directions to open the location of your lock and get directions in the Maps app. Play sound alert 1. Open the Find My app. 2. Tap the Items tab. 3. Select your lock in the Items list and tap Play Sound. * The sound alert will only play if your iPhone is connected to a network. and your lock is in Bluetooth range of your iPhone (approx. 160f/50m).	Set up Notify When Left Behind If your lock is not in Bluetooth range of your iPhone for a period of time, you will receive a notification that your lock has been lost (if you set up a name, the name will be displayed, otherwise it will show lock). 1. Open the Find My app. 2. Tap the Items tab. 3. Select your lock in the Items list and scroll down. 4. Under Notifications, tap Notify When Left Behind and turn on. Mark your lock as lost 1. Open the Find My app. 2. Tap the Items tab. 3. Select your lock in the Items list and scroll down. 4. Ensure Notify When Left Behind is turned on. 5. Under Lost Mode, tap Enable, then tap Continue. 6. Enter your phone number/email address so that the lock of your lock can contact you, then tap Activate. Changing the Name of Your Lock 1. Open the Find My app and tap the Items tab. 2. Select your lock in the Items list. 3. Scroll down and tap Rename Item. 4. Select a name from the list or select
--	--	--	--	--	--

Custom Name. 5. For Custom Name, input a name and select an emoji. 6. Tap Done. Removing Your Lock Removing your lock from your Apple ID will allow it to be activated and used by another person. 1. Ensure that your lock is connected to your iPhone*. 2. Open the Find My app. 3. In the Items tab, tap the lock. 4. Tap Remove Item, tap Remove and confirm to remove. * If not connected when removing your lock from your Apple ID, it will no longer be discoverable and you will need to perform a factory reset before creating a new connection (see "Getting Started > Factory reset" above). Unwanted Tracking Notification If your lock is separated from your iPhone and is detected moving with another person with an Apple device over time, that person will receive a tracking alert message. Safety Warnings 1. Do not expose the device to	temperatures below -10°C (14°F) or above 35°C (95°F). 2. Do not expose the device to an open flame, submerge it in water, or expose it to rain as this will damage the device. 3. Always check for damage to the device, cables, or other accessories before using the device. If damaged, do not use the device. 4. Do not attempt to disassemble, modify, or use sharp objects to damage the device in any way, as it may cause serious damage and void the warranty. 5. Do not expose the device to corrosive liquids, or high humidity as they will seriously damage the device and void the warranty. Charging Your Lock Use the cable to charge. During charging, the status light will be orange. When fully charged, the status light will turn green. It is recommended to fully charge your lock once every 3 months. The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac, or the Find Items app on Apple Watch. To use the Apple Find My app to locate this	item, the latest version of iOS, iPadOS, or macOS is recommended. The Find Items app on Apple Watch requires the latest version of watchOS. Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards. Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license. More Specific Info 1. How long will the battery last when fully charged? After activating the device, it needs to be fully charged immediately and can be used normally for 4 months. It is recommended to charge it every 3 months. 2. How do you know the remaining power? iPhone 8 or Later will display the	remaining battery level of the device on Find My App. 3. How long does it take to fully charge the battery? 1h30min 4. Charging indicator light • Charging: Orange light • Full Charging: Green light How to Change the Password Default Password: 000 To Set a New Password: 1.Set the dials to the Original password. 2.Press and hold the button on the bottom. 3.While holding the button, set your desired new password by rotating the dials. 4.Release the button, your new password is now confirmed.	FCC Caution This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.	
---	--	---	--	---	--